PREVENTIVE MAINTENANCE SCHEDULE MONTHLY OF DIESEL TRACTOR TLD 025 A (TR)

GSE NUMBER		SUBJECT	TASK CARD NO.
TLM-TR-025		SCHEDULE A	TR-TLD-025-A-TLM
CHA NO	ENG NO		W.O. NO.
N/A	N/A		2311255

SER NO	HR METER	INSP. TYPE	INTERVAL	EFFECTIVITY	PAGE :
T36406	2315.5	SVC	250 H / 3 MO	TLD-025	1 of 5

GENERAL

This task include check list on daily check, basic check, shortest repetitive interval until 250 service hours.

A. References :

Reference	Title
GRS-RM-CK-060	Preventive Maintenance for Baggage Tractor (TR)

B. Fixtures, Tools, Test and Support Equipment

REFERENCE	DESCRIPTION
……	
……	
……	

C. Consumables Materials

DESCRIPTION	SPECIFICATION
……	KL094
……	15W40

DATE	REPORTED BY	DATE	VERIFIED BY
13/10/2026	TL258189 Mr.Jeeraphat Phothong TL258190 Mr.Wuttichai Chaiyarat	13/10/2026	TL130201 Mr.Chaiwat Panseethong TL130056 Mr.Non Vismitananda

Thai Lion air

PREVENTIVE MAINTENANCE SCHEDULE MONTHLY OF DIESEL TRACTOR TLD 025 A (TR)

GSE NUMBER	SER NO	TASK CARD NO.	W.O. NO.	PAGE :
TLM-TR-025	T36406	TR-TLD-025-A-TLM	2311255	2 of 5

ITEM	DESCRIPTION	PERFORMED BY
	BASIC CHECK (GENERAL&ELECTRICAL SYSTEM)	
	1. Check fuel level	✓
	2. Check engine oil	✓
	3. Tires pressure Rear: 104 Psi, Front: 58 Psi	✓
	4. Check tire treads / clean tire if necessary	✓
	5. Check headlight for normal operation	✓
	6. Check stop light, warning light, rear light, beacon light, etc.	✓
	7. Check all cabin function wiper, roof light	✓
	8. Check horn and backup alarm	✓
	9. Check brake fluid level	✓
	10. Check battery charge	✓
	11. Check wheel nuts torque Front: 88.5 ft.lb (120 N.M), Rear:362 ft. lbs (500 N.M)	✓
	12. Check axle fixation on the leaf springs	✓
	13. Check beacon light for available	✓

Thai Lion air

PREVENTIVE MAINTENANCE SCHEDULE MONTHLY OF DIESEL TRACTOR TLD 025 A (TR)

GSE NUMBER	SER NO	TASK CARD NO.	W.O. NO.	PAGE :
TLM-TR-025	T36406	TR-TLD-025-A-TLM	2311255	3 of 5

ITEM	DESCRIPTION	PERFORMED BY
	14. Check rear axle oil level	✓
	15. Check exhaust pipe for leak	✓
	16. Drian water at the water / fuel separator side	✓
	250 HOURS	
	1. Check king pins and hub bearing for play	✓
	2. Parking brake. With parking brake engaged, tractor have to stay parked in position on a 8% slope if tractor is not parking brake cable accordingly	✓
	3. Alternator belt tighten, if necessary check manufacturer OM for details	✓
	4. Check hydraulic oil level and refill if necessary	✓
	5. Inspection engine coolant hoses and transmission oil cooled hoses	✓
	6. Check brake pads and disk wear, refer to below spreadsheet	✓
	7. Check brake pedal pivot and spring grease if necessary	✓
	8. Check abnormal play in the cardan shaft between transmission and rear axle grease the shaft nipples	✓
	9. Inspect acceleration cable for abnormal wear	✓

PREVENTIVE MAINTENANCE SCHEDULE MONTHLY OF DIESEL TRACTOR TLD 025 A (TR)

GSE NUMBER	SER NO	TASK CARD NO.	W.O. NO.	PAGE :
TLM-TR-025	166406	TR-TLD-025-A-TLM	2611286	4 of 5

ITEM	DESCRIPTION	PERFORMED BY
	10. Check front axle toe-in and inspect hub bearing	✓
	11. Check brake calipers to detect any abnormal leak	✓
	12. Gresae all greasing ports and nipples	✓
	13. Check engine hood lock	✓
	14. Grease steering swivels	✓
	15. Drain and replace engine oil. Check related manufacturer OM manual Every 250hr on Cummins engine. Every 500hr on other engine (Deutz, Perkins)	✓

Thai Lion air

PREVENTIVE MAINTENANCE SCHEDULE MONTHLY OF DIESEL TRACTOR TLD 025 A (TR)

GSE NUMBER	SER NO	TASK CARD NO.	W.O. NO.	PAGE :
TLM-TR-025	T36406	TR-TLD-025-A-TLM	2311255	5 of 5

GENERAL

DEFECT FOUND : ☐ **Yes** ☐ **No**

✓

RECTIFICATION : .....

.....

.....

.....

COMPONENT / MATERIAL REQUIRED				
NO.	**DESCRIPTION**	**PART NO.**	**QTY**	**S/N NO. / BATCH NO. / P.O NO.**
1	.....	7.00-14	1	

☐ Time Critical ☐ Time Sensitive ☐ Frequently Used ☑ Reference

☐ Doc. Level 1 ☐ Doc. Level 2 ☐ Doc. Level 3 ☑ Doc. Level 4

Please use "✓" upon ticking the box.