
PS3 mainboard COK-002 - power supply

There are many measuring points on the mainboard, which are either small round or square pads with solder. All measuring points of the power supply are round. Measuring points with the designation "JL" are *original* measuring points, "JX" are some of mine. Red circles and a yellow box means that there is a measuring point as above, squares with an orange box means that the measuring point with the name is not there, but it is connected to it.



U typ MP description description JL6063 + 1.2V MC2 VDDIO 1,20V Cell BE JL6103 BE POW FAIL JL6114 + 1.0V BE VDDC 1,20V Cell BE, primary care JL9654 + 1.6V BE VDDA 1.70V Cell BE JX9601 1.50V Cell BE 1.5V BE YC VDDA JL6201 RSX POW FAIL JL6208 + 1.2V RSX VDDC 1,30V RSX, main supply JL6048 1,80V RSX, clock 1.8V RSX PLL VDD JL6056 1.50V RSX 1.5V AVCG VDDIO JL9651 + 1.2V_RSX_VDDR 1,20V RSX 1.50V RSX JL9656 + 1.5V RSX VDDIO Southbridge, voltage for data and address lines to connected chips such as 3,30V SATA Bruderge, USB Hub, StarShip2 (NAND controller), ... JL6060 2,50V Southbridge, Clock 2.5V SB PLL VDDC JL6061 + 1.8V SB PERI 1.8V Southbridge +1.2V SB VDDC JL9648 1,20V Southbridge, home care +1.2V SB VDDR JX9602 1.50V Southbridge 1.5V SB RC VDDA

PlayStation

- PlayStation 2
- PlayStation 3
 - o <u>versions</u>
 - o motherboard
 - standby
 - power supply
 - fuses
 - COK-002
 - SEM 001
 - DIA-001
 - DYN-001
 - SUR-001
 - Torn bush
 - o power adapter
 - o <u>drive</u>
 - o Disassemble the console
 - o hard disk
 - o cooling
 - o <u>hardware</u>
 - <u>firmware</u>
 - error
 - Homebrew
 - Service Features
 - Games list
 - Internet wisdom
 - controller
- PlayStation 4
- <u>PlayStation Portable</u>
- Sony service

JL9647	+ 1.8V_VDD_MEM	1,80V	RAM, internal
JL9652	+ 1.2V_YC_RC_VDDIO	1,20V	
	+		Voltage for data and address lines for the communication of Cell BE, RSX, RAM and Southbridge

by Takeshi