# Black Relay site kit · field card



## ✓ ANY CABLE, ANY PORT

Modems (ISP router, Starlink router, the Spitz's **LAN** port), a laptop or a switch: plug each into **any free port** on the CWWK.

Within about a minute the CWWK works out what each one is: modems join the secure link, the Spitz brings the Wi-Fi, laptops and switches join the site network.

## ✗ ONE CABLE PER DEVICE

Never plug the **same box into two ports**.

Moved a cable? Fine. Wait one minute and it carries on by itself.

### POWER UP

1. **Modems first:** ISP router; Starlink (open sky, up to 5 min); Spitz (needs a SIM for its own cellular).
2. **Then the CWWK.** Ready about 2 min after power-on; starts everything itself.
3. **Wait for green** on the controller's Health page.
4. **Get on the network:** Wi-Fi `GL-X3000-0fd` (or `-5G`), or plug a laptop into a free port.
5. **Controller → Setup → Run self-test.** Fix the first red line first.

### WHERE TO LOOK

| | |
|---|---|
| Anyone: is it working? | `https://status.lan` |
| Controller (on site) | `https://controller.lan` or `https://10.40.0.10` |
| Controller (anywhere) | `https://headscale.l8s.dev/cwwk/` sign in with Pocket ID |
| Modem admin pages | Controller → Setup → **Quick links** |
| Router admin | `https://router.lan` · `10.40.0.1` |

On site the browser warns about the certificate: expected. On a device running Tailscale, type the numbers, not the names.

### PASSWORDS (WRITE BY HAND)

Controller (on site): _____

Router (user root): _____

Wi-Fi: _____

### WHAT THE COLOURS MEAN

- 🟢 **Green:** working.
- 🟡 **Amber:** working, but look at it (e.g. one modem down: slower).
- 🔴 **Red:** down. Follow the "Fix it" box on Health.
- ⚫ **Grey port:** nothing plugged in there (fine).

### GOLDEN RULES

- **Wait 60 s** after any fix; it heals itself.
- **Nothing leaks:** if the secure link is down, nothing is sent at all.
- **Last resort:** reboot the CWWK (power button). Back in about 2 min.
- **Shade and airflow:** the CWWK has no fan.
- **Safe to press:** self-test, blink port, restart tunnel, start a container.

### WHICH JACK IS WHICH?

Controller → Setup → **Blink port** flashes that jack's light for 15 s. The Setup page shows what is detected on every port.

### TOP FIXES

| You see | Do this |
|---|---|
| **No internet at all** | Is at least one modem plugged in with its power on? Setup shows each modem found. Modems found but no lanes: the modems have no internet, or the hub is down: call the hub admin. |
| **One modem red / slow** | The others carry the traffic. Power-cycle that modem (unplug 10 s). Starlink: clear sky, wait 5 min, check it via its quick link or the Starlink app. |
| **No Wi-Fi** | The Spitz must be on, with its **LAN** port cabled to the CWWK (any port). Give it 2 min after power-on. |
| **Laptop on a cable gets no address** | Wait one minute. Still nothing after 2 min: unplug it for 5 s and plug it back in. |
| **Can't open the controller** | Be on the site Wi-Fi or a laptop port, and try https://10.40.0.10. Off site: https://headscale.l8s.dev/cwwk/ (needs the tunnel up). Still nothing: reboot the CWWK. |
| **"Leak guard NOT armed" or "CWWK is hot"** | Leak guard: stop sensitive traffic, reboot the CWWK, call the kit owner if it stays red. Hot: shade it, clear its vents, nothing stacked on top. |

How it all connects: Black-Relay-Site-Architecture.pdf · More help: controller → Field guide.