Black Relay site kit · field card

CWWK site box · keep with the kit

✓ ANY CABLE, ANY PORT

Modems (ISP router, Starlink router, the Spitz's **LAN** port), a laptop or a switch: plug each into **any free port** on the CWWK.

Within about a minute the CWWK works out what each one is: modems join the secure link, the Spitz brings the Wi-Fi, laptops and switches join the site network.

✗ ONE CABLE PER DEVICE

Never plug the **same box into two ports**.

Moved a cable? Fine. Wait one minute and it carries on by itself.

POWER UP

1. **Modems first:** ISP router; Starlink (open sky, up to 5 min); Spitz (needs a SIM for its own cellular).
2. **Then the CWWK:** up in ~2 min, **locked** (Wi-Fi only, no internet).
3. **Unlock:** USB key `BRKEY` in, 10 s, **pull it out, keep it**. Or admin + vault passphrase in the controller.
4. **Wait for green** on the controller's Health page.
5. **Get on the network:** Wi-Fi `BR2026_2` (or `BR2026_5`), or plug a laptop into a free port.
6. **Controller → Setup → Run self-test.** Fix the first red line first.

WHERE TO LOOK

Anyone: is it working?	`https://status.lan`
Controller (on site)	`https://controller.lan` or `https://10.40.0.10`
Controller (anywhere)	`https://headscale.l8s.dev/cwwk/` sign in with Pocket ID
Modem admin pages	Controller → Setup → **Quick links**
Router admin	`https://router.lan · 10.40.0.1`

On site the browser warns about the certificate: expected. On a device running Tailscale, type the numbers, not the names.

PASSWORDS (WRITE BY HAND)

Controller (on site): _____

Router (user root): _____

Wi-Fi: _____

WHAT THE COLOURS MEAN

- 🟢 **Green:** working.
- 🟡 **Amber:** working, but look at it (e.g. one modem down: slower).
- 🔴 **Red:** down. Follow the "Fix it" box on Health.
- ⚫ **Grey port:** nothing plugged in there (fine).

GOLDEN RULES

- **Wait 60 s** after any fix; it heals itself.
- **Nothing leaks:** if the secure link is down, nothing is sent at all.
- **Last resort:** reboot the CWWK (power button). Back in about 2 min.
- **Shade and airflow:** the CWWK has no fan.
- **Safe to press:** self-test, blink port, restart tunnel, start a container.

WHICH JACK IS WHICH?

Controller → Setup → **Blink port** flashes that jack's light for 15 s. The Setup page shows what is detected on every port.

TOP FIXES

You see	Do this
No internet at all	"Site locked"? Unlock (Power up, 3). Else: is at least one modem plugged in with its power on? Setup shows each modem found. Modems found but no lanes: the modems have no internet, or the hub is down: call the hub admin.
One modem red / slow	The others carry the traffic. Power-cycle that modem (unplug 10 s). Starlink: clear sky, wait 5 min, check it via its quick link or the Starlink app.
No Wi-Fi	The Spitz must be on, with its **LAN** port cabled to the CWWK (any port). Give it 2 min after power-on.
Laptop on a cable gets no address	Wait one minute. Still nothing after 2 min: unplug it for 5 s and plug it back in.
Can't open the controller	Be on the site Wi-Fi or a laptop port, and try https://10.40.0.10. Off site: https://headscale.l8s.dev/cwwk/ (needs the tunnel up). Still nothing: reboot the CWWK.
"Leak guard NOT armed" or "CWWK is hot"	Leak guard: stop sensitive traffic, reboot the CWWK, call the kit owner if it stays red. Hot: shade it, clear its vents, nothing stacked on top.

How it all connects: Black-Relay-Site-Architecture.pdf · More help: controller → Field guide.