									6 Meeting			
	Or in	Ŧ	D	-	YES	/ Volume						
	000	7.)	,	3/1/2	10-	10 will					
Notes		Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	nce	 Maintenance Tooling 			
		First Part Inspection Record	First Part I					Down Time Codes	Down Tir	ctions	Special Notes / Instructions	Specia
												ROUTING:
4												
		ľ	1									
3	2/1/2											
	CV.											
	0 0											
								1				
,						,						_
Ø						6	Ÿ	7	3	HP	7	6/2
Scrap Scrap Code		Notes			Down Time Code	Down Time	Cum. Total		Total Pcs.	Prod Hrs.	Emp. Name	Date
	bar/ om s					Office of second	School Sept.		STATE		Topological Park	
	Thru-		Pcs./Hr			Cycle		Setup Hrs.	4		Mach. No.	
								ility.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
						=	Located on the bag followed by "Lot Number."	lowed by "I	the bag fol	Located on	Snap Rings	Snap
						box label.	Use their work order number and date on the box label.	umber and	ork order n	Use their w	Flare Tubes	Flare
						etter "M."	Located on the spool label, starting with the letter "M."	abel, startir	the spool la	Located on	Copper Tubing	Coppe
		CP13				ord "heat."	Located on the box label, directly above the word "heat."	el, directly	the box lab	Located on	Brazing Rings	Brazir
		BRZ03				x quantity.	Six digit no. located on the box label under box quantity.	the box la	. located on	Six digit no.	Flare Nuts	Flan
		CUTU-1-1/2	C				nbers	eablity Nur	Distinguishing Traceablity Numbers	Distingu		
77	39227	SF405-5-1/4	SI						32		Order Qty	Ord
<u>.</u>	No(s)	Component(s)	6		LLC	devices, LLC	C C		393272	35	Order No.	Ord
aceability	Heat Lot/Traceability)			201			2/1-4-1/4-1/2	3405-	Part No.	Pal