-			I								
1								3 Setup			
	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted					
8	rt Inspection Record	First Part					Codes	Down Time Codes	tions	Special Notes / Instructions	Speci
П											ROUTING:
-											
											92 93
1 1											
			T								
Ш											
								ىو		88	1/8
es:	Notes			Down Time Code	Down Time	Cum. Total	Cur	Total Pcs.	Prod Hrs.	Emp. Name	Date
		Pcs./Hr			Cycle Time		Setup Hrs.		a	Mach. No.	
							×	Do Not require traceability.	on not redu	caps/riugs L	cab
			- k			ot Number.	/ed by "L	Located on the bag followed by "Lot Number."	ocated on		Sna
1					box label.	date on the	ber and	Use their work order number and date on the box label.	Jse their w	Flare Tubes	Flar
1			-		etter "M."	g with the l	l, startin	Located on the spool label, starting with the letter "M."	ocated on	Copper Tubing	Copp
			_		vord "heat."	above the w	directly	Located on the box label, directly above the word "heat."	ocated on	Brazing Rings L	Brazi
	AR30		.		ox quantity.	pel under bo	e box lak	Six digit no. located on the box label under box quantity.	six digit no.	Flare Nuts	Flai
	A-RING					nbers	olity Nun	Distinguishing Traceablity Numbers	Distingu		
- 1	1302-12-3/8-7/8	130	Ŀ					2		Order Qty	Orc
	Component(s)	6		LLC	devices, LLC	H		396356	39	Order No.	Orc
								1302-123/8//830	1302-12	Part No.	Pa