			4		1					10000			
		(4) na (403	CQ.	7		,				4 FAIR 5 Training	36		
		STATE OF THE PERSON NAMED IN	+X	>	1	CIES	1	11-11-15					
		Notes	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	ince	 Maintenance Tooling 			
			First Part Inspection Record	First Part In					me Codes	Down Time	ctions	Special Notes / Instructions	Specia
													ROUTING:
		-		ı									
			0										
	1	1.1											
	(1)	5											
		B											
													1. 1
								37		2	15	S	3/11/10
Scrap	Scrap		Notes			Down Time Code	Down Time	Cum. Total		Total Pcs.	Prod Hrs.	Emp. Name	Date
		put/onis					111110		1000				
		Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
									oility.	Do not require traceability.	Do not req	Caps/Plugs	Caps
								Located on the bag followed by "Lot Number."	lowed by "	the bag fol	Located on	Snap Rings	Snap
	G						box label.	Use their work order number and date on the box label.	number and	ork order n	Use their w	Flare Tubes	Flare
			BRZ00				etter "M."	Located on the spool label, starting with the letter "M."	abel, starti	the spool la	Located on	Copper Tubing	Coppe
			UTU-0-1-1/8	CUT			ord "heat."	Located on the box label, directly above the word "heat."	pel, directly	the box lab	Located on	Brazing Rings	Brazin
			BRZ22				x quantity.	Six digit no. located on the box label under box quantity.	the box la	. located on	Six digit no	Flare Nuts	Flare
	=		CUTU-0-5/32	CU.				mbers	eablity Nu	Distinguishing Traceablity Numbers	Disting		
	_[9-2.5-34							2		Order Qty	Orde
		No(s)	Component(s)	Con		LLC	devices, LLC	H		389845	32	Order No.	Orde
	litγ	Heat Lot/Traceability		•			1			J-21-74-46-D			101