BRAZING PR			Specia	ROUTING:					1721	Date			Cap	Flan	Coppe	Brazi	Flar		Ord	Orc	Pa	
BRAZING PRODUCTION RECORD			Special Notes / Instructions		2*				SS	Emp. Name	Mach. No.		Snap Rings Caps/Plugs	Flare Tubes	Copper Tubing	Brazing Rings	Flare Nuts		Order Qty	Order No.	Part No.	
ממס			ıctions							Prod Hrs.			Do not requ	Use their w	Located on	Located on	Six digit no.	Disting		35	-70TT	
		 Maintenance Tooling 	Down Time Codes						به	Total Pcs.			Located on the bag followed by "Lot Number." Do not require traceability.	Use their work order number and date on the box label.	Located on the spool label, starting with the letter "M."	Located on the box label, directly above the word "heat."	Six digit no. located on the box label under box quantity.	Distinguishing Traceablity Numbers	2	392848	1102-21-3/0-K	
										Cum.	Setup Hrs.		ved by "Lo	iber and d	el, starting	directly al	e box labe	blity Numb				
	Capillitica	Date Part Submitted								Cum. Total			t Number	ate on the	with the I	bove the v	l under bo	pers	devices, LLC			
		Time Of Day								Down Time	Cycle Time		i a	box label.	etter "M."	vord "heat."	ox quantity.				control	
	res/ NO	Approved								Down Time Code												
	Cleck	_	F											AND PARTY OF THE P								
		First Part In	2		Ç4					Pcs./Hr								110	Com)		
		Inspector	First Part Inspection Record							Notes								C-RING	1102-21-3/16	Component(s)	1-14-1	
											Thru- put/8hrs							7.			Heat Lo	
		Notes																N/A	N/A	No(s)	Heat Lot/Traceability	
										Scrap							J.				₹	
										Scrap Code												