							Service of the servic	
				T	Training Meeting	<b>б</b> И		
tor	Check Rev Letter Inspector	Approved N Yes / No Ch	Time Of Day	Date Part Submitted	Maintenance Tooling Setup FAIR	4 3 2 1		
Record	First Part Inspection Record	Н	× 1		Down Time Codes	tions	Special Notes / Instructions	Specia
								ROUTING:
		+						
١,	5 of 25 pus				2) 6	2/2	770	1/25
Notes		Down Time Code	Down Time	Cum. Total	Total Pcs.	Prod Hrs.	Emp. Name	Date
	Pcs./Hr		Cycle Time	Setup Hrs.	Se H		Mach. No.	
	CP15				Do not require traceability.	Do not requi	Caps/Plugs	Caps
	BRZ00		·=	y "Lot Number.	Located on the bag followed by "Lot Number."	ocated on t		Snap
5	CSW-7/8-2.5		e box label.	and date on the	Use their work order number and date on the box label.	Jse their wo	Flare Tubes	Flare
	BRZ04		etter "M."	irting with the I	ocated on the spool label, starting with the letter "M."	ocated on t	Copper Tubing	Coppe
6	CUTU-17-3/16		word "heat."	ctly above the v	Located on the box label, directly above the word "heat."	ocated on t	Brazing Rings	Brazir
	65		ox quantity.	x label under bo	Six digit no. located on the box label under box quantity.	six digit no. I	Flare Nuts	Flar
	G-RING			Numbers	Distinguishing Traceablity Numbers	Distingui		
	702-12-3/16				25		Order Qty	Ord
	Component(s)	LLC	devices, LLC	H	391572	391	Order No.	Ord
ji	20				3/17-C01 /C7170/C	2/0212	Part No.	Par