BRAZING PRO		Special	ROUTING:				7	11/20	Date /		Caps,	Snap	Flare	Copper	Brazin	Flare		Orde	Orde	Part
BRAZING PRODUCTION RECORD		Special Notes / Instructions		×				1	Emp. Name	Mach. No.	Caps/Plugs	Snap Rings	Flare Tubes	Copper Tubing	Brazing Rings	Flare Nuts		Order Qty	Order No.	Part No.
ORD	1 2 3 4 4	ctions					-	2	Prod Hrs.		Do not requ	Located on	Use their w	Located on	Located on	Six digit no.	Distingu		39	S7-2.5
	Maintenance Tooling Setup FAIR Training Meeting	Down Time Codes						5 80 80	Total Pcs.		Do not require traceability.	Located on the bag followed by "Lot Number."	Use their work order number and date on the box label.	Located on the spool label, starting with the letter "M."	Located on the box label, directly above the word "heat."	Six digit no. located on the box label under box quantity.	Distinguishing Traceablity Numbers	8	391236	S7-2.5-22-36-B
		Codes						0	Cum. Total	Setup Hrs.	×	ved by "Lot	nber and da	el, starting v	directly ab	e box label	blity Numbe			
	Date Part Submitted							Ju				Number."	ite on the l	with the let	ove the wo	under box	ers		O.C.	
	Time Of Day							40	Down Time	Cycle Time			ox label.	ter "M."	ord "heat."	quantity.			devices, LLC	25750
	Approved Yes / No						l	N	Down Time Code										,LC	
1	Mtrl Rev	Firs						0		Pc	_									
		First Part Inspec					- 1 1			Pcs./Hr			CP15	BRZ00	BRZ22	CSW-3-7/8	CUTU-36-5/32	SF7-2.5-22	Component(s)	
	Inspector	Inspection Record							Notes				15	.00	22	3-7/8	6-5/32	.5-22	nent(s)	
								1		Thru- put/8hrs								77	Heat	Heat
	Notes							4.		6	16.							4414	No(s)	Heat Lot/Traceability
Test	35						7	٥	Scrap									ח	29	bility
Test Form 11/4/15							Ç	N.	Scrap											