									6 Meeting			
	#0	(3)	of .		3							
		JH 14	/	9	465	Don	12-14-5		3 Setup 4 FAIR			
	Notes	Inspector		Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted		<ol> <li>Maintenance</li> <li>Tooling</li> </ol>			
		First Part Inspection Record	First Part				THE STATE OF	Codes	Down Time	tions	Special Notes / Instructions	Specia
	3											ROUTING:
	7											
		(										
		T Si										
		3/10										
+		5										
		1										
+	5											
									-			,
2							N	. \	\ \ \ \	(42	4	11/10
scrap Code	Scrap	Notes			Down Time Code	Down Time	Cum. Total	Cı	Total Pcs.	Prod Hrs.	Emp. Name	Date
	put/8hrs					IIme		nis.	X 64 47 25 1		The state of the s	
	Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
								ָּלַץ.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
						-	Lot Number.	ved by "I	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
		CP13				box label.	date on the	nber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
		CUTU-3-1/2	0	<u> </u>		etter "M."	ng with the I	el, startir	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
		BRZ22		<b>I</b>		vord "heat.'	above the v	, directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazir
		BRZ01				ox quantity.	bel under bo	າe box la	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flan
		CUTU-24-5/32-B	CI				nbers	blity Nur	Distinguishing Traceablity Numbers	Distingu		
	765262	SF4-2.5-10	(0)						3		Order Qty	Ord
	No(s)	Component(s)	6		LLC	devices, LLC	THE STATE OF THE S	!	393996	39	Order No.	Ord
	Heat Lot/Traceability		)			2			34-2.5-10-24-B	34-2.5	Part INO.	Pai