BRAZING PR	ar _i	Specia	ROUTING:									0/18	Date			Сар	Sna	Flare	Coppe	Brazi	Flar		Ord	Ord	Pa	
BRAZING PRODUCTION RECORD		Special Notes / Instructions										Ų,	Emp. Name		Mach. No.	Caps/Plugs	Snap Rings	Flare Tubes	Copper Tubing	Brazing Rings	Flare Nuts		Order Qty	Order No.	Part No.	
ORD													Prod Hrs.			Do not requ	Located on	Use their w	Located on	Located on	Six digit no	Disting		40		
	2 Tooling 3 Setup 4 FAIR 5 Training 6 Meeting											٩	Total Pcs.			Do not require traceability.	Located on the bag followed by "Lot Number."	Use their work order number and date on the box label.	Located on the spool label, starting with the letter "M."	Located on the box label, directly above the word "heat."	Six digit no. located on the box label under box quantity.	Distinguishing Traceablity Numbers	2	401158	G8-R	
		Codes											Cum	nis.	Setup	. I i	ved by "Lo	nber and c	el, starting	directly a	e box labe	blity Num				
	Submitted	Data Batt											Cum. Total				t Number	date on th	with the	bove the	el under b	bers		Ţ	1	
	Time Of Day												Down Time	lime	Cycle		7	le box label.	letter "M."	word "heat.'	ox quantity.			devices.	control devices, LLC	
	Yes / No	A						*					Down Time Code							7			LLC		i f	
	Check	11													Washington and					_						
_	Rev Letter	First Part In:													Pcs./Hr							0	2-	Com	?	
	Inspector	Inspection Record			+								Notes									G-RING	G8	component(s)		
					S	,	0	,						put/8hrs	Thru-							2	ح		Heat Lo	
	Notes													AND THE PROPERTY OF THE PARTY.	Andrew Grand or							<u> </u>	A	No(s)	Heat Lot/Traceability	
Test F				P									Scrap												ΪŢ	
Test Form 11/4/15													Scrap Code													