			ŀ				ı			THE PRODUCTION OF THE PRODUCTION OF THE PERSON OF THE PERS
						• • · · · · · · · · · · · · · · · · · ·				
	T						3 Setup 4 FAIR			
Inspector		red Mtrl lo Check	Approved Yes / No	Time Of Day	Date Part Submitted	lance	 Maintenance Tooling 			
ion Record	First Part Inspection Record					Down Time Codes	Down T	tions	Special Notes / Instructions	Specia
										ROUTING:
		+								
							1		SB	1/4
Notes		me	Down Time Code	Down Time	Cum. Total		Total Pcs.	Prod Hrs.	Emp. Name	Date
	Pcs./Hr			Cycle Time	· 5	Setup Hrs.			Mach. No.	
		L				bility.	Do not require traceability.	Do not requ	Caps/Plugs [Caps
				.=	Located on the bag followed by "Lot Number."	llowed by	the bag fo	ocated on		Snap
				e box label.	Use their work order number and date on the box label	number ar	ork order	Jse their w	Flare Tubes	Flare
				letter "M."	Located on the spool label, starting with the letter "M."	label, start	the spool	ocated on	Copper Tubing	Coppe
			·a	word "heat	Located on the box label, directly above the word "heat."	bel, direct	the box la	ocated on	Brazing Rings	Brazir
03	A-KF003			ox quantity	Six digit no. located on the box label under box quantity.	n the box l	. located o	six digit no	Flare Nuts	Flan
3/16-0	2803A-20-3/16-0				umbers	ceablity N	Distinguishing Traceablity Numbers	Disting		
-HT	DCN516-HT						1		Order Qty	Ord
ent(s)	Component(s)		LLC	devices, LLC	Ą		395655	35	Order No.	Ord
							2803A-20-3/16	2803/	Part No.	Par