	The state of the s											
									6 Meeting			
									3 Setup			
	Notes	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	Се	 Maintenance Tooling 			
		First Part Inspection Record	First Part Ir				The same of	e Codes	Down Time Codes	ctions	Special Notes / Instructions	Spec
												ROUTING:
	7											
	?											
												5
		V.										
) HO										
				Ť								
									\ \			2/110
Scrap Code	Scrap	Notes			Down Time Code	Down Time	Cum. Total	Cu	Total Pcs.	Prod Hrs.	Emp. Name	Date
	put/onis					IIIIe		- 1119.				
	Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
								lity.	Do not require traceability.	Do not requ	Caps/Plugs	Cap
							Lot Number.	wed by "I	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Sna
				_		box label.	date on the	mber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flar
				1		etter "M."	ng with the I	bel, startir	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Copp
						vord "heat."	above the v	directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Braz
_		A-KF005	1			ox quantity.	bel under bo	the box la	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Fla
\	7	DCN316-HT	DC				mbers	ablity Nur	Distinguishing Traceablity Numbers	Distingu		
\	15	2201-6-1/4-0	220						3		Order Qty	Or
	No(s)	component(s)	Coll		LLC	devices, LLC	T C		400351	40	Order No.	Or
	Heat Lot/Traceability		2			OP TOO			2201-6-1/4	220:	Part No.	Pa