										j	BBAZING BBODI ICTION BECOME	
				Check	Yes / No		Submitted		2 Fooling			
	Notes	r Inspector	Rev Letter	Mtrl	Approved	Time Of Day	Date Part	ce				
		rt Inspection Record	First Part					e Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
												ROUTING:
	*											
	(
		-										
	110											
			9									
								2				
	(3)											
									نو		SB	1-14
ap Scrap Code	Scrap	Notes			Down Time Code	Down Time	Cum. Total	5	Total Pcs.	Prod Hrs.	Emp. Name	Date
The state of the s					Total Sport					Calculation of the Control		
	Thru- put/8hrs	-	Pcs./Hr			Cycle Time		Setup Hrs.			Mach. No.	
							7.	lity.	Do not require traceability.	Do not requ	Caps/Plugs	Cap
				-		=	Lot Number.	wed by "I	Located on the bag followed by "Lot Number."	Located on		Sna
						box label.	date on the	ımber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
				I		etter "M."	າg with the l	bel, startir	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
						vord "heat."	above the w	ય, directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazi
						x quantity.	bel under bo	the box lal	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flar
	30060667	E-RING					nbers	ablity Nur	Distinguishing Traceablity Numbers	Distingu		
	ZA	E17				1	III		12		Order Qty	Ord
	No(s)	Lomponent(s)	5		LC	devices, LLC	TI CO		396918	39	Order No.	Ord
	Heat Lot/Traceability		,			7			E17-R	im	Part No.	Pa