											THE STATE OF THE S		1
										1		·	
		7	(#03)		Q/	103	9:002	3-14-16		3 Setup			
	25	Notes	Inspector co	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted					
			t Inspection Record	First Part I					Codes	Down Time Codes	ctions	Special Notes / Instructions	Specia
	4												ROUTING:
	7												
	3	1230											
		000											
								20		20	Ma 10man	U	3/14/10
Scrap Code	Scrap		Notes			Down Time Code	Down Time	Cum. Total	Cu	Total Pcs.	Prod Hrs.	Emp. Name	Date
		put/8hrs					Time		Hrs.				
		Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
									×	Do not require traceability.	Do not requ	Caps/Plugs	Caps
					I		=	ot Number.	ed by "L	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
				ш			box label.	date on the	ber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
							etter "M."	g with the l	l, startin	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
			CP15				ord "heat."	above the w	directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazir
		10//	BRZ09				x quantity.	oel under bo	e box lak	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flan
	1		CUTU-1-7/8	CL				nbers	olity Nun	Distinguishing Traceablity Numbers	Distingu		
		=	SF704-20-3/16	SF7						20		Order Qty	Ord
	325	No(s)	Component(s)	Cor		LLC	devices, LLC	T.		403438	40	Order No.	Ord
	bility	Heat Lot/Traceability		,			7			S704-20-3/16	S704-	Part No.	Par