						Training Meeting	6 5		
	N P	1	465	102	ンゴス	Setup FAIR	ε 4		
٦	Rev Letter Inspector	Mtrl R	Approved Yes / No	Time Of Day	Date Part Submitted	Maintenance Tooling	2 1		
ecord	First Part Inspection Record	E				Down Time Codes	tions	Special Notes / Instructions	Specia
П									ROUTING:
			1						
			ti .						
								ē	
									, , ,
				0	706	70%	らい	JU	12/19
Notes			Down Time Code	Down Time	Cum. Total	Total Pcs.	Prod Hrs.	Emp. Name	Date
	Pcs./Hr			Cycle Time	s.	Setup Hrs.		Mach. No.	
						traceability.	Do not require traceability.	Caps/Plugs	Caps
	CP13	T		=	/"Lot Number.	Located on the bag followed by "Lot Number."	ocated on the		Snap
	L-RING			box label.	nd date on the	Use their work order number and date on the box label.	Jse their work	Flare Tubes	Flare
16	CUTU-17-3/16			etter "M."	rting with the le	Located on the spool label, starting with the letter "M."	ocated on the	Copper Tubing	Coppe
	BRZ04			ord "heat."	tly above the w	Located on the box label, directly above the word "heat."	ocated on th	Brazing Rings	Brazir
١/2	CUTU-1.875-1/2			x quantity.	label under bo	Six digit no. located on the box label under box quantity.	six digit no. lo	Flare Nuts	Flare
	L3/4				lumbers	Distinguishing Traceablity Numbers	Distinguish		
	SF403-2-3/16	-					700	Order Qty	Orde
	Component(s)		LC	devices, LLC	THE STATE OF THE S	20	394320	Order No.	Orde
•	The state of the s					3/41/1	S40323/163/417F	Part No.	Par