		Specia	ROUTING:							11/4	Date			0) i	FIA	Copt	Bra:	FI		O.	٥	Ţ.
		Special Notes / Instructions								Š	Emp. Name		Mach. No.	27/1/483	Cans/Plugs	Flare Tubes	Copper Tubing	Brazing Rings	Flare Nuts		Order Qty	Order No.	
5	3 2 1	ctions									Prod Hrs.			bo not led	Located on	Use their w	Located on	Located on	Six digit no	Disting		4	
FAIR Training Meeting		Down Time Codes								ā	Total Pcs.			po not require traceability.	Located on the bag followed by "Lot Number."	Use their work order number and date on the box label.	Located on the spool label, starting with the letter "M."	Located on the box label, directly above the word "heat."	Six digit no. located on the box label under box quantity.	Distinguishing Traceablity Numbers	12	400244	The state of the s
		Codes									Cun		Setup Hrs.	Į.	ved by "L	nber and	el, startin	, directly	າe box lak	blity Nun			
	Date Part Submitted										Cum. Total				ot Numbe	date on th	g with the	above the	el under l	nbers		Ŧ	
	Time Of Day										Down Time		Cycle		7.	ne box label.	letter "M."	word "heat	ox quantity			devices	111111
	Approved Yes / No										Down Time Code	Breath chicago						T .			1		
	Mtrl Check											A Transport		<u> </u>					L	_			
Rev Letter		First Part In			8	<u> </u>						Pcs./Hr	Pcs./Hr									<u>د</u>	
	Inspector	First Part Inspection Record			Sj	, \frac{1}{2}	1			35.	Notes								S TAIR O	I-RING	JR1-1/2	Component(s)	
												put/8nrs	Thru-						991 0H10r	2,0012	No.	No(s)	
	Notes		4	>							Scrap								166	7/	100	raceability	· · · · · · · · · · · · · · · · · · ·
											Scrap												