										0.4		
									3 Setup 4 FAIR	N (1)		
	Notes	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	(0	 Maintenance Tooling 			
		First Part Inspection Record	First Part Ir					Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
												ROUTING:
	1											
+	4	1										
	3	2						1				
	MY											
									+		SB	8/8
Scrap Code	Scrap	Notes			Down Time Code	Down Time	Cum. Total	Cu	Total Pcs.	Prod Hrs.	Emp. Name	Date
	put/8hrs		Pcs./Hr			Time		Hrs.			Mach. No.	
	Thru-					Cycle		Setup				
								ty.	Do not require traceability.	Do not requ	Caps/Plugs	Cap
							Lot Number.	wed by "	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
						box label.	date on the	nber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
						etter "M."	ng with the le	el, startii	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
					87	ord "heat."	above the w	, directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazii
	NIA	A-KF004				x quantity.	bel under bo	ne box la	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flar
	W/A	DCN316-HT	D				mbers	blity Nu	Distinguishing Traceablity Numbers	Distingu		
	398746	2203A-4-1/4-0	220						4		Order Qty	Ord
	No(s)	Component(s)	Cor		LLC	devices, LLC			399716	39	Order No.	Ord
	Heat Lot/Traceability)			2			2203A-4-1/4	2203	Part No.	Pai