			ALC: N						Meeting	6		
	0.00	7	A	1	YES	1	MEN			υ 4. τ.		
Notes	S#)	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	ice		2 1		
		First Part Inspection Record	First Part I					ne Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
												ROUTING:
1												
5.	7											
6	(1/1)											
	1											
٨												
								+				
			e e									
									٦	10 Min	C	4-40-
Scrap		Notes			Code	Down Time	Cum. Total	CL	Total Pcs.	Prod Hrs.	Emp. Name	Date
			STATE OF THE PERSON NAMED IN		Down Time		To real returning products		THE RESERVE AND ADDRESS.			
vi	Thru- put/8hrs		Pcs./Hr			Cycle Time	- 3	Setup Hrs.			Mach. No.	
								ility.	ire traceab	Do not require traceability.	Caps/Plugs	Caps
						•=	Located on the bag followed by "Lot Number."	owed by '	the bag foll	ocated on		Snap
		CP14				e box label.	Use their work order number and date on the box label.	umber an	ork order ni	Use their wo	Flare Tubes	Flare
		BRZ07				letter "M."	Located on the spool label, starting with the letter "M."	bel, starti	the spool la	ocated on	Copper Tubing	Coppe
05758 W	7	CSW-3-5/8	0			word "heat."	Located on the box label, directly above the word "heat."	el, directly	the box lab	ocated on	Brazing Rings	Brazir
33/73	,	BRZ22				ox quantity.	Six digit no. located on the box label under box quantity.	the box la	located on	Six digit no.	Flare Nuts	Flar
(4C98M	Л	CUTU-36-5/32-B	CUT				mbers	eablity Nu	Distinguishing Traceablity Numbers	Distingu		
391447	W	SF5-2.5-16	,,						2	ı	Order Qty	Ord
No(s)		Component(s)	60		רכ	devices, LLC	T T		391447	39	Order No.	Ord
Heat Lot/Traceability	Heat					7			20 10 10 00 0	00 210		Part No.