Test Form 11/4/15	Test Fo										ORD	BRAZING PRODUCTION RECORD	RAZING PRO
										6 Meeting			
		Notes	Inspector	Rev Letter	Mtrl	Approved Yes / No	Time Of Day	Date Part Submitted	ınce	<ol> <li>Maintenance</li> <li>Tooling</li> </ol>	188		
			First Part Inspection Record	First Part Ir					Down Time Codes	Down Tir	ctions	Special Notes / Instructions	Specia
													ROUTING:
	9												
	5												
		TU											
		3775											
		57											
		5											
		<u> </u>											
										_		38	12/15
Scrap Code	Scrap		Notes			Down Time Code	Down Time	Cum. Total		Total Pcs.	Prod Hrs.	Emp. Name	Date
		put/sms									ACCOUNT OF SECURITY		
		Thru-		Pcs./Hr			Cycle	70	Setup			Mach. No.	
									oility.	Do not require traceability.	Do not req	Caps/Plugs	Caps
								Located on the bag followed by "Lot Number."	lowed by '	the bag fol	Located on	Snap Rings	Snap
							box label.	Use their work order number and date on the box label.	number an	ork order n	Use their w	Flare Tubes	Flare
							etter "M."	Located on the spool label, starting with the letter "M."	abel, starti	the spool l	Located on	Copper Tubing	Coppe
							vord "heat."	Located on the box label, directly above the word "heat."	pel, directly	the box lak	Located on	Brazing Rings	Brazir
		20060667	E-RING				x quantity.	Six digit no. located on the box label under box quantity.	the box la	. located on	Six digit no	Flare Nuts	Flare
		394195	E50					ımbers	eablity Nu	Distinguishing Traceablity Numbers	Disting		
	_[	N/A	902-14-1/4	90						1		Order Qty	Orde
		No(s)	Component(s)	Con		LTC	devices, Ltc	4		394236	3:	Order No.	Ord
	lity	Heat Lot/Traceability		,			7			902-14-1/4-50	902-1	Part No.	Par
									100				