								The state of the s	STATE	
							100000	6		
	(d)	<i>M</i>	#	422	1.73/12	61.67.11		4 n		
	80# Notes	Inspector	Re		_ <	Submitted		3 2		
		t Inspection Record	First Par	Approved Mtri		Date Part	Down Time Codes		Special Notes / Instructions	Specia
										ROUTING:
7										
?	(									
	100									
	10.									
	. 10 14									
				Đ						
					1	4	1			,
					Ø	7	h	(wa	176	1/13/14
Scrap Scrap		Notes		Down Time Code	Down Time Do	Cum. Total	Total Pcs.	Prod Hrs.	Emp. Name	Date
	put/onis				lime	9.			monthly parameter	
	Thru-	-	Pcs./Hr		Cycle	, p	Setup		Mach. No.	
							Do not require traceability.	Do not requi	Caps/Plugs	Caps
					=	y "Lot Number.	Located on the bag followed by "Lot Number."	Located on t		Snap
		CP14			box label.	ind date on the	Use their work order number and date on the box label	Use their wo	Flare Tubes	Flare
		BRZ22			etter "M."	rting with the le	Located on the spool label, starting with the letter "M."	Located on t	Copper Tubing	Coppe
		BRZ07			vord "heat."	tly above the w	Located on the box label, directly above the word "heat."	Located on t	Brazing Rings	Brazir
		CUTU-36-5/32-B	CUT		ox quantity.	label under bo	Six digit no. located on the box label under box quantity.	Six digit no. I	Flare Nuts	Flare
		CSW-3-5/8	0			dumbers	Distinguishing Traceablity Numbers	Distingui		
	395788	SF5-2.5-15	S				4		Order Qty	Orde
•	No(s)	Component(s)	6	.,	devices, LLC	C C	395788	395	Order No.	Ord
ţ	Heat Lot/Traceability		,		1		S5-2.5-15-36-B	S5-2.5-	Part No.	Par