Test Form 11/4/15											ORD	BRAZING PRODUCTION RECORD	BRAZING PR
								MANUAL PROPERTY.		6 Meeting			
			Chi.	<u></u>		YE	1:00	216					
	Notes	K	Inspector) refrei	Check		, or Day	Submitted	1	2 Tooling 3 Setup			
			la constant	Dou lottor	Mtrl	Approved	Time Of Day	Date Part	ř	1 Maintenance	L.		
		A	t Inspection Record	First Part Ins				AND	e Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
					and the latest	HOLD STREET							ROUTING:
	4												
	3												
	1	5	7										
		28											
	10												
			B										
							15	8			t Charles	2	1616
							Ř)			311	4	3/2/11
Scrap Code	Scrap		Notes		Ф	Down Time Code	Down Time	Cum. Total	C.	Total Pcs.	Prod Hrs.	Emp. Name	Date
	10	but/oills					111110		1113				
	ń	Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
									ťv.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
							. 11	Lot Number	wed by "	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
							e box label.	date on the	mber and	Use their work order number and date on the box label.	Use their wo	Flare Tubes	Flare
							letter "M."	ng with the	el, startii	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
			CP13			-	word "heat.'	above the v	l, directly	Located on the box label, directly above the word "heat."	Located on :	Brazing Rings	Brazir
			CUTU-1-1/2	CUT			ox quantity.	bel under b	he box la	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flar
			BRZ23	-				mbers	ablity Nu	Distinguishing Traceablity Numbers	Distingu		
			SF405-3-1/4-1/2	SF405						20		Order Qty	Ord
	No(s)		Component(s)	Com		LLC	devices, LLC	1		402867	40.	Order No.	Ord
	Heat Lot/Traceability	Heat					200			S405-3-1/4-1/2	S405-3	Part No.	Pai