		l	-								
-1								3 Setup 4 FAIR			
	ter Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted					
ď	rt Inspection Record	First Part					Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
											ROUTING:
									I		
								4		SB	1/29
1553	Notes		3175	Down Time Code	Down Time	Cum. Total	Cur	Total Pcs.	Prod Hrs.	Emp. Name	Date
8 1	+	Pcs./Hr			Cycle Time		Setup Hrs.	a a		Mach. No.	
							y .	Do not require traceability.	Do not requ	Caps/Plugs	Caps
					2.5	ot Number.	ed by "L	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
			l		box label.	date on the	ber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
			I		etter "M."	g with the l	l, startin	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
					vord "heat."	above the w	directly a	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazin
			L		ox quantity.	el under bo	e box lab	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flare
	A-RING					nbers	olity Num	Distinguishing Traceablity Numbers	Distingu		
	A15		G.					4		Order Qty	Orde
	component(s)	_		LLC	devices, LLC	C C		398698	39	Order No.	Orde
	,				1			A15-R	A	Part No.	Par