BRAZING PRODUCTION RECORD			special Notes / Instructions	Special Motor / In	ROUTING:										12/30 58	Date Emp. Name		Mach. No.	Caps/Plugs	Snap Rings	Flare Tubes	Copper Tubing	<b>Brazing Rings</b>	Flare Nuts		Order Qty	Order No.	
RECORD			structions	truction.												me Prod Hrs.	The state of the s	ю. 	Do not rec	Located o	Use their	Located o	Located o	Six digit no	Disting		ω	
	6 Meeting		1 Maintenance	Down Time											t	Total Pcs.	The second second		Do not require traceability.	Located on the bag followed by "Lot Number."	Use their work order number and date on the box label.	Located on the spool label, starting with the letter "M."	Located on the box label, directly above the word "heat."	Six digit no. located on the box label under box quantity.	Distinguishing Traceablity Numbers	4	395451	
			Codes	Cadas												Cum	200 000	Setup Hrs.	ťγ.	ved by "Lo	nber and c	el, starting	, directly a	ne box labe	blity Numl			
		Submitted	Date Part													Cum. Total	Annual Control			t Number	date on the	with the	bove the v	el under bo	bers		7	County Investor
		Time Of Day														Down Time		Cycle		=	e box label.	etter "M."	vord "heat."	ox quantity.			devices, LLC	THE PERSON NAMED IN
		Yes / No	Approved			2										Down Time Code	Color specimen										LLC	
		2.5	Mtrl																									
		Rev Letter	irst Part In															Pcs./Hr									2	
		Inspector	First Part Inspection Record													Notes									E-RING	E8	components)	
							-	7.1	; ; ;	シ								Thru- put/8hrs							306	2		-
		Notes						), (	3	7	Ś	\					A STATE OF THE SAME								30060667	NIA	No(s)	5 S
					Č	Z	>									Scrap												
												Ī				Scrap Code												