							Meeting	6 (
							FAIR	4 л		
	Notes	er Inspector	Mtrl Rev Letter	Approved N Yes / No Ch	Time Of Day	Date Part Submitted	Maintenance Tooling Setup	3 2 1		
		First Part Inspection Record				H	Down Time Codes		Special Notes / Instructions	Specia
		lia-								ROUTING:
1										
)	5212									
	1									
	No de la constantina della con	X PAN A								
Scrap Scrap	Sc	Notes		Down Time Code	Down Time	Cum. Total	Total Pcs.	Prod Hrs.	Emp. Name	Date
	put/8hrs		PG-/ FI		Time	s.	Hrs.		and cit.	
	Thru-				Cycle	dp	Setup		Mach No	
							Do not require traceability.	Do not requi	Caps/Plugs	Cap
					• =	"Lot Number	Located on the bag followed by "Lot Number."	Located on th	Snap Rings	Snap
					e box label.	nd date on the	Use their work order number and date on the box label.	Use their wo	Flare Tubes	Flare
					letter "M."	ting with the l	Located on the spool label, starting with the letter "M."	Located on th	Copper Tubing	Coppe
					word "heat."	tly above the v	Located on the box label, directly above the word "heat."	Located on th	Brazing Rings	Brazi
					ox quantity.	label under bo	Six digit no. located on the box label under box quantity.	Six digit no. l	Flare Nuts	Flar
						lumbers	Distinguishing Traceablity Numbers	Distinguis		
L		CUTU-42-5/32					1020	10	Order Qty	Ord
	No(s)	Component(s)		LC	devices, LLC	A	401208	401	Order No.	Ord
	Heat Lot/Traceability	TO THE PROPERTY OF THE PROPERT			1		CUTU-42-5/32-B	CUTU-4;	Part No.	Pa