			V						6 Meeting			
		7	2	4	100	MEO	10.01					
	90	+		- Circum	T. S.	2004	100					
	Notes	Inspector	Rev Letter	Mtrl	Approved	Time Of Day	Date Part Submitted	ce	 Maintenance Tooling 			
		t Inspection Record	First Part Ir		The state of	7000		e Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
1												ROUTING:
7												
?												
		7										
),											
	\	1										
						61						
	5.											
										*		
Scrap		Notes			Down Time Code	Down Time	Cum. Total	Cu	Total Pcs.	Prod Hrs.	Emp. Name	Date
	put/snrs					lime		1113.				
	Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
								lity.	Do not require traceability.	Do not requ	Caps/Plugs	Cap
				•		=	Located on the bag followed by "Lot Number."	wed by "I	the bag follo	Located on	Snap Rings	Sna
		CP15				box label.	Use their work order number and date on the box label.	mber and	ork order nu	Use their w	Flare Tubes	Flare
		BRZ00		•		etter "M."	Located on the spool label, starting with the letter "M."	bel, startir	the spool lal	Located on	Copper Tubing	Coppe
		BRZ22				ord "heat."	Located on the box label, directly above the word "heat."	directly	the box labe	Located on	Brazing Rings	Brazi
		CUTU-36-5/32-B	CUTI			x quantity.	Six digit no. located on the box label under box quantity.	the box la	located on t	Six digit no.	Flare Nuts	Flar
		CSW-3-7/8	Ω				nbers	ablity Nur	Distinguishing Traceablity Numbers	Distingu		
		SF7-2.5-22	S	1 9.					17		Order Qty	Ord
	No(s)	Component(s)	Con		LC	devices, LLC	H		392280	39	Order No.	Ord
~	Heat Lot/Traceability		2			OD TOO	ı		5/-2.5-22-36-B	3/-2.5	Part No.	Pa