								L			
								6 Meeting			
								4 FAIR			
_				-	_				(1)		
	Notes	Inspector	Rev Letter	Approved Mtrl Yes / No Check	Time Of Day Ye	Date Part Ti	ce	<ol> <li>Maintenance</li> <li>Tooling</li> </ol>			
		First Part Inspection Record	First Part In				ne Codes	Down Time Codes		Special Notes / Instructions	Special
_											ROUTING:
Ò											
Ş											
	(				+						
	3,5										
	O JULI										
	76										
	7										
					1						
				-							
								তা		SB	3/35
Scrap Scrap		Notes		Down Time Code	Down Time Dov	Cum. Total D	Cun	Total Pcs.	Prod Hrs.	Emp. Name	Date
	put/8hrs		PCS./Hr		Time		Hrs.			Macil. No.	
	Thru-		Por /Uz		Cycle		Setup			Mach No	
							lity.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
						Located on the bag followed by "Lot Number."	owed by "Lo	the bag follo	Located on	Snap Rings	Snap
					ox label.	Use their work order number and date on the box label.	ımber and	ork order nu	Use their w	Flare Tubes	Flare
					er "M."	Located on the spool label, starting with the letter "M."	bel, starting	the spool la	Located on	Copper Tubing	Copper
					rd "heat."	Located on the box label, directly above the word "heat."	el, directly a	the box lab	Located on	Brazing Rings	Brazin
					quantity.	Six digit no. located on the box label under box quantity.	the box lab	located on	Six digit no.	Flare Nuts	Flare
	20293300	A-RING				bers	eablity Num	Distinguishing Traceablity Numbers	Distingu		
	99810H	AR25						5		Order Qty	Orde
	No(s)	Component(s)	Con		devices, LLC	di de		401865	40	Order No.	Orde
lity	Heat Lot/Traceability				-			AR25-R	AF	Part No.	Par