1.00.1											
Order No.	3/-4	392114		THE STATE OF THE S	control	5	<u>.</u>	Component(s)	Heat Lot/Traceability	raceability (s)	
Order Qty		1						7-4-9	391126		
	Distingu	Distinguishing Traceablity Numbers	lity Numb	ers				CUTU-0-1/4	N A		
Flare Nuts	Six digit no.	Six digit no. located on the box label under box quantity.	box labe	under bo	x quantity.			BRZ09	101 be	11	
Brazing Rings	Located on	Located on the box label, directly above the word "heat."	directly ak	ove the w	ord "heat."			BRZ05	-	376	
Copper Tubing	Located on	Located on the spool label, starting with the letter "M."	l, starting	with the l	etter "M."		0	CUTU-0-7/8	N/A		
Flare Tubes	Use their w	Use their work order number and date on the box label	ber and d	ate on the	box label.			CP15			
Snap Rings	Located on	Located on the bag followed by "Lot Number."	ed by "Lot	: Number.	=						
Caps/Plugs	Do not requ	Do not require traceability.	/-								
Mach. No.	U		Setup Hrs.	5	Cycle	N S	Pcs./Hr		Thru- put/8hrs		N.
Date Emp Name	D D D D D D D D D D D D D D D D D D D	Total Bos	C .	Cim Total	D Him	Down Time		Notos			Scrap
	001110	0.00	Calli	0.00	Cowin	Code		Notes		Scialo	Code
2-3-4 Hub		/							\	0	
								7			
								10000			
							(
							4				
									7		
								3	55		
								X			
										?	1
ROUTING:										1	
Special Notes / Instructions	ıctions	Down Time	Codes				First Part	First Part Inspection Record			
		 Maintenance Tooling 		Date Part Submitted	Time Of Day	Approved Yes / No	Mtrl Check Rev Letter	r Inspector	9	Notes	
			- 19	23/15	05:11	4/65	4	本	OA HO		
		5 Training6 Meeting					4				