BRAZING PRODUCTION RECORD		1 Mainter 2 Tooling 3 Setup 4 FAIR	Special Notes / Instructions Dow	ROUTING:							100	ate Emp. Name Prod Hrs.	Mach. No.	caps/riugs Do not require traceability.			Copper Tubing Located on the spi	Brazing Rings Located on the bo	Flare Nuts Six digit no. locate		Order Oty 100
	ting	nance	Down Time Codes								0	Total Pcs. Cum. Total	Setup Hrs.	ceability.	Located on the bag followed by "Lot Number."	Use their work order number and date on the box label	Located on the spool label, starting with the letter "M."	Located on the box label, directly above the word "heat."	Six digit no. located on the box label under box quantity.	Distinguishing Traceablity Numbers	
		Date Part Submitted Time Of Day	がん 東 び し									otal Down Time	Cycle Time		Number."	te on the box lab	vith the letter "N	ove the word "he	under box quant	ars	
		Day Approved Yes / No										Down Time Code				el.	1."	eat."	ity.		
		Check Rev Letter	First Part I										Pcs./Hr								
		Inspector	First Part Inspection Record									Notes							J-RING	10	02 0 2/16
						10 S	5						Thru- put/8hrs						99L0h02	~ /A	
		Notes		3	7	5.5		5				Scrap							766		
												Scrap Code									