											200 000
							04 0	6 Meeting			
			6				4	4 FAIR			
	(grul r.g.)	X	1	-	7.7	1.22-16		3 Setup			
	Notes	Inspector	Mtrl Rev Letter	Approved N Yes / No Cl	Time Of Day	Date Part Submitted	nance	<ol> <li>Maintenance</li> <li>Tooling</li> </ol>			
		First Part Inspection Record					Down Time Codes	Down '	ctions	Special Notes / Instructions	Specia
											ROUTING:
	7										
	1 5/										
	1000										
	45										
1					*						
						_			& Jane	TATO	1199/16
Scrap Code	Scrap	Notes		Down Time Code	Down Time	Cum. Total		Total Pcs.	Prod Hrs.	Emp. Name	Date
	put/onrs				111110		1113.				
	Thru-		Pcs./Hr		Cycle	- O	Setup	*		Mach. No.	
							ability.	uire tracea	Do not require traceability.	Caps/Plugs	Caps
					-	Located on the bag followed by "Lot Number."	ollowed by	the bag fo	Located on	Snap Rings	Snap
					box label.	Use their work order number and date on the box label	number an	ork order	Use their w	Flare Tubes	Flare
					etter "M."	Located on the spool label, starting with the letter "M."	label, start	the spool	Located on	Copper Tubing	Coppe
		CP13		1	vord "heat."	Located on the box label, directly above the word "heat."	abel, directl	the box la	Located on	Brazing Rings	Brazir
		BRZ03			ox quantity.	Six digit no. located on the box label under box quantity.	on the box l	. located c	Six digit no	Flare Nuts	Flare
		CUTU-1-1/2	C			umbers	Distinguishing Traceablity Numbers	uishing Tra	Disting		
	297921	SF403-6-3/16	SF					1		Order Qty	Orde
	No(s)	Component(s)	6	TC	devices, LLC	H		397921	3	Order No.	Ord
	Heat Lot/Traceability		}		on the column at			S403-6-3/16	540	Part No.	Par