											BBAZING BBODI CTION BECORD	RAZING DR
									Ω.			
									4 FAIR 5 Training			
				9								
	Notes	Inspector	Rev Letter	Mtrl	Approved	Time Of Day	Date Part Submitted	ĕ	 Maintenance Tooling 			
		rt Inspection Record	First Part I					e Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
2												ROUTING:
									ىو		SB	12/7
Scrap Scrap		Notes			Down Time Code	Down Time	Cum. Total	Q	Total Pcs.	Prod Hrs.	Emp. Name	Date
	Thru- put/8hrs		Pcs./Hr			Cycle Time		Setup Hrs.			Mach. No.	
-	日本の日本の日本の日本の日本の日本の日本の日本の日本の日本の日本の日本の日本の日			Show A photos			E			Section Section		
								ity.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
						=	Located on the bag followed by "Lot Number."	wed by '	the bag follo	Located on	Snap Rings	Snap
						box label.	Use their work order number and date on the box label.	mber an	ork order nu	Use their w	Flare Tubes	Flare
						etter "M."	Located on the spool label, starting with the letter "M."	el, starti	the spool lak	Located on	Copper Tubing	Coppe
					77-5	vord "heat."	Located on the box label, directly above the word "heat."	l, directl	the box labe	Located on	Brazing Rings	Brazii
						ox quantity.	Six digit no. located on the box label under box quantity.	he box la	located on t	Six digit no.	Flare Nuts	Flar
	30151504	G-RING					mbers	ablity Nu	Distinguishing Traceablity Numbers	Distingu		
2360	11.00 Met	701-4-5/16	7(2		Order Qty	Ord
	No(s)	Lomponent(s)	-		ררכ	devices, LLC	H		392865	39	Order No.	Ord
ility	Heat Lot/Traceability						1		701-4-5/16-R	701-4	Part No.	Pai