									6 Meeting			
									4 FAIR			
	Notes	Inspector	Rev Letter	Check	Approved Yes / No	Time Of Day	Submitted	ce	<ol> <li>Maintenance</li> <li>Tooling</li> <li>Setup</li> </ol>			
		t Inspection Record	First Part I					e Codes			Special Notes / Instructions	Specia
												ROUTING:
				1					900		90	121
COOC					3				300		3	12/
Scrap Scrap		Notes			Down Time Code	Down Time	Cum. Total	5	Total Pcs.	Prod Hrs.	Emp. Name	Date
THE STATE OF THE PARTY OF THE P	put/8hrs					Time		Hrs.				
	Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
								lity.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
							Located on the bag followed by "Lot Number."	wed by "	the bag follo	Located on		Snap
						box label.	Use their work order number and date on the box label.	mber and	ork order nu	Use their w	Flare Tubes	Flare
						etter "M."	Located on the spool label, starting with the letter "M."	pel, starti	the spool lal	Located on	Copper Tubing	Coppe
						ord "heat."	Located on the box label, directly above the word "heat."	l, directly	the box labe	Located on	Brazing Rings	Brazir
	30060667	E-RING				x quantity.	Six digit no. located on the box label under box quantity.	the box la	located on t	Six digit no.	Flare Nuts	Flar
	Z/A	E10					mbers	ablity Nu	Distinguishing Traceablity Numbers	Distingu		
	389214	902-19-3/16	90	ļ					250		Order Qty	Ord
	No(s)	component(s)	6		LLC	devices, LLC	C C	E.	394833	39	Order No.	Ord
ility	Heat Lot/Traceability	manant(s)	5			ont rol			902-19-3/16-10	902-19	Part No.	Par