

## **Kindle Setup for 2024 -2025 models**

---

### **Preparation**

1. Bring the Right Cable: Always carry both a USB-C and a Micro-USB cable. Many users have lost their original chargers.
2. Verify Wi-Fi Status: Most sync issues are solved by checking the signal strength in the top menu bar.
3. Use the "Slow Down" Rule: Kindle processors are slower than phones. Allow 2–3 seconds for the device to respond after a tap.

### **1. Device Identification and Registration**

To identify your model, go to Settings > Device Options > Device Info. Alternatively, log into Amazon.com, go to 'Manage Your Content and Devices,' and select the 'Devices' tab to see the specific generation.

To register or switch accounts: Settings > Your Account > Deregister. Once deregistered, you can log in with the new credentials. Note that this removes all currently downloaded content from the device.

### **2. Managing Content and Libraries**

To add library books via Libby: Borrow the book in the Libby app, select 'Read with Kindle,' and follow the link to Amazon. Ensure the Amazon account signed into the browser matches the account on the Kindle.

To filter your library: In the library view, tap the 'Filter' dropdown and select 'Downloaded' to see only local files, or 'All' to see your cloud library.

### **3. Advanced Storage Management**

For bulk removal of files (to free up space):

1. Navigate to Settings > Device Options > Advanced Options > Storage Management.
2. Select 'Manual Removal.'
3. Choose a category like 'Samples' or 'Books.'
4. Use the checkboxes to select multiple items, then tap 'Remove.'

**Note:** This removes the local file to clear space but keeps the book linked to your Amazon cloud account.

### 4. Troubleshooting and Maintenance

Firmware Updates: These occur automatically via Wi-Fi. To update manually, download the .bin file from the Amazon website for your specific model, connect the Kindle to your computer via USB, and place the file in the Kindle root folder. Eject the device, then go to Settings > Device Options > Update Your Kindle.

**Forgotten PIN:** On e-readers, entering 111222777 in the PIN field will trigger a factory reset. On Fire tablets, enter the wrong PIN 5 times to trigger a reset link.

### 5. Device Organization

To manage multiple Kindles, rename each device via the 'Manage Your Content and Devices' page on Amazon. This allows you to easily choose the correct device when sending books ('Deliver to device').