

1. One Earbud Not Producing Sound

Check both earbuds are charged by placing them in the case for 5 minutes, then retry. Reset the connection: place both earbuds back in the case, close the lid for 10 seconds, reopen, and reconnect.

Check Bluetooth audio balance settings on your phone — some devices have a left/right balance slider that may be set to one side. If the issue persists after these steps, this may indicate a hardware fault eligible for warranty service.

2. Earbuds Won't Charge

Check the USB-C cable is fully seated in both the case and the power source. Try a different power source, such as a wall adapter or different USB port, to rule out a faulty charger.

Clean the charging contacts inside the case and on the earbuds with a dry, soft cloth — debris on contacts is a common cause of charging failure. If the LED shows no response at all after these steps, the unit may need warranty service.

3. Earbuds Won't Pair or Keep Disconnecting

Ensure earbuds are charged above 20%. Turn off Bluetooth on the phone, wait 10 seconds, then turn it back on. Forget the "ShopNest Pulse" device in Bluetooth settings, then perform the reset procedure and re-pair from scratch. Move closer to the connected device — distances beyond 10 meters or obstructions like walls can cause drops.

4. Sound Cutting Out Intermittently

This is most commonly caused by Bluetooth interference from other wireless devices, low battery, or distance from the source device. Try moving closer to the paired device and away from other electronics like routers or microwaves.

5. Touch Controls Not Responding

Ensure the touch sensor area, the outer flat surface of the earbud, is dry — moisture from sweat or rain can interfere with the capacitive touch sensor. Wipe dry and try again.

6. Earbuds Falling Out During Exercise

If your earbuds keep falling out, especially during exercise or running, this is almost always a tip-size or insertion-angle issue rather than a product defect. Try the Large ear tips if you're currently using Medium, and insert by gently pulling the outer ear up and back while inserting, which straightens the ear canal for a better seal. For high-movement activities, a snugger fit

combined with proper insertion technique resolves this in most cases.

7. Echo or Feedback During Calls

If the person you're calling reports hearing an echo, try lowering your call volume slightly, as the earbuds' microphones may be picking up audio from the speaker. Moving to a quieter environment and ensuring only one earbud's microphone is active at close range can also help. If the issue persists, try the call on a different app to rule out a software-side cause unrelated to the earbuds.

8. One Earbud Louder Than the Other

If one earbud sounds louder than the other, check your phone's Bluetooth audio balance settings, as some devices have a left/right balance slider that may not be centered. If the balance settings are centered and the issue persists, try the reset procedure: place both earbuds in the case, close the lid for 10 seconds, reopen, and reconnect from scratch.

9. Case Not Charging the Earbuds

Confirm the earbuds are seated fully and correctly in the case — they should click or seat firmly into place, and the charging contacts on the earbuds should align with the contacts inside the case. Clean both sets of contacts with a dry, soft cloth, as debris is a common cause of failed charging even when the case itself has power.

10. LED Indicator Not Working

If the LED inside the case does not light up at all when opened or when charging, first confirm the case itself has charge by connecting it to power for at least 15 minutes. If the LED still does not respond after that, this may indicate a hardware fault eligible for warranty service.

11. Earbuds Overheating

Mild warmth during charging or extended use is normal. However, if an earbud becomes uncomfortably hot to the touch, stop using it immediately, remove it from your ear, and let it cool in a well-ventilated area. If overheating happens repeatedly under normal use, this may indicate a hardware fault eligible for warranty service.

12. Voice Assistant Not Responding to Triple-Tap

Confirm your phone has a voice assistant enabled and set as default, since the earbuds only relay the trigger and do not have their own built-in assistant. If the assistant is enabled but still doesn't respond, try re-pairing the earbuds, since a weak or interrupted Bluetooth connection can prevent the trigger signal from reaching your phone.

13. Audio Delay or Lag

Some audio delay is expected during video playback or gaming due to standard Bluetooth audio latency (approximately 120-180ms). If the delay is more severe than usual, move closer to your connected device to rule out signal interference, and check whether other Bluetooth devices nearby might be causing congestion.

14. Earbuds Stuck in Pairing Mode

If the earbuds remain in pairing mode (blinking white LED) and won't connect, forget the "ShopNest Pulse" device from your phone's Bluetooth settings entirely, place both earbuds back in the case, close the lid for 10 seconds, then reopen and attempt first-time pairing again from scratch.

15. Case Lid Not Closing Properly

Check that both earbuds are seated correctly and haven't shifted out of their charging slots, as misaligned earbuds can sometimes prevent the lid from closing flush. If the lid still won't close properly with both earbuds correctly seated, this may indicate a physical defect in the case hinge, which would need to be evaluated for warranty coverage depending on the cause.