Czech manual for Graphic Packet v1.61 modified in HTML form



Czech manual for the Graphic Packet program

Translation: OK1DNH, OK1BY, OK1DLE

I'm sorry and I know it's embarrassing to stick to someone work, but the whole text had to be re-written and in some places Correct or finish the translation, because unfortunately some passages were wrong. If you have the original text file, be careful, there are terms confused a memory or data file. At the same time, I tried to create a more suitable format. And it took me quite a bit of work, so I hope it doesn't appear under a different name on some other page...
Petr Faltus OK1CFP

Contents

1 General Information

1.1 Difference Between GP.EXE and GP286.EXE

2 Installation

2.1 Installation
Examples 2.2 Multi-Caller Operation

3 Additional information

3.1 CONFIG file.
GP 3.2 File *. GPI
3.3 Call file. GPC
3.4 Call File. GPM
3.5 MHEARD file.
GP 3.6 NAMES file.
GP 3.7 File *. GPB
3.8 BINDATA file.
GP 3.9 ICONS file.

GP 3.10 The mycall file. GPL
3.11 File *. GPI
3.12 File *. GPH

4 Keyboard commands

4.1 Commands Valid for All Channels
4.2 Commands Valid for Channels 1 to 10
4.3 Editor
Commands 4.4 BBS Menu and List Menu
Commands 4.5 Cursor Movement on the
Screen 4.6 Entering ASCII Characters 1 to 31

5 QSO Operation

5.1 General Information
5.2 Filetransfer (ALT-T)
5.3 Saving Connections (ALT-S)
5.4 Copying Text in the
Editor 5.5 Remotely Controlled Operation
5.6 External Programs
5.7 Splitscreen
5.8 Scroll-Lock
5.9 TNC
Commands 5.10 Journaling
5.11 Miscellaneous Connectt Texts
5.12 Sysop Function
5.13 DieBox AutoBin Transfer

6 MailBox Usage Options

6.1 BBS menu
6.2 DieBox List
function 6.3 Find
function 6.4 Problems recognizing a list
6.5 Importing a list from the editor

7 GP Editor

8 List of MH (ALT-H)

9 QSO Spy

9.1 Invoking a Joint Read
Connection 9.2 Spy Window
9.3 Automatic QSO Spy
9.4 Possible Problems

10 Autorouter

10.1 Recursive Path
Entries 10.2 Autorouting via SP Gateway
10.3 A Few Notes on the AUTOROUTER
10.4 QRG Management (for TNC Multiport Only)
10.5 Autoconnect Frequency-Dependent Conditions 10.6 %DIGI%
Macro 10.7 Registering Callers to the List During the Connection (ALT-N)

11 Setup Function (ALT-U)

11.1 Changing Colors
11.2 Remote-Controlled Prompt
11.3 Remote Control On/Off
11.4 Inserting Text Buffer
11.5 Echo
11.6 RX Clicker
11.7 Line
Break 11.8 Packet
Length 11.9 Softscroll
11.10 Code AutoSave
11.11 Beacon Menu
11.12 Dividing Line Between QSO Window and Monitor Window

12 DOS Shell

13 Using the Mouse

13.1 Scroll Bar (ScrollLock)

14 Command Line Parameters

14.1 **/e** a **/v**
parameters 14.2 **/h**
parameter 14.3 **/NOXMS** a **/NOEMS**
parameters 14.4 **/XTBO** a **/ATKBO**
parameters 14.5 /**3MOUSE**
14.6 /**NOFIFO**
parameter 14.7 /**CHECK**
parameter 14.8 /**KISSOFF** parameter

15 Softscroll

16 What is HOST mode on TNC2

17 Synchronization Errors

18 Several types

Appendix A

1 License Law

Appendix B

1 Contact Addresses

Appendix C

1 Authors of the program

1 General Information

GP is a terminal program using Host-Mode software WA8DED, or another. However, other TNC software can also be used if it supports KISS mode. In this case, however, the TFPCR program from DL1MEN and a suitable modem are required. GP differs from other terminal programs in that it uses a graphical user interface, which makes it very easy to operate. For everyone Important features here are icons that can be entered with the mouse. If the mouse is not connected, These functions can be activated using the keyboard (hotkeys). GP offers a maximum of 10 QSO channels, but you can set fewer of them if desired. However, for Mailbox traffic There are two more useful features. After **the (C)heck** command, the following is stored overview in a special buffer, which can then be called up using F11. Likewise, after **(L)ist** command, invoke it using F12. From version 1.20 onwards, other BBS systems. In addition, there is a small editor built into GP, allowing text editing, but also e.g. configuration data.

To work with GP, you need an IBM-compatible computer, at least 1MB, EGA or VGA graphics card and DOS 2.0 or higher DOS version. GP works also in the DOS window under OS/2. In conjunction with standard VGA, it can be run at full capacity screen or as WINDOWS, or can be switched via ALT-Home. Whether he works and with SVGA, XGA, etc., unfortunately, I can't say. However, full-screen mode will work Anyway. If EMS or XMS memory is built into the PC used, then GP stores Scroll-Back-buffers and there is still about 380K left for further use normal DOS memory.

1.1 Difference Between GP.EXE and GP286.EXE

- - GP is designed in two variants, for different types of processors.
- - GP.EXE works with all 80x86 processors, i.e. 8088, 8086, 80286, etc
- - GP286.EXE supports the extended 80286 command set, and therefore It does NOT run on 8088 or 8086, but ONLY on 80286 and its successors. If the If you try to run this program on 8088 or 8086, the system crashes. (Experiments have shown that GP286.EXE also runs on the XT if it is equipped with an NEC V20 processor) Z lack of memory space, the QSO spy function was abandoned in GP.EXE, which occurs only in GP286.EXE.

2 Installation

HD is required to operate GP. Installing GP on HD is very simple. Just call up the INSTALL.BAT after which the desired GP directory and copying all the necessary files. Then it is necessary to file CONFIG. GP to adapt to personal needs, i.e. setting your own CALL, etc. For remote control, an additional subdirectory needs to be compiled, which they can then access all foreign stations. The path to this subdirectory must then be in the configuration files are adjusted accordingly. For the remote **RUN** command, another must be taken subdirectory, because this command it is a call to external programs whose output is directed to TNC, i.e. back to the counterstation. However, these external programmes should be included in another directory than GP, because GP itself can be invoked as an external program, which would led to

inevitable complications. The commands for the configuration file are explained in Chapter 3.1.

2.1 Installation Examples

To operate GP, we need the following files: GP.EXE and GP. OVR or GP286.EXE and GP286. OVR (own program and its Overlay), BINDATA. GP (file for the greetings window), ICONS. GP (Icon Image File), CONFIG. GP (configuration file), ????????. GPT (e.g. DL.GPT) (texts for system and remote control), ????????. GPH (e.g. DL.GPH) (texts for remote help).

The remaining files are not strictly necessary for GP operation. Using CTEXT. GPI and QRT. GPI can compose texts for both greeting and farewell according to your wishes. To the NAMES file. GP are used to write the names of the stations, that used the **Name** statement as well as the paths to them. List of these stations can also be replenished manually. If a station is already in the list, just enter when connecting only her caller and GP will find the way to her in the overview himself.

Example:
*- GP must be installed on C**:\GP***
*- upload all remote control functions to **the C:\GP\USER directory.***
GP *- external programs that can be invoked using **RUN** must be located in the **C:\GP\EXTERNAL directory.***
GP *- data storage must be done in **the C:\GP\SAVE directory.***
GP *- the original floppy disk with GP is in the drive A:*
C:\>cd and:
A:\>install a: c:\gp
(the installer starts and saves automatically to C:\GP)
C:\GP>md external.gp
C:\GP>md user.gp
C:\GP>md save.gp
C:\GP>copy sysinfo.exe external.gp
(1 file copied)
C:\GP
> Now the CONFIG must be changed. GP, namely the path setting for remote control and text storage:
UserDir = C:\GP\USER.
GP ExternalDir = C:\GP\EXTERNAL.
GP SaveDir = C:\GP\SAVE.
GP LogDir = C:\GP
In addition, the call sign must be changed:
MyCall = xxxxxx
(e.g.: MyCall = OK1KQJ)

Until now, only NOCALL has been used instead of CALL and therefore we need to replace it with our own CALL. The data for the serial port is still set to 9600baud and COM1. If we set the TNC to a different number of baud or we will operate it on another port, we must adjust the individual parameters accordingly change (**SerBaud**

and **SerNr**). If you would like to operate a GP on third or fourth port, then you need to add the port number and the IRQ port number, because they are not standardized. You can get the necessary information in the manual of the PC you are using. The next one is to add to the NAMES file. GP insert custom CALL, NAME and LINK the way to well-known stations. The syntax of these notations can be found in Chapter 3.6, or in NAMES. GP of the original floppy disk.

2.2 Multi-Caller Operation

If we run GP on a computer under different tags (CALL), We have the opportunity to compile separate contact texts, info texts for each caller and farewell texts. Installation is very simple and we need it for every CALL file to compile a separate file and store the necessary data in it. Names then correspond to the given CALL. The directory can then contain the following files:

CTEXT???. GPI - General Connectt texts (see 5.11)
<call>. GPC - Personal Connect Texts for <Call>
<Call>. GPM – mail file for <call>
*<mycall>. GPI (or INFO. GPI) – an info file called up using **I***
*QRT. GPI - farewell texts, called up by **Q***

Each of these data is first searched in the MYCALL file. If it is not there, it is searched in the GP file. This gives the possibility to use part of the MYCALL texts, common to other CALLs.

3 Additional information

3.1 CONFIG file. GP

In the CONFIG. GP stores the necessary parameters for GP operation. These need to be set to the appropriate values right away, especially then parameters for the V24 interface, graphics and data for remote control. Syntax determining variables always has the same form, e.g.:

Zoom = 2

It is also possible to include comments in the file if it is preceded by We put a semicolon. However, they can always be only at the end of the line after the command, e.g.:

Zoom = 2 ; Zoom is set to 2

3.1.1 Color Adjustment

The GP screen is divided into several windows, the color of which can be set completely individually according to your own wishes. Screen color options reveals the following list:

Black = Black
Blue = Blue
Green =
Green *Cyan = Turquoise*
Red = Red
Magenta = Purple
Orange =
Orange LightGray = Light Grey
DarkGray = Dark Grey
LightBlue = Light Blue
LightGreen = Light Green
LightCyan = Light Turquoise
LightRed = Light Red
LightMagenta = Light Purple
Yellow = Yellow
White = White

There are the following variables for setting them:

MonitorBackGround	Monitor window background color
MonitorForeGround	Monitor window text color
MonitorInverzAttr	Monitor window text color, inverse
EditorBackGround	Editor background color
EditorForeGround	Editor text color
EditorInverzAttr	cursor color and EOL tags in the editor
CheckBackGround	background color BBS Menu window
CheckForeGround	Text Color BBS Window Menu
CheckInverzAttr	Selection color and data labeling
ListBackGround	DieBox List Window Background Color
ListForeGround	DieBox List Window Text Color
ListInverseAttr	Color of data selection and labeling, inverse
ConnectBackGround	Background color of the Connect window (channel 1 to 10)
ConnectForeGround	Color of the received text in the Connect window
ConnectInverzAttr	Color of the broadcast text in the Connect window
MenuBackGround	Top Menu background color
MenuForeGround	Text color of the top Menu
MenuInverzAttr	If we receive text on one channel, we can see at the same time activity on another channel, this will be reflected in the change in the color of the text
StateBackGround	Background Color Status Window
StateForeGround	Text color Window status

InputBackGround	Receiving Window Background Color
InputForeGround	Receive window text color
MHBackGround	MH Sheet Background Color
MHForeGround	MH Sheet Color
MHInverzAttr	Inverted Color MH Sheet (Selection)
SpyBackGround	QSO spy background color
SpyForeGround	QSO spy foreground color
SpyInverseAttr	inverse color of QSO spy

3.1.2 Setting the Scroll Back Buffer

In GP, there is a text buffer for each channel, into which data is stored and can be browsed if you view the data on the screen. The size of the text buffer is individually adjustable and is given by the number of 80 character lines. Therefore, if we want the size of the text buffer expressed in bytes needed for RAM, we need to multiply the number of rows by 84, because we need 80 bytes on the line (80 bytes for the actual text and 4 bytes for color settings). The number of rows can fluctuate between 40 and 780, with 40 lines is the minimum that can be displayed in the image, and 780 is the maximum that can be one segment of memory of the 80x86 processor to address because its maximum the capacity is 64KB, which is equivalent to about 780 rows.

CheckBuffer	buffer for BBS Menu window
EditBuffer	Buffer Pro Editor
TextBuffer	buffer for monitor and channels 1-10, the number of channels can be selected and according to their number, also the size of the monitoring window. Entered in order Monitor, Channel 1, Channel 2, Up to
InputBuffer	buffer for channel 1-10 and monitor writes window. Applications This command is analogous to the TextBuffer command, but you can insert a maximum of 199 lines.
SpyBuffer	buffer for QSO spy window
MHBuffer	buffer for MH sheet

3.1.3 Setting Timers

GP also includes a screensaver, which after a certain period of time, If no key has been pressed, it will darken. This time can be set configuration data. The command is **Screensave** and is given in minutes, i.e. the **Screensave command = 5** darkens the screen after 5 minutes of inactivity. Next we can set the time for which the data of the Pop-Up window, connection messages, etc. should be displayed. There is also a **PopUpTime** command, where but the time is given in seconds. **PopUpTime command = 5** means that the command will be displayed for 5 seconds. Also, the

internal time of GP is adjustable in relation to the computer. The change is made by using the **Time** and **Zone** command. The **Time** statement defines the GP program time in the relation to the computer in minutes. **Time = -60** is used to achieve a delay GP time against computer time by 60 minutes. The **Zone** statement affects the MACRO **%z**, specifying in zone time. However, for automatic journaling, in addition to system GP time still needed universal time (UTC). This can be determined by **the UTC** command. A time shift is also possible here compared to the system GP time by commanding e.g.: **UTC = -120**. This will achieve computer time delay compared to system time by 2 hours = CEST (daylight saving time). The **ConnectBell** command indicates the number of times to ring if the is connected by another station. In this case, the GP produces a signal that sounds like three-voice phone ringtone. **ConnectBell command = 5** means that the bell will ring 5 times.

3.1.4 Configuring the serial interface

GP is capable of handling any combination of address and IRQ for the serial port. IRQs can also have AT-specific values, i.e. values between 8 to 15. If we use the first or second interface, there are both port numbers and IRQs is standardized and GP is known, so you only need to enter the port number. All values may be entered in decimal or hexadecimal. However, in the case of hexadecimal numbers, the dollar must come first, e.g. $3F8. Number of data, traces, and bit parities cannot be change. These are set to 8 data bytes, 1 stop bit and no parity in GP. The following commands exist for serial interface settings:

SerNr - Port
Number *SerBaud - Transfer*
Rate *SerPort - SerIRQ Interface*
Port *Address - Port IRQ*

3.1.5 Path Settings

For remote control by **Dir**, **Write**, **Read** and **DELete** from the terminated counterpart, directory Roads. All foreign stations have the same priority, i.e. they can read all files and add other files as you wish. For this purpose, it is advisable to have your own overview. The command to set the data path is in CONFIG. GP **UserDir**. Another way is needed **for the RUN** statement. This directory will contain externally executable programs, the path is set by the **ExternalDir** command. You can also set the path to saving texts to memory with the **SaveDir** command. In order to achieve greater insight in the recording of QSOs, the spy for the QSO was Version 1.50 introduced **the SpyDir** command. This serves as a standard for listening to QSOs.

3.1.6 Initialization and deinitialization of TNC.

At the start and end of work with GP, TNC can be used according to your own wishes initialize. The syntax for initialization is always:

TNCINI = < TNC > Statement

As a <TNC command> you can use all the commands used TNC. Any number of initialization data can be included in the configuration data commands. For example, if we want to insert TNC computer time, we use **the TNCINI = Date Time** command, which is not in fact, the right TNC command, but only the GP program password. GP then this turns the password into TNC setup commands. The same applies to deinitialization rules as for initialization, except that the command TNCDEI:

TNCDEI = < TNC > Statement

If we want to invoke the DOS shell during GP work, it is advantageous disable the TNC monitor so that its buffer does not overflow due to other data, while we work in DOS. For example, there is a TNCDOS command for this case, which specifies which TNC parameters will be set to call the DOS shell and what value. After the shell exits, the TNCINI values are set to original condition. The syntax of the command is:

TNCDOS = < TNC > Command

3.1.7 Setting Up the Printer.

If we want to record the progress of the connection with the printer, we have the ability to distinguish the received text from the sent text by different types of font. However, this is only in in case the printer can do it. EPSON-compatible printers offer Various options. Up to 10 decimal characters can be used for setting, separated by commas. The **DefaultPrint** command sets the EPSON printer to print the received text, while **the InvertPrint** command will print it on the EPSON text sent by you. Syntax:

DefaultPrint = character 1, character 2 to .. character 10
InverzPrint = character 1, character 2 to .. Character 10

3.1.8 Remaining Settings.

The number of channels actually used is determined by the **Channels** command, the maximum is 10. Must not be more channels are specified than TNC is capable of processing. Otherwise, it will be permanently reported I guess. The GP has no way of knowing how many channels the TNC can process and therefore, PRG is only dependent on the correct settings. However, problems can also arise in in the event that fewer channels are set than the TNC is able to handle, if a channel that is not served by the GP is connected. Syntax:

Channels = < number of >
(e.g. Channels = 4)

The MYCALL command will reveal your caller and accordingly I'm going to start TNC. It is possible to use a separate caller for each channel. Channels Without a set caller, they are automatically placed by the monitor caller. The callers are given in the following order: monitor, channel 1 to .10 and are separated by a comma. Two lines in a row omit one channel. Syntax:

MYCALL = monitorcall, channel1call, channel2call, up to .

Example: OK1KQJ, , OK1KQJ-2, , OK1KQJ-4
In this case, the monitor has been set to the OK1KQJ caller, Channels 1 and 3 have been omitted, i.e. they will take over the settings from the monitor and on channel 2 will be OK1KQJ-2 and on channel 4 will be OK1KQJ-4.

With the NoName command, we set both the stations (whose names are not yet entered into the namefile) to be addressed by the system (macro %N in the *. GPI). Syntax:

NoName = (salutation)

In the monitor window, you can optionally insert a blank line between displayed packets with the **InsertMonLine** command. Syntax:

InsertMonLine = (ON/OFF)

Automatic station-journal management can be switched off on request with the **Log** command. Syntax:

LOG = <ON/OFF>

When automatic journaling is turned on, the frequency must be specified or at least a band, e.g. 430.625 or 70cm. This length is a maximum of 7 characters. Syntax:

QRG = Frequency/Band

However, this command is only effective if we do not use multiport TNC. However, we need to include QRG in the NAMES data when using it. GP. You can find out more in Chapter 9. The Backup command allows GP to exit stored the information in a text buffer, from where it retrieves it after the restart, so that in the event that the GP's work is interrupted during the connection, the QSO data shall be will not lose. Syntax:

Backup = <ON/OFF>

The receipt of each data packet can also be announced acoustically by tapping, i.e. when another packet arrives, a signal is heard. The command is **RXClick** and can take the form of:

0	No signal
1	signal only when a packet arrives in a window other than the current one
2	Signal when a packet arrives in any window

Syntax:

RXClick = <0 to 2>

The language when remote control of the counter station can be set. However, only those languages about which there are * can be selected. GPT files.

Syntax:

RemoteLanguage = <xxx>

Example: RemoteLanguage = G
In this case, English will be set. If this If you skip the command, the currently set language will be selected for the counter station as well.

The **REMOTE** command can be used to define the allowed remote control commands that can be used by the counter station use. **Setting REMOTE = *** means any remote control command. If we want to use only some, we need to list the individual commands separated by a comma. It is enough to state only Their abbreviations:

Example: REMOTE = VER, I, NE, N, #
In this case, the VERsion, Info, NEws commands are allowed, Name and language. All other commands are disabled.

The exact opposite of REMOTE is **NOREMOTE.** Here it is possible to define remote control commands that must not be used in No way. Otherwise, use as with the REMOTE command.

If we are bothered by GP questions such as YES/NO/interruption, we can replace with **Questions = <ON/OFF**> where ON turns the query on, OFF turns it off. But be careful, when disabling the query until the **FastPol** command affects the GP query method on TNC. **FastPol = ON** leads GP to query TNC at optimized speed and is fully utilized here interruptible operation V24. However, this method can lead to **Resync** errors, i.e. character failure when receiving V24. It depends entirely on the PC used, installed driver and programs that are running at the same time as GP. If if the problems just described occur, set **FastPol = OFF. FastPol=AUTO** is set, in which the query method depends on whether we use 16550A UART, or not. If we use it, the query will be optimized. Otherwise, it will be program should behave as **FastPol=OFF. PopUnableKeyboad** sounds terrible, but it actually decides whether the windows PopUp will be closed by keyboard, mouse or only mouse before **PopUpTime** expires. Premature closure allows **the PopUnableKeyboard command = ON** along with ENTER or ESC. On the other keys if there are windows open, does not respond. Copying the text as it used to be is no longer possible. **PopUnEnableKeyboard = OFF** allows the keyboard query if at least one window is still open. During of this time, we can prescribe, for example, a text that, after closing the window, will be in the transcript window. The window may be **PopUpTime** over time in this case closed with the mouse. **The MultiPort** command determines whether TNC should work in a standard, or DRSI mode. Normally, the GP recognizes completely automatically whether the TNC mode supports DRSI or No. Nevertheless, it may happen that, depending on the TNC SW, this automatic Recognition does not work. Therefore, when using MULTIPORT TNC, such as: FALCon/TNC4 or TNC3, **the MultiPort = ON** command must be used. When using TFPCX from version 2.0

onwards, we have the option to use **MultiPort command = AUTO** <default settings>. If we do not want to use the advantages of MultiPort, we will use **the MultiPort = OFF** command.

3.1.9 Conditional configurations.

In some situations, it is advantageous to be able to configure GP operatively according to the situation. In addition, the program offers the option of Edit **IF** Condition Configuration data and then control them using the command line. The function is simple, preferably The explanation will be given on an example:

Let's have two TNCs, one works with 9600 baudy and is controlled by V24, the second with 38400 baudy.

We can do CONFIG. GP to write the following commands:

```
<IF 38400>
SerBaud = 38400
<ELSE>
SerBaud = 9600
<END>
```

If GP is called **gp 38400** or **GP286 38400**, will be installed V24 with 38400 bauds. Otherwise, V24 with 9600 baud will be installed. They are For example, the following alternatives are possible:

```
<IF 38400>
SerBaud = 38400
<END>
<IF 19200>
SerBaud = 19200
<END>
<IF 9600>
SerBaud = 9600
<END>
```

The ELSE condition is not always necessary. There is also a logical use using **the NOT** function. For example:

```
<IF NOT 9600>
SerBaud = 38400
<ELSE>
SerBaud = 9600
<END>
```

Here, GP works with the 9600 baud interface if the user He called 9600. In all other cases, 38400 baud is installed.

What to watch out for:

- **key commands <IF (NOT) xxx>**, **<ELSE**> and **<END**> must be themselves on the line and must start in the first column.
- the use of multiple nested IF conditions is not allowed. The new IF condition can be defined if the preceding one is closed by using END.

3.1.9.1 Reserved keywords:

Previously, GP only had one **keyword to use, %TFPCX200**. Its use is similar Use the command-line parameter. However, it depends on whether (from version 2.0 onwards) TFPCX installed or not. For example:

```
<IF %TFPCX200>
TNCINI = @L 0:DB0FN
<END>
```

The **command @L 0:DB0FN** can be used if TFPCX 2.0 is installed. When using TNC, TFPCR or earlier version of TFPCX, this command is ignored.

3.2 File *. GPI

Files can be supplemented with GPI = Graphic Packet Infofile. Files with this extension contain informational texts that can be read other stations, e.g. by means of remote commands. In all files of this Extensions can be used macros. There are a total of 15 of them available. They are following:

%V	The version number of this software (in this case, it is **1.61**.)
%C	Counter Station Caller
%N	Counterstation name
%Y	Custom caller
%K	Channel number used
%T	Current GP time in HH:MM:SS format (e.g. **10:41:32**)
%D	Current GP date (e.g.: **25.03.1991**)
%B	Corresponds to the beep sign (07h)
%I	If available NEWS. GPI, a link to its existence, otherwise nothing
%Z	Indicates the time zone of the GP clock
%_	End a line and jump the cursor to a new line
%%	Percent sign
%O	Reads a line from the ORIGIN file. GPI (Generator Selector random numbers)
%?	prompts the connected counter station to report its name, if it is not already in the NAMES file. GP
%	Turns on prompt, recommended only for CTEXT file

Additionally, it is possible to add formatting information that Specifies the total length of the macro text. This is necessary because macros do not have a defined length when it changes according to the situation, e.g. %N macro. The formatting is determined after double cross with a two-digit number. If the actual MACRO TEXT is shorter than is the given format, the rest is filled with white space. For example:

%N 20 *will add a name connected stations, but the total length of the macro is always only 20 characters.*

The formatting information is especially important if we want to text that contains a macro to frame. As an example for using a macro, we can specify the CTEXT file. GPI.

3.2.1 CTEXT file???. GPI

This file contains a general greeting text that is sent when another station connects. The standard connection text is called **CTEXT. GPI,** but may also be included alternative. These texts can be switched as required during operation. Closer This is in Chapter 5.11.

3.2.2 NEWS file. GPI

This file is used to publish current news. Text can be read via the **NEWS** remote command. The file can be canceled, if there is no news.

3.2.3 MYCALL file. GPI

This file is sent by the **remote Info** command. It contains a short information about own station. A call sign (e.g. OK1XXX. GPI). Thus, information about multiple users of the computer can be included if more than one users. If the caller file is not available user, INFO is used**. GPI.**

3.2.4 F1 file. GPI to F12. GPI

These files may contain text macros. These texts can be invoked from GP using SHIFT+F1 to F12. The file name matches the functional number keys, e.g. **the F5 file. GPI** invoked by SHIFT+F5. Macros F11. GPI and F12. GPI can be used on a computer, that has an extended keyboard with F11 and F12 function keys attached.

3.2.5 QRT file. GPI

This file is sent at the end of the connection if The counterstation sends a remote **command Q**. After sending the text you are sent, the connection is interrupted.

3.2.6 RUN file. GPI

If a remote **RUN** command is invoked by any of the counterstations, sends the GP the text contained in this file. The file should contain a brief description of all external programs that can be invoked by **the RUN** command.

3.2.7 ORIGIN file. GPI

In this file, the user can collect original quotes and messages, and these using the %O macro can be used, for example, in CTEXT for random generating one of them. For each quote or phrase, only One line with a maximum of 255 characters.

3.2.8 Instructions for using *. GPI

Since GPI files can be read by any station, it is The following things to consider:

- Be careful to use diacritics and graphic accents in these texts. IBM characters. These may look nice on a given computer, but the opposite station on the They can show all sorts of other signs, which doesn't look nice anymore.
- In the text of remote commands, make sure that these commands they didn't start right at the beginning of the lines, because they could be the program of the counterstation evaluated incorrectly.

3.3 Call. GPC

Personal connections may be collected in these files texts for selected callers - this means that station A can be greeted differently than station B. If we are connected to a station and there is a corresponding to the GPC file, then the default is CTEXT. GPI ignored and the given GPC file. Personal connects texts can contain all macros.

3.4 Call. GPM

This suffix stands for Graphic Packet Mail. With the help of these files, we have the ability to direct personal messages to a specific caller. If we are this connected to the station, this file is sent instead of the normal greeting text. There can be only one GPM file for each caller. May contain the same macros as GPI files. The GPM file can be deleted by the remote **Kill** or **DEL** command without specifying the file name. This should be credited at the end. A GPM file always has a higher priority than a GPC file.

3.5 MHEARD File. GP

The GP has a built-in MH list inside, in which they are collected all the calls I heard. The size of the MH list can be found in the configuration data set using **the MH Buffer** command. The MH list serves as a menu for QSO spy (see Chapter 9) and can also be summoned by connected stations **by the MHeard** remote command. After the end of the GP, the MH list is again stored in the file MHeard.GP.

3.6 NAMES file. GP

Names and frequencies are collected in this file (bands) of other stations. In addition, QRG leadership takes place here through GP. Connected stations can be entered into the list themselves, if they use the **Name** statement. Because the for the list of names it is normal ASCII-Text, we can edit or change it. More detailed information on syntax can be found in Chapter 10.

3.7 File *. GPB

GPB stands for Graphic Packet Backup and refers to a file that GP established the program so that it would not forget its internal data by terminating it. It is not possible to manipulate. Thanks to this file, it is possible to end the GP during the QSO and again start without having to disconnect first.

3.8 BINDATA file. GP

This file contains data for the greetings window (introductory greeting) - in EGA mode, the greeting window cannot be displayed due to the small Discrimination.

3.9 ICONS file. GP

In this file there are icons from the program. This file is taken from HD, even if we have EMS or XMS memory installed in our PC. But in this In this case, the data is completely loaded into this memory at startup and for GP there are still available without having to go back to HD. The file must be in the same directory as GP. If it is missing or has been tampered with, GP will not start. The appearance of the icons can be edited according to your own wishes by the GPpaint program from DL1ELY.

3.10 mycall file. GPL

The GPL suffix stands for Graphic Packet Logfile and refers to a A daily newspaper founded by the manager of the newspaper. For each caller who uses the program, creates your own file to get a better overview. For different SSIDs, however, it does not create any new file. The journal file format is compatible with the SP program diaries.

3.11 File *. GPI

This file contains the GP system and remote texts. Therefore, it is it is possible to use different languages in GP, up to eight. For the sake of quick search, they are collected these texts each in a special file.

3.12 File *. GPH

These files store texts for control help programme. These are broadcast when a station invokes the **Help** command. Since high speed does not matter here, another one was chosen for this file format than for a GPT file. Each text is listed with a **CD** tag and then assigned a certain order as well as the number of significant letters, i.e.

how many first letters can be the maximum shortened. The exception is the general help text, i.e. when no other parameter is specified after the **Help** statement. This text is marked with @@.

4 Keyboard commands

4.1 Commands valid for all channels

F1 to F10	Switch between channels 1 to 10
F11 or ALT-F1	BBS menu
F12 or ALT-F2	DieBox list function
ALT-M	Switching to Monitor Channel
ALT-E	Switch to the editor
ALT-O	DOS shell
ALT-R	Enables/disables the softscroll of the respective channel
ALT-U	Program setup
ALT-X	Termination of the program
ALT-Z	On/off zoom (VGA only)
ALT-F4	Clear the current window
ALT-F6	Display of the last link status report
ALT-F7	Display the last error message
<Ins>	Switch between insertion and overwrite mode (only in editor and channels 1 to 10)
ALT-G	Clock chime switch (when using the mouse, you can click to the double note mark on the clock)

4.2 Commands valid for channels 1 to 10

ALT-B	Scroll lock on/off
ALT-C	Konekt, Build a Connection
ALT-D	Disconekt, disconnection of the connection
ALT-Y	Inserting a custom call (only in the unconnected state)
ALT-S	Continuous storage of connections
ALT-F	Sending data (connected state only) *)
ALT-F8	Splitscreen On/Off Switch
ALT-F9	Splitscreen split shift up
ALT-F10	Splitscreen split shift down

ALT-T	Artificially invoke connective text
ALT-Q	Inserting a frequency or band for QRG
ALT-N	Saving the name of the currently connected station
Shift-F1 to Shift-F12	Send text macros 1 through 12 to the counter (F1. GPI up to F12. GPI)
Ctrl-D	Write data to buffer
Ctrl-T	Write time to buffer
Ctrl-Y	Deleting rows in the buffer (can be copied to buffer and Ctrl-P to return to the original state)
Ctrl-C	Copy rows from an intermediate buffer (Copy)
Ctrl-P	Copy an intermediate buffer to a line (Paste)
Ctrl-O	Selecting a random line from the message generator (file ORIGIN. GPI) and copying it to the buffer
Ctrl-K or INS	Copying Selected Text from the Join Window to the GP Editor
Ctrl-ENTER	Send lines without CR at the end, which can set the length rows to a larger required length

4.3 Editor Commands

ALT-L	Loading the file *)
ALT-S	Save to a file
Ctrl-Y	Delete rows (can be copied to the buffer and Ctrl-P can be reverted to the original state at the same time)
Ctrl-C	Copy rows from an intermediate buffer (Copy)
Ctrl-P	Copy an intermediate buffer to a line (Paste)

and all other cursor commands

4.4 BBS menu and List menu commands

ALT-S	Sorting Checklist (BBS menu only)
Cursor	Selection in the list according to your wishes
<SPACE>	Mark/Cancel Current Enrollment
<ENTER>	Sending a **Mailbox READ** command for the current item
<ESC>	Leaving the Check Menu

4.5 Moving the cursor on the screen

CursorUp	Top
CursorDown	Down
CursorRight	Right
CursorLeft	Left
PageUp	One side up
PageDown	One side down
Ctrl-PageUp	Skip to top
Ctrl-PageDown	Skip to end of text
Ctrl-CursorRight	Jump to the beginning of the first word to the right of the cursor
Ctrl-CursorLeft	Jump to the beginning of the first word to the left of the cursor
Home	Jump to the first column**)
End	Jump to the end of the line **)

- *) **Upload text** and **Save text** are expected Enter a file name. If * or ? appears in the assignment, the so-called File Select Box, where we can select the file. If ***.*** has been specified, we can navigate through directories. An overview always starts with a subreport, followed by the file itself. Subreports can be recognized by the fact that the name is immediately followed by the backslash (****) character. Selecting a subreport sets a new path and prints the subreport. Press. **.** to return to the previous overview.
- **) **The Home** and **End** keys were due to the lack of others The appropriate keys in the monitor windows and channels 1 through 10 are occupied differently. Performed by Move up or down a row.

4.6 Entering ASCII characters 1 to 31

By default, ASCII characters can be produced with 1 to 31 key combinations Ctrl-A to Ctrl-Z, or other Ctrl combinations. Some of the functions of Ctrl are but occupied by GP control, e.g. Ctrl-D. In this case, we do not write ASCII character 4, but we substitute the date into the input buffer. If a combination is needed for The ASCII character, which is covered with a macro in GP, can be made classically using ALT keys and numeric keypads. Press the ALT key and hold it down, then we can type any number from 1 to 255 and finally release the ALT key.

5 QSO Operation

5.1 General Information

GP contains ten communication windows in which you can Connect to up to 10 stations. These channels are switched with the F1 function keys to F10. For each channel, you can choose a different call button via ALT-Y. If we want to connect to

another station, we must first select a free channel and then press ALT-C and type the destination station caller. If the station is registered in list of names, just enter the caller without a path. For example, if we want to connect DH1DAE via DB0NWS and DB0FN, when DH1DAE is not yet listed, we need to enter **DH1DAE DB0NWS DB0FN** (see TNC-2 manual). However, if DH1DAE is written in the list, you only need to write DH1DAE and the others will be arranged by the GP. To interrupt the connection, press ALT-D. If we simultaneously connected on multiple channels (in multiple windows), it will be shown on the top edge of the color if there is a new text on a channel that has not yet been read. We have the option of backing up the packet reception with an acoustic signal (see 3.1.8).

If we are connected to a station, we simply write to keyboard. The text is shown in the top window and can be edited with the cursor. K To send a text line, press Enter. The input editor is equipped with an automatic by interrupting line, so when you finish a line, a word that has not yet been completed moves to the next line and the last line is automatically sent (broadcast). This prevents uncontrolled division of words into end of lines and we no longer have to press ENTER, but longer texts can be typed and tapped without we would worry about sending a line. We just have to press Enter in that case, if the line should be less than 80 characters. This value can be changed in SETUP, which is important for cases where, for example, we are in CONVERS node mode. There, the node pre-orders the call characters before the lines senders and thus the length of the line is limited. Therefore, it is better to use CONVERSE, for example, Set line breakers to 65 characters per line.

5.2 Filetransfer (ALT-T)

This function sends the HD file to the counterpart, macros used for GPI files are ignored. There are 3 types of data transmission:

1. Text transfer (text files only)
2. Binary data transfer (similar to text transfer, but does not appear in the window at the same time)
3. Auto Bin Transfer (File Transfer including Check, File Name and attributes)
4. Transfer editor content (text only)

When transferring text files, the data is read sequentially and is transmitted to the counter station. However, certain signs are ignored, e.g. LF or EOF, which means a slight modification of the text. It doesn't matter with the text. However, if we want to transmit data that must not be altered, it must be sent exact content as a binary transfer. Auto Bin Transmission is an extension of the transmission binary data, where a simple protocol is used for transmission, which can be Any errors were also detected during the transfer. Before the actual transmission, first sends information about the file length to the counterpart and the counterpart confirms receipt of this information. This is followed by the actual data transfer and after the end it is sent to the counter station checksum that was calculated during the transfer. So it is possible to compare with the partner and if they have a different value, there was an error during the transfer and the data, which was received by the counter station are erroneous. This method of transmission is compatible with Turbo Packet, TOP, SP, etc. Of course, only

if the partner uses such a program. To receive data, there must be **7+ Auto Save** is enabled in the program, otherwise it will not appear at the beginning of the transmission The header does not decode and acknowledge, and the transmission cannot occur. GP detects when switched on 7+ AutoSave AutoBin header automatically.

The DieBox system offers the ability to upload and read file using AutoBin mode. More on this in Chapter 5.13. Broadcast content editor corresponds to the transfer of text data, only the content is broadcast instead of the file built-in text editor, and when the editor is broadcast, a check is performed maker. Therefore, care must be taken to avoid accidental macro evaluation. Therefore, there must be no such characters in the editor, any percentages must be manually to **%%.**

All methods of data transfer can be interrupted at any time and then the respective function can be repeated. If the GP during any data transmission we end ALT-X, then at the new start the transmission will start at the place where it was interrupted.

Since version 1.50, an additional status message is displayed when sending data. A window with some interesting data. Next to the file name and size, you can see how much has already been broadcast and the graphic percentage of the total length of the file. In addition, the effective transfer speed is also calculated, how long the transmission has been going on (ELAPSED TIME) and how long it is likely to last (ESTIMATED TIME). However, this estimate is quite rough, it depends a lot on the quality of traffic, which is relatively large fluctuations.

5.3 Saving Connections (ALT-S)

The connection to another station can be stored by different ways. If activated, the corresponding menu changes. During storage, it may be GP ALT-X is terminated, saving will continue at a new start. The same as when file transfer is shown for saving from Version 1.50 status box. Preliminary Calculation of transmission time and graphical display are only possible if the known overall size. This applies to Autobin and 7+ Autosave. The following is a description different storage options.

5.3.1 Text file continuously

Text is written to a floppy disk or disk at the moment when it is received and shown on the screen. And that is as long as there is no saving cancelled. Only text is saved since the save function is activated. It also imposes broadcast text.

5.3.2 Printing continuously

This saving option works the same as on a floppy disk or HD, only the printer is specifically addressed and the transmitted text is provided with a different print attribute, so that the appearance of the received text is different from that of the transmitted text (similar to the screen). Print attributes can be set in the configuration file commands **DefaultPrint** and **InverzPrint**. Because DOS is being built parallel

ports of printers as files, the data can also be printed. This happens if we specify **LPT1** to **LPT4** (or **PRN)** instead of the file name as the save destination.

5.3.3 Saving a part of text

Any part of windows 1 to 10 can be saved to HD. It is useful if, for example, we want to pull an interesting text from the Mailbox and we have They didn't turn on continuous saving. We can decide in this way only after the read the message. However, only text that is still in HD can be saved in the window buffer. If a small buffer is selected, it may happen that part of the text has already been rewritten and thus this part of the text is lost. Therefore, we should always have one for one channel to choose a relatively large buffer (e.g. 500 line), to which we connect Mailbox. Large GIF images, etc., if they have been encoded into text format via 7Plus, should always be saved continuously. It is best to 7Plus data can be saved using the Code Autosave function (see 5.3.5). As a goal Saving we will write some text file. If saving is performed on a printer, corresponds to the printed image of point 5.3.2. To print a part of the text, we need to enter corresponding print port, e.g. LPT 1. If we choose as the lower limit last line, we have the option to continue with continuous saving.

5.3.4 Saving to HD at Autobin

This function stores a binary file with a transfer file on the HD protocol that is compatible with Turbo Packet, SP and AHP (Car mode). A more detailed description is provided in Chapter 5.2. To receive from a partner some binary file, we must first activate binary storage with us, namely before the transmission is started at the opposite station. To save to HD some binary data that has been encoded with 7Plus, we can store it as normal text, i.e. continuously (see 5.3.1). From version 1.50 onwards, we don't need to receive Autobin can be started manually and we can leave it only to the GP. However, the prerequisite is activated switch for 7+ AutoSave and receiving Autobin headers from the opposite station filename. This applies, for example, to SP from version 6.0 and DieBox from version 6.0 onwards. 1.9.

NOTE: A file that is saved to the Mailbox in AutoBin format, is identified by **the (BIN)** before the title contribution. If the counter station does not use the extended Autobin header, they are data stored in memory under the name of the sender's call card file with the extension serial number between 000 and 999. For example, if the DB0SGL.000 file already exists, the name DB0SGL.001 will be generated next time if the extended Autobin is not used header.

5.3.5 Code Autosave

Code Autosave is a useful feature to store encoded data 7Plus to disk. GP organizes them automatically and the user does not have to worry about correct file names. The program recognizes all 7Plus files, including **ERR** and **COR**. This is especially practical if the file is divided into more episodes. Because the GP chooses the correct names for the files in question automatically, we don't have to worry about anything at all, just

enter e.g. **r 10-20** in the Mailbox and after to have a cup of coffee. The operation is simple. Once a 7Plus header is detected, then GP automatically activates saving and announces it in the information window. Next The file is stored until the appropriate end label is accepted. This is how the resulting HD files do not contain other text, such as the Mailbox header. This function is activated (or deactivated) in the SETUP menu, closer to the Chapter 10. Since version 1.50, autosave has also been extended to Autobin mode, see 5.3.4. From version 1.60 onwards, it is also possible to use the Autosave function during Text saving turned on.

5.4 Copying text in the editor

Since version 1.20, there is an option to just receive text From the connection windows 1 to 10, copy it to the editor for further processing. For However, this feature is required by the mouse. To be able to copy to any editor text clipping, we need to cut it out (mark). To do this, press the initial line paragraphs and keep the mouse button pressed, do not let go and move the mouse up or down until all the required lines of text are marked with an inverse color. Then then release the mouse button and press Ctrl-Ins or Ctrl-K. editor some earlier text that is not saved on HD, the corresponding question. If we choose **Interruption**, then It does not copy the selected text into the editor. However, it remains marked. New marking on of the same channel deletes the old designation (color marking).

5.5 Remotely Controlled Operation

GP offers a variety of remote commands that it can execute connected counterstation. Each remote-controlled command must be preceded by two slashes so that the GP can recognize them. This can lead to a mistake when, for example, at the beginning of the new paragraph, there happens to be a sentence that begins with two slashes. This may be the case, in particular, when using Mailbox, if the author in his or her contributions from for some reason, he used remotely controlled commands. For this reason, it is advisable to connection to Mailbox remote control on the respective channel can be turned off or credited given Mailbox to the NAMES file. GP as type **B**. For **these** callers, GP blocks remote control during the connection automatically.

For commands that are used to manipulate files, they must be path specified in the configuration file. All users have the same priority and are thus allowed to use the same commands. For this reason, he should be elected directory other than the GP directory. Command to set the path in CONFIG. GP is **UserDir=road**. If GP is installed on a other HD, the path settings must be changed, because otherwise it is not possible to Use all of these commands. Remotely controlled commands can be executed by the user himself, when the result is sent to the counter station as if it had executed the command. That's what is done Esc key and in the window by entering a remote-controlled command. Attention should be paid to to enclose the command with two slashes (), to be recognized as remotely controlled (e.g. **ESC //h** broadcasts the full text of the Help to the counterstation), otherwise it may be interpreted as a TNC command.

5.6 External Programs

By remote **command RUN name of the program**, or **name program**, the counter station can start programs that are not in the basic GP equipment. There are two kinds of programs for GP from version 1.50 onwards. First, they can be existing programs (utilities) can be used, secondly, the so-called GPR can be used And programs. GPR I stands for Graphic Packet Remote Interface, and it's completely a new type of program. In relation to the existing programmes, GPR I programmes able to interact with the user. This gives us many more options use. At the same time, we can use GP quite normally, even if a GPR I is running program. Due to the structure of GPR I, the method of Multitasking is possible, that is, that multiple GPR I programs can run at the same time, but only one on each channel. More information about GPR I for programmers can be found in file GPRI.DOC, as examples for GPRI programming, it is possible to use the PASCAL sources supplied by the GPRI programs. Programs must be installed in a subdirectory that is in the CONFIG. GP declared by the **ExternalDir** command.

5.7 Splitscreen

If we want to additionally monitor the monitor during the QSO, we can ALT-F8 to split the screen into two halves. In the upper half we continue to connect (in QSO), in the lower one we watch the monitor. ALT-F9 and The ALT-F10 can be used to move the dividing line between the two halves. You can use the dividing line Right-click to turn it on or off. The size of the windows can be changed, If we move the mouse pointer over the double-arrow symbol on the dividing line and Move the mouse up or down with the left mouse button.

5.8 Scroll-Lock

On-screen printing can be stopped by pressing the SCROLL-LOCK. The ScrLock switch on the dividing line between the QSO and the monitor screen. This switch can be controlled with the mouse.

CAUTION: printing on the screen will remain blocked for so long, as long as the mode is in operation (Scroll-Lock indicator is lit, or if the switch is Scroll-lock pressed). If you forget the mode by pressing the key again cancel, a buffer overflow and an error occur.

5.9 TNC Commands

To change the TNC parameters, press the <ESC> when the window appears in which we write the command. By re- <ESC> close the window again without executing the command. Possibly modified TNC parameters initialized by **TNCINI** after they call the DOS shell using <ALT-O> will be rewritten configuration data.

5.10 Keeping a journal

On request, the GP automatically keeps a station logbook. To configuration file, just type **the Log=ON** command.

5.11 Miscellaneous Connectt Texts

GP offers the ability to create various connectt texts. By doing so, we can prepare different texts for different occasions easily and quickly switch. The standard text link is in the CTEXT file. GPI, alternative can be created by extending the file name by up to three letters, e.g. CTEXT_A.GPI CTEXT_01.GPI CTEXT_ABC. GPI, etc. When using the program more The user may experience a problem when alternative connectt texts exist only for one of the users. If the selected alternate link text is not found, A standard one is sent.

5.12 Sysop Function

For Sysops TheNet, BayCom and Flexnet as well as FALCon/DigiWare and password-compatible mailboxes offers GP automatic password generation. The password is automatically generated and written to the writing buffer, as soon as the **SY** or **PW** command is answered. In any case, MUST send at least **SYs** so that GP can Generate password. With Mailbox, the password is generated directly when logging in and can be copied to the writing buffer at any time (pre-write window) **via Ctrl-B**. For each node or box must be set up own file, which has the name of the machine caller and **the extension GPW**. If he has caller also SSID, must also be indicated (without a hyphen).

EXAMPLE:
*The file for DBOIZ-9 must be **DBOIZ9. WSE**. May contain only the actual text of the password, or in the case of flexnet one five-digit decimal number, and u box 60 lines of 27 characters each. In order for the password function to work, the station must also be in the NAMES file. GP, when the correct type data matters. Details see Chapter 9. BayCom nodes must be declared as **N**, because They use TheNet passwords. FALCon/DigiWare as **B**, because it is DieBox system was used. In later versions of DigiWare, the password system slightly modified, so the **W** type is already available in GP. Appropriate login command as a Sysop can be invoked up to when no more data is received from the machine, that is, when it has sent Last Prompt. Otherwise, the GP will not recognize the query and will not calculate any password.*

5.13 DieBox AutoBin Transfer

The DieBox system since version 1.9 offers the ability to load binary file using AutoBin mode to Mailbox or select it. The procedure is no different from the current method of uploading and reading the file. You just need to turn on the 7+ function AutoSave in GP and send a read command to the box. The rest goes automatically as with Selecting a 7+ file. In the box, you can recognize the file by the previous designation **(BIN)** in the title.

6 MailBox Usage Options

The following MailBox uses are based on the various BBS systems. Message lists can be obtained for Box using the **(C)HECK** or **(L)IST** command, for other BBS systems using various **(L)IST** commands. If you are not yet familiar with the operation of Mailbox, please read the helpful advice **Mailbox (H)ELP**.

6.1 BBS Menu

Mailboxes provide the ability to browse through all new records from the last Login (connection). Everyone responds in every Mailbox system a certain format. The GP has the ability to distinguish the corresponding lists from regular BBS systems. It recognizes:

- DieBox
- F6FBB (Version 5.15, but only with reservations)
- DK5SG BBS (DB0SAO)
- DB0IE

If the GP receives such a list, it will store it in its memory special buffer. This buffer is linked to the menu selector, so you can conveniently select the selected item to read. Tap to automatically transform on the read command and it is sent to the box. Then we can wait for the text. The list is deleted (cancelled) only if the user cancels the connection himself, for example using DISC. In case of Time out, Link failures, etc., the list is preserved and can be be reused when CONN is restored. However, it must be on the same channel! Because there is only ONE buffer, we can only use this function if the GP is connected WITH ONLY ONE MAILBOX, otherwise the entries of all Mailboxes would be written in one buffer and errors would inevitably occur. Here's how to use the function:

1. CONN Mailbox
2. Send the appropriate C(HECK) command to the box (read the instructions for the mailbox for information on the commands).
3. As soon as the overall list comes and the PROMPt is shown, we choose using ALT-F1 Check window, search for the message we want to read with the cursor key and select it with the SPACE key. To read the messages, enter ENTER and then just wait for the message to appear. This can be repeated at will. If you want to read only one piece of information, just hover the colored bar over that data and press ENTER. On request, the list can also be divided into individual sections, which makes it clearer, because we are mostly interested in only one of the section. If there is another list in the BBS Menu and the new list is accepted, the query old list is shown **Cancel Yes/No/Interrupt.** If we choose YES, then the old list will be cancelled and replaced by a new allowance. NO will add a new post to the old list. An interrupt interrupts the function and prevents a CHECK or LIST from being sent.

6.2 DieBox List Function

The LIST function basically has the same function as the CHECK function. However, this menu only works with Mailbox. Only one can be assigned to a list section. To use

this feature, it looks like this:

1. CONN Mailbox
2. Browse through the relevant section (read info about box commands)
3. Once the entire list is received and the PROMPt box appears, we select using the ALT-F2 LIST function, select the appropriate message to read with the cursor and mark with a spacebar. To read it, type ENTER and then just wait for the messages. This can be repeated at will. If you want to read only one message, just set color bar on this figure and press ENTER directly.

6.3 Find function

In the BBS menu as well as in the DieBox list function, we can For example, have callers searched. To do this, just press ALT-F or press using the mouse to enter the corresponding ICON and then type the search term into the box. As soon as it is the line with the search term found, GP marks it with a colored bar. A new assignment ALT-F and confirming the new term with ENTER the search continues to the current cursor position. However, if a new search term is entered, GP always starts the search from the beginning of the list, regardless of the position of the colored bar.

6.4 Problems in recognizing the list

Unfortunately, there are always problems with recognizing mail list. This usually happens as soon as a new version of Mailbox is installed software. With FBB BBS, it occurred to me that the format of the list is directly dependent on the the language you set. If there are any problems while evaluating the list, please write to me please send a short message (Mail) and with it send a cut-out of the list so that I can GP on customize it.

With Baycom Box, the format of the list can be customized according to of their own wishes. With the standard settings, the DieBox is compatible and the list is GP program without any problems. Perhaps other preset formats also work. We will find out when we try it.

6.5 Importing a list from the editor

In the BBS Menu and List Window settings, there is a version 1.60 one function with which we can import a list from the editor to the BBS Menu, or to the list window. To do this, you need to upload a file that contains the corresponding CHECK list, in the editor and select in the BBS Menu (or function window) **to paste from the editor**. Found posts in the editor will be attached to any existing ones posts. If we want to cancel old posts, we have to do it manually by invoking ALT-F4 function. New functions for changing the reference channel or rubric should be should have been clear.

7 GP Editor

This small editor is a simple tool to process short texts such as configuration or NEWS information files. GPI or CTEXT. GPI. It does not offer any special comfort to the operator, but they are still there All essential functions available. The main advantage is the ability to edit some text without leaving the GP program. The size of its memory can be set in configuration file according to your own wishes. There are 80 characters per line. The minimum is 40 lines, maximum 780 lines (about 64kB). The editor can work in two modes. **Slide** mode moves everything to the right of the cursor to the right, and the character **is inserted** into the vacated space. Optically, this mode is **made visible** by the half cursor, while in **the overwrite** mode, the cursor is whole. Both modes are switched by the INSERT key.

When using the GP editor, you need to distinguish between **a text** line and **an on-screen** line. A screen line can be up to 80 characters long, and contains those characters that we see on the screen, while the text line can be consist of several screen lines and is what you can do after uploading a appears on a single line. GP editor is capable of processing text lines with up to 255 characters. However, these will be divided into several screen lines of 80 characters each. If you save more than 80 characters per line, they will be ignored. The length of the text Line can be edited in the menu by setting the line break. To edit text, press ALT-L key, and then type a name for the file. To record a file that you have on floppy/HD is not there yet, also simply press ALT-L, specify the name of the new file and answer YES to the question of whether the file should be saved.

8 List of MH (ALT-H)

GP maintains an internal MH list that contains a list of 40 last heard stations. This is sent to the remote-controlled **with the MHeard** command. The MH list contains information from the monitor channel and continuously captures the latest status if the monitor is turned on (Monitor TNC must not be **N**). MH offers a list the ability to test whether the listened to calls are already entered in the file NAMES. GP. Just hover over the call sign with the inverse line and press **ENTER**. It can also be done with the mouse, the function is the same as for **the BBS menu**.

9 QSO Spy

From version 1.50 onwards, GP offers the ability to read selectively individual connections of other stations on the channel. The relevant data shall be recorded in the own window. Up to 10 foreign connections can be eavesdropped on in this way, if there are enough memory space for text buffers in SPY windows. The size of the text buffer can be set in the configuration file using **the Spybuffer** command, the maximum The number of spy windows then using **MaxSpy**.

9.1 Invoking a Joint Reading Connection

If we want to subtract a foreign connection, we switch first to the MH list. Next, either click on the **SPY** icon with the mouse or press ALT-S. A prompt will appear in the window PLEASE SELECT QSO. Now we can select the appropriate QSO connection

from the MH list by hover over the colored line and press ENTER or use the mouse. Next the question of whether we want to save the QSO. If we answer YES, we can enter the next insertion window to enter the name under which the monitored connection will be saved to the HD file. GP will offer some standard name. To use it, just press ENTER. Then the GP jumps into the window in which the recorded QSO takes place. Terminate a QSO spy we can either press ALT-K in the temporary window or tap the **Kill Spy** icon. QSO can be removed from the MH list also by pressing ALT-K or tapping on the **Kill Spy** icon and then choosing the desired QSO.

If the MH list also includes the opposite direction of the selected QSO, this is also automatically marked and the spy window naturally shows data of both directions (in different colors). If there is no opposite direction when the QSO is activated the spy can be heard, it is not in the MH list and the GP writes and marks only one direction. Is it hear the opposite direction at a later time indication, it can be subsequently called to reading together. In this case, the GP automatically recognizes that they are together read the second half of the QSO and the spy does not open a new window, but assigns it to the to the existing window.

9.2 Spy window

This window shows the transmitted data of the listened connection QSO. If both directions are heard, the GP will recognize it automatically and in the window It marks both directions with different colors. Which caller will be marked with which color depends on which direction was chosen from the MH list.

EXAMPLE:
*We have chosen in MH-list QSO **DB0SG - DH1DAE,** then DB0SGL data in foreground color and DH1DAE data in color appear in the spy window **inverse (SpyInverseAttr**). On the one hand, a QSO will appear in the status window, which is read in this window and the number of the last read AX.25 packet. IN AX.25 protocol, packets are numbered so that in the event of a transmission error, the given erroneous packet was repeated. The numbering is done in the interval 0 to 7 (from this Maxframe parameter in TNC can also be only a maximum of 7). Numbering naturally, it always refers to only one direction.*

9.3 Automatic QSO Spy

From version 1.60 onwards, GP can be set to automatically save to HD certain QSO connections. These are automatically stored in memory in the SPY list. A new file is created for each QSO. His name is generated from the call card with a sequential suffix of 000 to 999, e.g. **DH1DAE.000**. If the Info frame of a station is captured to be automatically spied on, a new QSO spy is automatically started if there is one. QSO connection is then stored in HD until a DISC, DM- or UA- packet is received station or its counterpart. In that case, the QSO spy will be replaced again closes automatically and the window is available for a new QSO connection.

Which QSOs should be automatically spied on, we can set using **the AutoSpy** and **NoAutoSpy commands** in the CONFIG file. GP. With **the AutoSpy** parameter, we

ensure which callers those calls that should not be there should be automatically saved by **the NoAutoSpy** parameter. Under NoAutoSpy should be in any case the custom caller is listed, because it doesn't make much sense to record your own QSO. U Up to 10 data can be defined for both parameters, which need to be separated by a comma. At the same time, it does not have to be directly callers, but it can be any section from the Monitor window. Experiments in the development of this feature have shown that it is practical Search criteria to choose the keywords **FM** and **to**. It is absolutely necessary to Follow the uppercase and lowercase letters as well as the position of the space character!

ATTENTION! In the normal course they are stored on HD as normal QSO as well as UI packets (that is, beacons or Flexnet search). In the UI package but there are no DISC packets, so the QSO spy will open but never close again. Therefore, it is a good idea to specify the **CTL UI** keyword to **the NoAutoSpy** parameter (see example).

Example 1 - we have to record all connections between DB0SGL and DB0FN, but no QSOs that take place with DH1DAE:
AutoSpy = fm DB0SGL, fm DB0FN
NoAutoSpy = DH1DAE

Example 2 - we have to record all the connections that will be with any DB0 station, but no QSO with DH1DAE or UI packets:
AutoSpy = fm DB0
NoAutoSpy = DH1DAE, ctl UI

Example 3 – we have to record a QSO between DB0SGL and DB0FN, however, only a connection from DB0FN without SSID, not QSO DB0FN-1, DB0FN-2 to DB0FN-15:
AutoSpy = DB0FN, DB0SGL
space after the word DB0FN is important because this will only make GP respond to frames from DB0FN without SSID

Recommended when using automatic QSO spies regularly Delete the generated files, otherwise it is easy to lose the overview. But he recommends use it if it saves you from searching or downloading data in Mailbox, for example.

NOTE: 7+ files can also be processed from SPY files without problems using the 7+ program (naturally, if there were no errors in the the audibility of the station). Those who do not know, should study the documentation to the 7+ program. It offers some interesting features...

9.4 Possible problems

QSO spy works without problems only when we hear the given station (or node) perfectly and every packet. If we can't always properly build our object accept, it may be the case that some part of the connection is missing in the spy window, or are displayed in the wrong order.

10 Autorouter

Autorouter helps us connect known stations without having to enter the complete path or manually work through the nodes. The prerequisite is However, the road to the station in question is known, still operational and that it has been recorded in the NAMES file. GP. The lines in the file always have the following syntax:

TYPE>CALL NAME; PFAD

or

TYPE>IDENT:CALL NAME; PFAD

It is important to enter the TYPE correctly, because according to it, the GP will recognize which actions should be performed and which should not. Thus, the CHECK and LIST functions can be used only for the mailbox, while the message can be sent only to those channels using the **remotely controlled n Text** command, that are connected to another end station. The station name may contain and can theoretically be arbitrarily long, but in the program It works only with the first 22 letters. The call card and TYPE data must be capitalized in letters, see the examples below. If the station in question can be reached directly without nodes, then the path is omitted, otherwise it must contain all the necessary nodes after way.

IMPORTANT: The last entry must in any case ALWAYS TYPE>CALL syntax and must not contain any IDENT! A type can contain the following letters:

B	Mailbox (e.g.: B>DB0SGL)
D	L2 nodes (e.g.: D>DB0ID)
F	Flexnet node (e.g.: F>DB0FN)
N	NetRom node (e.g.: N>DB0EAM)
!	as N, here you need to use **the C command!**
T	Terminal, end station (e.g.: T>DH1DAE)

If the final station is also used as a digipeater, then GP automatically generates the appropriate Remote command, i.e. **C to** . By type of designation shall be recognised by the GP as to how it must connect individual stations. The path input looks something like this:

T>DH1DAE Ulf; D>DB0NWS D>DB0FN T>DH1DAE
*In this case, the GP sends **the command C to TNC DH1DAE DB0NWS DB0FN.***

However, if there is another N> or F> node in the path, e.g.:

T>DH1DAE Ulf; N>DB0HSK F>DB0DOZ D>DB0FN T>DH1DAE
*then the connection looks a little different. Now the DB0HSK node will be connected first, then the **C DB0DOZ** command will be sent, and then the **C DH1DAE DB0FN** command will be sent.*

The following example demonstrates the use of the **!** type:

T>DF3VI Patrick; D>DB0FN-9 !>DB0II !>ON5PL !>ON5ZS F>LX0PAC D>DB0HOM
GP generates only the following konnekt sequence: ***C DB0II DB0FN, C! ON5PL, C! ON5ZS, C! LX0PAC, C DF3VI DB0HOM***

For example, an ident can look like this:

F>SIEGEN:DB0FN Digi Siegen
T>ULF:DH1DAE Ulf; D>SIEGEN T>DH1DAE

We can only set ***DH1DAE*** *or* ***ULF*** *and GP generates the link command:* ***C DH1DAE DB0FN****.*

10.1 Recursive path notations

The list of stations does not have to include the complete path to the specific station, but it can be based on other already known routes.

For example:

F>DB0FN Digi Siegen
F>DB0WST Netzknoten West; F>DB0FN F>DB0WST
F>DB0ME Digi Solingen; F>DB0WST F>DB0ME
B>DB0SGL Mailbox Siegen; F>DB0FN B>DB0SGL
B>DB0IZ Mailbox Solingen; F>DB0ME B>DB0IZ

The full path to DB0IZ is compiled from e.g. the path to DB0ME and to DB0WST. This automatically gives the following path when connecting:

F>DB0FN F>DB0WST F>DB0ME B>DB0IZ

There are two advantages to using recursive path notation:

1. We need to tap less
2. The list of paths becomes more variable if a certain Digi drops out or when a new line is created, just change the notation of one path.

10.2 Autorouting via SP gateway

If a line is used in a path via the SP gateway, when the port number must be given after the caller, it can be achieved simple trick, through the Dummy node.

Example:
DL9ZZZ is an SP gateway that is on Port 0 on 70 cm and Port 1 on the 2m band. The station is on a 2m band and wants to connect the DB0XYZ on the 70 cm band. The relevant command of the connect would therefore have to ***Sound C DB0XYZ-0****.*

Write a line in the NAMES file. The GP then looks like this:

N>DB0XYZ Testdigi; T>DL9ZZZ D>0 N>DB0XYZ

*GP connects first DL9ZZZ and sends **the command C DB0XYZ-0** (if DL9ZZZ has configured its Gateway as a Node, we can also write **N>DL9ZZZ>DL9ZZZ)** instead of **TDL9ZZZ**). This trick can be used not only for the SP gateway, but also, for example, for the Baycom node, if it must be specified there some port number.*

10.3 A Few Notes on AUTOROUTER

As you have already noticed, AUTOROUTER evaluates the relevant message link to communicate the actual end nodes. From a purely technical point of view, it is like this the AUTOROUTE method is quite nonsensical, but with the current Packet network it works differently is not possible. In any case, better ROUTED will be taken over from Flexnet Digipeatru and For this reason, this ROUTING should be used as much as possible. When Flexnet Digipeater can be notified which digi may be available via Flexnet Autorouting. The command by which such a list can be invoked is **D**.

10.4 Managing QRG (TNC Multiport Only)

Since version 1.50, GP can manage multiple ports (not TNC). For example, more ports are offered by the Baycom USCC card in conjunction with TFPCX from version 2.00 or modern TNC such as FALCon or TNC 3. In order for the GP to know which port to connect to, or on which port a connection (QSO) is running, we need to tell it on which port is what node and on which frequency it is located. To do this, use the PORTx command, where **x** is a number between 0 and 8. The syntax for this command is:

PORTx = <digi>, <qrg>

Example:
I'm using DB0FN as nod. It operates at a frequency of 430.625 MHz and the transmitter is connected to Port 0.

Then the relevant record reads:

PORT0 = DB0FN, 430.625

IMPORTANT: Multiple frequencies can be allocated per port, but not the other way around. GP always automatically takes the first port record that belongs to for the selected frequency. If more ports were assigned to one, we would have to frequency data can be entered differently, e.g. by using "**,** " instead of "**.**" as a separation between MHz and kHz data. But because it doesn't have to be in the station diary the exact frequency and only the band is enough, there are other options to resolution. If a node with two different SSIDs operates on one frequency, e.g. since it works with both 1200Bd and 9600Bd, then we also have to assign it Port record.

Example:
DB0FN broadcasts to QRG 430,625 with 1200Bd and with 9600Bd. On port 0 is

connected a modem with 1200Bd and on Port 3 is connected to the modem with the 9600Bd.

If we want to work with both speeds, we need to integrate into the NAMES file. GP as follows:

PORT0 = DB0FN, 430.625
PORT3 = DB0FN-9, 430, 625
comma instead of dot is intentional

If we want to start a connection on a 9k6 port, we need to specify QRG **430, 625**, on the other hand, if we want to work through a 1K2 port, we need to specify a QRG **of 430.625**. In fact, this should rarely occur, because who would want to work on a 1K2 port when it can also use 9K6?! When using multiport TNC Port recording is absolutely necessary. Otherwise, the attempt to connect via unknown will end frequency by erroneous reporting. Port Logging Is Not Required If Multiport TNC we do not use it.

10.5 Frequency-dependent conditions of the autoconnect

If we have more nodes within range and therefore change the input more often to the network, we usually also have to change some data in NAMES. GP and customize them to the current node. So that we don't have to do it manually, we can from version 1.50 to NAMES. GP to build in frequency-dependent IF conditions. The way it works is in the principle is the same as for IF conditions in CONFIG. GP, only the decisive figure is here QRG frequency. The use is simple and can best be explained with an example:

I have the ability to work both through DB0FN and DB0NWS.
Then the NAMES file can. GP should look like this:

PORT0 = DB0FN, 430.625
PORT1 = DB0NWS, 433.775
<IF 430.625>
B>DB0SGL Mailbox Siegen; D>DB0FN B>DB0SGL
F>DB0ME FALCon-Digi Solingen; D>DB0FN F>DB0ME
<END>
<IF 433.775>
B>DB0SGL Mailbox Siegen; D>DB0NWS B>DB0SGL
F>DB0ME FALCon-Digi Solingen; D>DB0NWS F>DB0ME
<END>
T>DG9EP Walter; F>DB0ME T>DG9EP
B>DB0IZ Mailbox Solingen; F>DB0ME B>DB0IZ

If we work only through DB0FN, the path to DG9EP looks like e.g. as follows:

D>DB0FN F>DB0ME T>DG9EP

If, on the other hand, we work through DB0NWS, the path changes automatically to:

D>DB0NWS F>DB0ME T>DG9EP

If we use hierarchical lists (as in the example above) paths, they do not have to be all dependent on one IF condition, but only parts of them, which changes by changing the node used. In the example above, for example, the path from DB0ME always the same, so it is necessary to change the path only to DB0ME, but not the path, that lead from DB0ME onwards.

10.6 Macro %DIGI%

This macro is interesting only in multiport operation. Program GP replaces it when finding a way through the node callers that are assigned the currently active port. If we use the Autorouter node, it makes it much easier to Build a list of paths.

For example:

PORT0 = DB0FN, 430.625
PORT1 = DB0NWS, 433.775
B>DB0SGL Mailbox Siegen; D>%DIGI% B>DB0SGL
F>DB0ME FALCon-Digi Solingen; D>%DIGI% F>DB0ME
T>DG9EP Walter; F>DB0ME T>DG9EP
B>DB0IZ Mailbox Solingen; F>DB0ME B>DB0IZ

This example corresponds to function of the example given in Chapter 10.5. By using this Macro, you can In this case, the IF pointers are deleted.

10.7 Registering callers in the list during the connection (ALT-N)

If we want to take over to NAMES. GP station just connected, We can do this by editing this file. But it can be done more simply, if we press ALT-N and insert the name of the station. GP then stores the station in memory to the end of the NAMES file. GP. In this way, they can be done very easily construct hierarchical paths as we connect from node to node and each time we use the ALT-N function. However, I can only recommend this method at TheNet compatible nodes, because FlexNet autorouting compatible nodes generally works better than the path list in NAMES. GP.

11 Setup Function (ALT-U)

GP offers the possibility to change some of the program functions during operation parameters. These include, for example, setting the color or activating or deactivating remote control for QSO channel, etc. Individual menu items can be selected either by the cursor key and ENTER, or by double-pressing the left mouse button. When ending GP using ALT-X, all settings of this menu are saved to a file CSTAT. GPB and at the next start, GP will read these values again. For each channel there is a custom setup that is not as extensive as with the Mailbox list, editor, MH list, or monitor

11.1 Changing Colors

After selecting the appropriate menu, you can change the colors. Selection window It offers three options and can be made with the left or right arrow buttons. The matching colors are presented in a small window. If we choose a color according to If desired, confirm the change in the menu by pressing **ENTER**. Color selection can be made at any time interrupt using **ESC**. If you want the new color setting to be ready for next use, you need to change the settings in the CONFIG file as well. GP.

11.2 Remote-controlled prompt

This menu item determines the shape of the prompt that is emitted after execution remotely controlled command to the counterstation. However, the prompt will only be sent if there is activated via the remotely controlled **PRompt ON** command. Prompt can contain all macros that are also used in files *GPI. This applies to all QSO channels.

11.3 Remote Control On/Off

Remote Menu Item **The control** shows the current state of remote control. To turn on or off remote control, just tap the mouse on this point or press ENTER. This The setting applies only to the current channel.

11.4 Inserting a Text Buffer

This menu item is used to disable **the BACKUP** function, which the current content of the Scroll buffer screen when leaving GP is saved to HD and when new restart. Compared to other setting data, this value is not stored on HD, but when GP restarts, it is read from the CONFIG file. GP.

11.5 Echo

This menu item turns local Echo on or off. When ON is in the the text I broadcast will also be shown on the screen of the current channel. If set OFF, the text is suppressed during transmission and only the text received from the counterstations. This setting applies only to the current channel.

11.6 RX Zigzag

The name RX klick is an acoustic signal that alerts you to the text being received. This parameter It can have 3 values:

- **0** - the acoustic signal is always disconnected
- **1** - if text is received on any port other than the selected one (channel), an acoustic signal sounds. However, if text is broadcast on the currently activated channel, no signal will be heard.
- **2** - An acoustic signal is always heard when text is received on the any channel.

This status applies to all channels.

11.7 Line break

This parameter specifies the maximum number of characters per line. When converse mode, for example, this value should be set to 65, otherwise by default to 80 characters per line. This setting applies only to the currently selected channel.

11.8 Packet Length

Specifies the maximum number of characters per AX.25 package. For example, if we have a relatively bad connection to a node, it should not be This value is too high, because with short packets, the chance of a flawless transmission higher than with long ones. But the value should not be too small either, Because then we need many packets to forward the message. This setting applies to all QSO channels.

11.9 Softscroll

Toggles the Softscroll function. For more details, see Chapter 14. The setting applies to all channels.

11.10 Code AutoSave

Turns AutoSave on and off for 7plus and LCplus file. This setting applies separately to each QSO channel. For more information, see 5.3.5.

11.11 Lighthouse Menu

This menu item can only be found in the monitor window. Controls Beacon broadcasting. It can be specified which beacon text is to be broadcast and at what destination address to be sent. It can also be through a node. This must be entered corresponding in the destination address. The **Periode** menu item does not need to be mentioned. An example is given in the original text.

IMPORTANT: not to unnecessarily burden the nodes and frequencies, The beacon function should be turned on only in special cases, e.g. when we on the portable. As a rule, we do not need a beacon.

Example: As the beacon text,
*we want to have **DH1DAE/p in Siegen** and as destination address **ALL.***

If we insert a period of 5 minutes, the GP broadcasts every 5 minutes following:

fm DH1DAE to ALL ctl UI^ pid F0
DH1DAE/p in Siegen

If we insert that the destination address is **ALL DB0FN,** we will see the following:

fm DH1DAE to ALL via DB0FN ctl UI^ pid F0
DH1DAE/p in Siegen
fm DH1DAE to ALL via DB0FN* ctl UI^ pid F0
DH1DAE/p in Siegen

11.12 Dividing Line Between QSO Window and Monitor Window

For individual functions that could be used more often, there are additionally switches in the Setup menu, which can be switched on using the mouse or turned off. The switch symbols are usually clear enough, so only Short explanation:

QRG: xxxxxxx	Frequency reported in the logbook
CT: xxxxxxxx	Text connection option (see 5.11)
[->ü	German umlauts on/off
Echo	Echo on/off (see 10.5)
<stairs>/<line>	Softscroll on/off
<Note>	Beep (Ctrl-G) on/off
7+	7plus autosave on/off (see 5.3.5)
Remote	Remote control on/off
BIN-RX	AutoBin saving to an on/off file
BIN-TX	AutoBin broadcast on/off
ScrLock	Holds a TNC query on an existing channel. Compared to earlier GP versions, where this switch was applied to all channels at the same time, now only to the existing channel. Therefore, this function must be turned off. If the channel is held in this way, the current caller is in the list menu shown by the cursor.

12 DOS Shell

Invoking this function allows us to enter DOS commands without we would have to end the GP. If we want to return to GP, we need to give the **EXIT** command and confirm with the **Enter** key. In the **CONFIG. GP**, the **command TNCDOS = M N** should appear, which stops the monitor from listing, otherwise there is a danger, that TNC will overflow with unclaimed monitored information. In addition, if we turn off **the M N** monitoring, we lose the possibility of using a QSO spy.

13 Using the Mouse

If a mouse is connected to the PC and the driver is loaded, GP It automatically recognizes and allows you to select all icons and menus with the mouse. The mouse operation is quite simple. When selecting a menu icon or function, hover over the

object and press and release the left mouse button again. If we accidentally selected another object, then move the pointer while pressing the icon or window in the menu and then release the button. It works the same way mouse in the CHECK and LIST menu. If we accidentally pressed the left mouse button, then while the button is pressed, hover over the SCROLL bar and only then release the button. In these menus, in addition to the left mouse button, the right button also has its function. It works when pressed in the same way as **the SPACE spacebar**, which you can use to tag different records. But the best thing is to try out all the features of the mouse themselves.

13.1 Scroll Bar (ScrollLock)

For all text windows, you can see on their right side scroll bar, showing the current screen viewport in relation to the entire scroll buffer. You can use your mouse to scroll up or down rows or pages. To scroll in a row, just press both arrows. On the other hand, if you want to scroll full page, you must press the cyan-colored bar below or above the position stripe. To display any section of the screen, you can press the positional bar and move to the desired position while pressing the mouse button. Scrolling The bar can also be deleted to get 80 columns. This is done using a combination of ALT-B keys, or click **B** of the scroll bar.

14 Command Line Parameters

GP allows you to change command-line parameters that affect start of the program. The call is carried out as follows:

gp <parameter1> <parameter2>

or

gp286 <parameter1> <parameter2>

14.1 /e and /v parameters

This parameter turns on EGA or VGA mode without noticing settings in the CONFIG file. GP.

gp /e

or

GP286 /E

switches GP to EGA mode (640x350).

gp /v

or

GP286 /V

switches GP to VGA mode (640x480)

14.2 Parameter /h

With this parameter, GP can be started without initialization Guest mode. However, the TNC must already be in guest mode, otherwise interruption of the program. However, GP does not need these parameters for normal operation, because it knows if the TNC is already in guest mode or not.

14.3 /NOXMS and /NOEMS parameters

GP recognizes completely automatically whether there is XMS memory in the PC or EMS and directs the receiving buffers and other data there to save space of normal DOS lower memory. If there are any problems, the GP may specify that it does not use any additional memory, even if it is present in the PC. Problems may occur e.g. when using XMS (HIMEM.SYS) if the TFPCX. On slower computers, using GP on XMS, TFPCX may experience income problems and the operation of PR will thus become much more difficult. In this case, it is better XMS by invoking the /NOXMS parameter. The /NOEMS parameter similarly prevents use of EMS memory.

14.4 Parameters of /XTBO and /ATKBO

These parameters are considered in case it does not work Automatic keyboard recognition. To use the F11 and F12 function keys, GP must use special BIOS functions, which e.g. on XT computers They do not exist and this leads to problems. In normal cases, GP recognizes the keyboard immediately, but there may still be problems, because the PCs are not completely compatible. If there is a problem in the overwriting window, they keep appearing some characters without any key pressed, then it's good to enter the GP **parameter /XTKBD**. If you have keyboard with F11, F12, but GP does not respond to them in any way, try to enter **the /ATKBD** parameter.

14.5 /3MOUSE Parameter

GP normally only supports left and right mouse button. However, if we have a mouse with three buttons, then the middle button corresponds to the ALT-Z function. However, in this case, we must inform the GP that we are connected a three-button mouse by entering **the /3MOUSE parameter**.

14.6 /NOFIFO Parameter

Since version 1.50, GP also supports UART 16550, which has inside 16 byte data buffer <FIFO>. This allows for greater transmission speed without character loss (no

interruptions). Even on the 286, it is possible to transmit up to 115200 baud, but provided that you use corresponding TNC <FALCon or TNC3 >. GP will automatically recognize if there is a initialized 16550A, or whether the UART used is a common type. The **/NOFIFO** parameter can be used to do the following automatic recognition can be turned off and thus the GP will not activate FIFO.

14.7 /CHECK Parameter

With this command, the GP is instructed to look at the some change to your code. If he has found one, he stops searching and announces the find. V In this case, immediately scan your computer for the possible presence of a virus. Computer on Turn off for a while, wait and turn it back on. Now insert the floppy disk with the antivirus program. You can then scan HD for viruses and remove viruses. In the In any case, prepare a virus-free floppy disk in advance, which you should secure write protection. Viruses always appear when you least expect them.

14.8 /KISSOFF Parameter

This command instructs the computer to Kiss mode was turned on, turned it off at startup.

15 Softscroll

The peculiarity of GP is that it allows you to switch between **normal** and **slow** scrolling. Softscroll **slow** means that the total text on the screen will not scroll by one text line, i.e. 8 or 16 graphic line, but by 4 or 8 times two graphic lines up. This produces an **effect slow scrolling**, which makes it easier to read text. However, this slow scrolling also has its drawback, that the ratio of scrolling speeds It is too small for the section of the screen that needs to be scrolled. This loss speed is generated by an enormous amount of data, which on a screen of 80x40 characters (for capital letters 80x20 characters) in any case represents 102400 bytes. This The amount of memory slots is required for one row 4 times for slow scrolling shift, i.e. Softscroll of one line of lowercase characters must be shifted by 409600, with a line of large characters even by 819200 characters. In this case, only A faster computer. The 80386 is not bad either. Nevertheless, it happens that in the case of a large TNC monitoring is not enough and the memory overflows. That's why I recommend that Softscroll has only been used in conjunction with the use of a reduced window, as this a significant decrease in the amount of processed text.

Unfortunately, most VGA cards that are programmed mainly hardware, malfunctions occur when activating Softcsroll, because there is no One hundred percent compatibility with the VGA standard is guaranteed. Problems arise especially with SVGA cards. If a malfunction occurred in which the screen was deleted, you can fix this by jumping into DOS Shell for a while and then with EXIT you will return to GP. In order to shut down Softscroll, it is necessary to immediately Start the screen, press ALT-U to start the Setup menu.

16 What is HOST mode on TNC2

I'm sure you've wondered what the HOST mode is when you talk about it operation of some terminal programs? HOST mode is a type of operation on TNC2, in which the data exchange between the computer and the TNC is a little different. In this Terminal program works as **HOST** and TNC **as a SLAVE**, which means that the TNC does not send a program until it gives the command to do so. This ensures that data will always reach the correct terminal channel. In practice, the terminal the program sends a query to all TNC channels if there are any on the given channel data or not. If so, TNC sends the data to the terminal program. Traffic slows down a bit because the GP is not able to recognize which channel the data is on is currently being accepted and therefore has to question everyone. It takes a little longer to The data will appear on the screen. If an error occurs in this process, the GP will recognize it immediately and tries to bring TNC to a defined state. The user is told this as Synchronization error. However, it cannot be repaired, so data loss may also occur.

However, the HOST mode must not be confused with the AX.25 protocol. TNC's in fact, it converts the cache that receives data according to the AX.25 protocol into another format and caches it until the terminal program He won't say. The opposite is true for broadcasting, where PC data is broadcast to TNC, where they are cached and converted to the AX.25 protocol. Per repetition count (Retries) for the packet to reach the destination without errors, the terminal program does not have no influence. The maximum you can ask for **is LINK** information and that's it.

HOST mode has been compiled for **INTELLIGENT** terminal programs that are able to provide **MULTIKONNET.** For **a normal** terminal program, inappropriate. Unfortunately, not every TNC has a built-in HOST mode, e.g. TAPR. WA8DED only software and The Firmware <Nord><Link> have it. That's also the reason, why programs like GP, SP, THP, and the like only work with these TNCs. In addition, there are also additional programs that replace TNC or allow the use of other TNC instead of The Firmware. Such is, for example, the TFPCR from DL1MEN, representing KISS HOST interface enabling TAPR operation. Another such program is TFPCX from DG0FT, replacing even the entire TNC, requiring only a very small modem between the TRX and the PC.

17 Synchronization Errors

Synchronization errors occur when the GP and the TNC is the loss or distortion of characters. In this case, the GP tries to bring TNC to the default state, so that the further operation of the information runs without defects, if the GP cannot synchronize with TNC, it will end the activity and go to DOS. But it can happen that TNC, for example, as a result of a short network outage, fell apart and GP does not have the TNC option synchronize. In such a case, an **emergency brake** was installed, which The resynchronization procedure is interrupted and the screen prints a menu that will allow you to decide on the further course of the GP. This is possible perform RESYNC ERRORS during RESYNC ERRORS by using Ctrl-BREAK. We can bring the decayed TNC bring TNC REINIT back to life by calling TNC REINIT from the menu without having to

exit the GP. Of course, we still have to reset the TNC before and wait a while. If the On the first try, a malfunction message appeared, please try again. TNC after reset He always needs some time to recover. Another option is simply TNC ignore, but in that case no more exchange of information between GP and TNC will fail.

If you use TFPCX or TFPCR, none of the resynchronization errors may occur at all. If they do occur, they should we would delete them because they always represent data loss. We usually have luckily in that a resynchronization error occurs when querying for LINK status, but this can also happen when TNC queries QSO connection data. In such a In this case, the data will neither appear on the screen nor be stored in memory, and so on they are lost. We can solve this problem by reducing the number of Bauds V24 or we will use 16550A UART. But often it is enough to discard it from memory programs such as disk cache or slow drivers, or replace them with others.

18 Several types

Finally, a few types for using the GP program.

To connect to Mailbox, it is recommended to use a channel with if possibly with a large text buffer. Because we can't set up for all channels large text buffers relative to the memory space of the PC, we should as a channel For mailbox, for example, choose the last channel (e.g. channel 4 with a maximum of four channels) and equip this with a large text buffer. The last channel can be connected only when all other channels are already connected to the occupied. This ensures that we can connect one Mailbox and Mailbox at any time. when we were already connected by other stations. Another reason for Such a procedure is remote control. This can be turned on and off for each channel separately and independently - the current state is stored in the memory. With Mailbox, the remote control should be disconnected in any case, because in the texts there may be commands for the remote control, on which the GP reacts and then there are erroneous boxing reports or something worse. It is Good so that the remote control is activated during normal connections. In order to they still didn't have to turn the remote control on and off when they were running on one channel QSO connection and Mailbox operation, it is practical when for Mailboxes uses a special last channel on which there will never be any QSO. When e.g. we use channel 4 for Mailbox, just turn off the remote control for the first time and then We don't have to worry about anything anymore.

Testmode: If we want to start GP without TNC (to be tested and so on), we can do so by adding **the /h** parameter (see 14.2). If GP then reports an error in synchronization, we can interrupt the count using Ctrl-Break and then choose **TNC to ignore**. However, no connection is possible in this mode QSO, only the editor remains usable.

Of course, this trick is eliminated when we use TFPCX or TFPCR. If the **TNC message does not respond** appears at the start of the GP, there is nothing fine in communication between PC and TNC. This can have several causes:

- serial port number in CONFIG. GP disagrees
- speed of communication in CONFIG. GP was not given correctly
- the serial port IRQ setting was not in CONFIG. GP correctly entered
- V24 line to TNC is broken or not properly wired
- TNC has collapsed. In this case, only a TNC reset will help
- There is no built-in software with WA8DED hostmode in TNC. Examples that's why Multimode TNCs like KAM, PK 232, etc. With these TNCs, GPs run only in connection with the Hostmode TFPCR program from DL1MEN.

If you suspect that malfunctions are occurring when using TFPCX reception, you can check this by specifying **the TFPCX -d** parameter. From the speaker A PC will sound a tone by which you can estimate the quality of TFPCX reception. If the tone sounds relatively clear, it should not be No difficulty in receiving them. If you hear a distinct crackling sound on the tone, or even its interruption is a problem in some memory driver. Problems can be caused by cause e.g. HIMEM.SYS. In this case, run GP with **the /NOXMS** parameter (See 14.3). The TFPCX driver can be terminated with **the TFPCX -u** command.

XMS: From version 1.50 onwards, GP requires more XMS trades than how much HIMEN.SYS normally provides. Therefore, when using XMS, you can GP cannot fully use the XMS memory because there are no more free available trades. Therefore, it is a good idea to install HIMEM.SYS as follows:

DEVICE = HIMEM.SYS /NUMHANDLES=64

Appendix A

1 License Law

GP may be used or disseminated only in accordance with General Terms and Conditions for the Use of Amateur Software (ALAS), as well as conditions compiled in 1992:

Copyright © 1992 Hans Georg Giese, DF2AU
Hinter dem Berge 5
D-3300 Braunschweig

This document may be freely distributed or reproduced if it will not be altered. Thank you for the changes leading to its improvement. (DF2AU @ DK0MAV.DL.EU)

1.1 Preface

This license is derived from the General Public License of Free Software Foundation (GPL). I have tried, while preserving its meaning, to bring into it greater clarity. Some of its passages have completely fallen away. However, every user has the right to use the terms of the GPL in place of this license. The purpose of this license is to protect both the author and the user of this software. Therefore, there are certain limitations

and thus in fact, also obligations to the person who changes and distributes the software associated with this license. This is achieved by the fact that this software is protected by Copyright and therefore the user This license has almost unlimited possibilities in its use.

1.2 Scope of Validity

This license applies to each program or part of the flowing from him. In the following, the term PROGRAM will be considered this program or parts of the flowing from him. You are then the user of the license.

1.3 Your rights:

You can use, copy, split or change the program if you By doing so, you are not pursuing any commercial goals.

1.4 Your obligations:

1.4.1 You may not copyright or link to this license under any circumstances change and it must be clear to the user every time this program is started. indicated.

1.4.2 You must also grant the rights that have been transferred to you to the person to whom you pass this PRG on. Likewise, demand obligations and comply with them.

1.4.3 You may not demand any compensation for the transfer of the PRG to another user. remuneration, except for the cost of media and postage.

1.4.4 You may only submit the complete program as you received it you. (Note DH1DAE 1:1 copy of the original floppy disk!)

1.4.5 If you change the program or use parts of it for your work, whether in a literal or modified wording, then the newly created program is subject to the following points:

- You must state clearly enough: your name and address, the fact that you have modified the program or used some parts of it.
- You must then pass on the program either with full indication of the origin or each may be asked to send the original text only for the payment of the costs of the medium and postage.

- You must not place any restrictions that go beyond the scope of this license.

1.5 Other.

You receive the program without any guarantee of functionality, flawlessness or applicability to an activity. You waive any claim compensation in the event of damage, for whatever reason. S By using this program, you fully agree to these license agreements. conditions.

Version 1.0, 13-OCT-92
Ende ALAS

Appendix B

1 Contact Addresses

If you are interested in the latest version of GP, send a floppy disk and sufficient payment of postage to the address:

Ulf Saran Bankverbindung:
DH1DAE account: 674945
Veit-StoÐ-Str. 36 Institute: Sparkasse Siegen
57076 Siegen BLZ: 460 500 01

(Fundraisers for the program are not necessary, but will be accepted with gratitude)

Appendix C

1 Authors of the program

The GP program was entirely developed by DH1DAE, some routines to The initialization of V24 comes from DL5FBD. The idea and execution of GPRI (Graphic Packet) Remote Interface) comes from DH1DAE. GP was developed using TURBO PASCAL 6.0 © (Borland International 1990). To program the graphical user interface Standard means were used, i.e. no special tools. The length in has currently enlarged to almost 26800 lines (about 700kB) to

Special thanks for the reports, help with programming, utilities, Translations, suggestions for improvement, etc., etc., include:

DL1ELY, DF3VI, DG9EP, DG3DBI, DG1EHE, DG1EH, DC1VL, DG0FT, DG1FAZ, DL1DBC, DL7GAI, DJ1XK, G0KIU, F1HBN, PE1MHO and many more.

(This list does not claim to be complete)

Thanks also to ADACOM e.V. and AMPACK Bayern e.V.
The right to change is reserved.

Siegen, 16.09.1993

© **Petr Faltus OK1CFP** 25/9/2001