



PIN2/the SEL connection doesn't exist because it overlaps with the rotary switch's SEL connection

NOTE B: BOOT7 is only connected so it can be routed through the unused switch's pad

TITLE:	GRUBswitch_CustomHW_RevB		
Documen	t Number:		REV:
Date:		Sheet: 2	1/1