

B737 MAX 8 AOM



Caribbean Airlines

A practical systems, procedures and line-operations guide

Document ID	CALV-B38M-AOM-001
Revision / date	Revision 1 / 17 August 2026
Aircraft	Boeing 737-8 (737 MAX 8)
Purpose	Virtual-airline training and desktop flight simulation
Status	UNCONTROLLED TRAINING DOCUMENT

CRITICAL NOTICE: This is not a Caribbean Airlines, Boeing, CFM, FAA, EASA or TTCAA approved publication. Caribbean Airlines' publicly listed fleet currently comprises Boeing 737-800 and ATR 72-600 aircraft; this 737-8 manual represents a fictional/virtual-airline operating concept. Never use it for real aircraft operation, maintenance, dispatch or safety decisions.

B737 MAX 8 AOM

Document Control

Authority	Caribbean Airlines Virtual — Flight Operations
Owner	Chief Pilot / Training Department
Distribution	Virtual flight crew, instructors and dispatchers
Review cycle	Whenever simulator behavior, virtual SOP or source data changes
Precedence	Simulator add-on documentation and current certified source data always prevail

Revision Record

1	17 Aug 2026	Initial detailed issue for Boeing 737-8 virtual operations.

How to Use This Manual

Read Chapters 1–7 before attempting a complete flight.

Use Chapters 8–10 as the normal operating sequence.

Use Chapter 11 only as decision support; the simulator's QRH/ECL remains controlling.

Use Appendix A as a cockpit quick-reference flow, then verify each checklist in the aircraft add-on.

DATA CONVENTION: “Public baseline” means a publicly reported aircraft-family characteristic. “Training baseline” means a representative value for simulation only. “Aircraft-specific” means the value must come from the current simulator model, dispatch release, FCOM/QRH or approved performance tool.

TRAINING & FLIGHT-SIMULATION USE ONLY • REV 1 — 17 AUG 2026 •

CARIBBEAN AIRLINES VIRTUAL | B737-8 AOM

Table of Contents

1. General Information and Operating Philosophy
2. Aircraft Description and Principal Data
3. Limitations, Operating Policies and Stabilized Approach Criteria
4. Flight Deck and Display Management
5. Aircraft Systems
6. FMS/CDU Programming
7. Flight Planning, Dispatch and Performance
8. Normal Procedures — Preflight to Takeoff
9. Normal Procedures — Climb, Cruise and Descent
10. Normal Procedures — Approach, Landing and Shutdown
11. Non-Normal and Emergency Operating Framework
12. Adverse Weather and Special Operations

B737 MAX 8 AOM

13. Crew Resource Management and Line Operations

14. Training Profiles and Proficiency Standards

15. Sample Caribbean Airlines Virtual Sector

16. Source Hierarchy, Data Updates and Glossary

Appendix A — Quick-Reference Normal Flow

Appendix B — Go/No-Go Decision Gates

Appendix C — Personal Notes and Aircraft-Specific Entries

TRAINING & FLIGHT-SIMULATION USE ONLY • REV 1 — 17 AUG 2026 •
CARIBBEAN AIRLINES VIRTUAL | B737-8 AOM

1. General Information and Operating Philosophy

1.1 Scope

This manual provides a single-pilot-friendly but two-crew-oriented operating framework for the Boeing 737-8 in Caribbean Airlines Virtual service. It emphasizes stable configuration, disciplined automation management, threat-and-error management, and repeatable flows supported by checklists.

1.2 Crew Priorities

1 — Aviate	Control flight path, energy, attitude and thrust.
2 — Navigate	Confirm present position, terrain clearance and intended path.
3 — Communicate	Coordinate with the other pilot, ATC, cabin crew and dispatch.
4 — Manage	Complete checklists, diagnose only when stable, and protect fuel/time margins.

1.3 Standard Callout Philosophy

- Use concise challenge–response language; do not bury a safety-critical item inside conversation.
- The Pilot Flying (PF) owns flight path and configuration requests. The Pilot Monitoring (PM) verifies selections, communications and checklists.
- Any crew member may call “STOP,” “GO-AROUND,” or “UNSTABLE.” A go-around call is immediately honored.
- Mode awareness requires verbal confirmation of unexpected FMA changes.

1.4 Caribbean Operating Environment

Typical network threats include convective weather, heavy rain, runway contamination, high humidity, salt exposure, bird activity, short island sectors, rapid turnarounds, non-radar environments and destination alternates separated by water. Plan conservatively and avoid “press-on” decisions when cells, fuel or runway condition erode margins.

2. Aircraft Description and Principal Data

B737 MAX 8 AOM

2.1 Aircraft Overview

The Boeing 737-8 is a twin-engine, narrow-body transport powered by two CFM LEAP-1B turbofans. It uses a conventional 737 control architecture with MAX-family flight-deck displays, advanced-technology winglets and updated systems. Boeing publicly lists a 39.5 m (129 ft 6 in) length, 35.9 m (117 ft 10 in) wingspan, 12.3 m (40 ft 4 in) height and range up to approximately 3,500 nmi for the 737-8; actual capability depends on configuration, payload, weather and reserves.

ICAO type designator	B38M	Flight plan/equipment coding must match network rules.
Engines	2 × CFM LEAP-1B27	Use add-on-specific start and limit indications.
Typical cruise	Mach 0.78–0.79	Optimize using ECON and cost index.
Maximum operating altitude	41,000 ft training baseline	Observe weight, temperature and buffet margins.
Maximum operating speed	340 KIAS / M0.82 training baseline	Verify aircraft-specific placards and PFD limits.
Fuel	Wing tanks plus center tank	Quantity/useable fuel varies by model.

2.2 Representative Structural Weights

VERIFY BEFORE DISPATCH: The following commonly published 737-8 figures are orientation values only. Enter the exact add-on/airframe values in the load manager and dispatch system.

Maximum taxi weight	82,420 kg /
Maximum takeoff weight	82,190 kg
Maximum landing weight	68,800 kg
Maximum zero-fuel weight	65,952 kg /

2.3 Ground Clearance Awareness

Engines have limited ground clearance: use low taxi speed near uneven pavement, shoulders and standing water.

Do not use excessive thrust behind light aircraft, vehicles, equipment or open terminal areas.

Maintain wingtip awareness when turning; the split-tip winglet increases visual complexity.

Avoid sharp turns with high gross weight or high speed; use the recommended tiller technique.

3. Limitations, Operating Policies and Stabilized Approach Criteria

3.1 Limitation Discipline

Red-line, amber-band and placarded limits displayed by the simulator are controlling. When this manual differs, use the more restrictive value until the discrepancy is resolved.

3.2 Representative Configuration Speeds

B737 MAX 8 AOM

Flaps 1 / 2 / 5	250 KIAS	Use placard display if different.
Flaps 10	210 KIAS	Avoid late deceleration.
Flaps 15	200 KIAS	Common intermediate/landing setting.
Flaps 25	190 KIAS	Verify model.
Flaps 30	175 KIAS	Normal landing setting when suitable.
Flaps 40	162 KIAS	Higher drag; performance/noise considerations.
Gear extension	270 KIAS / M0.82	Operational limits may differ by action.

3.3 Stabilized Approach Gate

By 1,000 ft above airport elevation in IMC, and by 500 ft in VMC, the aircraft should be on the correct lateral and vertical path, in landing configuration, checklist complete, thrust stabilized, and speed within +10/-5 kt of target unless an approved procedure states otherwise. Sink rate should normally be no more than 1,000 ft/min unless briefed. If not stabilized, go around.

3.4 Crosswind and Contaminated Runways

Treat simulator/add-on crosswind guidance as advisory unless its documentation states a demonstrated or limiting value.

Use current runway condition, braking action, slope, wind, temperature and reverser assumptions in the performance calculation.

Do not subtract reverse-thrust credit informally or use dry-runway intuition on a wet/contaminated runway.

4. Flight Deck and Display Management

4.1 Display Scan

PFD	FMA, attitude, airspeed trend, altitude, path and minima.
Navigation display	Map range, route continuity, weather/terrain display and traffic.
Engine/system display	N1, EGT, fuel flow, oil indications, alerts and configuration.
Mode control panel	Selected heading, altitude, speed and vertical mode.
CDU	Route, performance, progress, legs constraints and messages.

4.2 Automation Policy

Use the highest appropriate level of automation, not the highest available level.

Before selecting a mode, state the intended result; after selection, confirm the FMA.

If the aircraft does not do what is expected: intervene, simplify, then diagnose.

Hand-flying is encouraged when workload and conditions permit, but raw-data proficiency does not excuse unstable energy management.

4.3 Flight Directors and Autopilot

B737 MAX 8 AOM

Flight-director commands depend on armed and active modes. CMD engagement does not guarantee the desired path. Monitor pitch, roll, thrust and FMA continuously. Disconnect early if automation creates doubt, and trim/control the aircraft before troubleshooting.

5. Aircraft Systems

5.1 Electrical

Normal AC power is supplied by engine-driven generators, with the APU generator and external power available on the ground. Transformer rectifier units supply DC buses; the battery supports essential loads for limited time. Confirm the power source before removing another source.

Ground power: verify quality/availability indication before connection.

APU: observe start indications, generator availability and cooldown requirements.

Transfer: monitor for unexpected bus-off indications and load shedding.

Battery: do not leave the aircraft powered without an approved source and monitoring.

5.2 Fuel

Fuel is carried in left and right main tanks and a center tank. Main-tank pumps normally feed their respective engine manifolds; center pumps are used in accordance with quantity and pressure logic. Maintain lateral balance and respond promptly to LOW PRESSURE indications.

CENTER TANK: Do not use a generic “pumps always on” habit. Apply the simulator’s modeled center-tank pump logic, including minimum quantity and low-pressure actions.

5.3 Hydraulics

Systems A and B power flight controls, landing gear, brakes and other users, with standby hydraulic capability for selected essential functions. Electric motor-driven pumps supplement engine-driven pumps. Monitor quantity, pressure and temperature; do not cycle a failed system repeatedly.

5.4 Pneumatics and Air Conditioning

Engine bleeds, the APU bleed and an external source can supply the pneumatic manifold. Packs provide conditioned air and pressurization. Configure isolation and bleeds deliberately during engine start, single-pack operation, anti-ice use and abnormal conditions.

5.5 Pressurization

Set landing altitude before departure. In AUTO, the system schedules cabin climb and descent from flight and landing altitude inputs. Monitor cabin altitude, differential pressure and cabin rate during climb and before top of descent. A cabin-altitude warning requires immediate memory actions modeled by the simulator, followed by the applicable checklist and descent planning.

5.6 Ice and Rain Protection

B737 MAX 8 AOM

Engine anti-ice is used for icing conditions as defined by the aircraft source documentation, including appropriate ground operations.

Wing anti-ice is primarily an in-flight system; follow model-specific restrictions.

Anti-ice increases bleed demand and affects thrust/performance. Recalculate or use the proper takeoff/landing setting.

Use windshield heat early and continuous as prescribed; use wipers only within modeled operating guidance.

5.7 Flight Controls and High-Lift Devices

Primary controls are hydraulically powered with manual or standby provisions depending on axis/system. Speed trim, yaw damper and stall-management functions assist handling. Flaps are selected through detents and monitored for agreement. Never continue configuration changes into a suspected asymmetry or disagree condition without the non-normal checklist.

5.8 Landing Gear and Brakes

The tricycle gear retracts hydraulically. Normal braking uses hydraulic pressure with antiskid, autobrake and brake-temperature considerations. Select autobrake based on landing distance, runway exit plan and passenger comfort—not as a substitute for performance assessment.

5.9 Fire Protection

Engines and APU include detection and extinguishing provisions. Cargo compartments use detection and suppression logic depending on configuration. A fire warning demands immediate control of the aircraft, completion of memory actions, then checklist confirmation. Do not delay landing for diagnosis when fire is confirmed or cannot be excluded.

5.10 Communication, Navigation and Surveillance

The aircraft integrates VHF communications, transponder/TCAS, weather radar, radio altimeters, IRS/GNSS navigation and optional datalink functions. Verify simulator equipment before filing capability codes. TCAS resolution advisories take priority over ATC vertical instructions unless terrain or aircraft safety requires otherwise.

6. FMS/CDU Programming

6.1 Initialization Sequence

Set IRS selectors as required and verify present position source.

On IDENT, confirm aircraft model, navigation database validity and engine rating.

Enter company route or origin/destination on RTE; verify runway and flight number.

Build the route from clearance—not from expectation. Resolve discontinuities only when path continuity is intended.

Select departure and arrival procedures; cross-check charts, runway, transitions and constraints.

Enter performance data: reserves, cost index, cruise altitude, forecast winds if supported, and temperature.

On N1 LIMIT and TAKEOFF REF, enter the dispatch-approved thrust and flap setting.

Verify calculated V-speeds against the performance source, then line-select/accept them as modeled.

B737 MAX 8 AOM

6.2 Route Verification

Both pilots compare legs against the operational flight plan and clearance.

Step through every leg on the navigation display, looking for turns, gaps, duplicate fixes and unreasonable track changes.

Check altitude and speed constraints for feasibility.

Confirm runway extension, missed approach and destination/alternate data.

6.3 VNAV Discipline

VNAV is a management tool, not a guarantee. Observe path/deviation, speed intervention effects, forecast accuracy and constraint sequencing. On short Caribbean sectors, descent preparation may begin soon after top of climb; complete arrival setup before workload peaks.

7. Flight Planning, Dispatch and Performance

7.1 Fuel Planning

Taxi	Expected APU/taxi burn, congestion and deicing if applicable.
Trip	Takeoff to landing under forecast route and conditions.
Contingency	Uncertainty in winds, routing, level and performance.
Alternate	Missed approach, route to alternate and landing.
Final reserve	Protected minimum reserve; not routine usable fuel.
Additional / extra	ETOPS, holding, weather, MEL/CDL or captain's margin.

7.2 Takeoff Performance

Use a valid performance tool for runway, intersection, slope, wind, temperature, pressure, contamination and obstacle data.

Verify takeoff weight, flap, assumed temperature/fixed derate, packs/bleeds, anti-ice and runway condition.

Cross-check $V1 \leq VR \leq V2$ and reasonableness against recent flights.

Brief stop margin, initial track, acceleration altitude, engine-out path and return plan.

7.3 Landing Performance

Calculate landing distance before departure when required and update before approach using actual runway condition and wind. Compare required distance with available distance using the virtual operator's safety factor. A favorable ATC runway assignment does not replace a completed landing assessment.

7.4 Oceanic and Extended Overwater Operations

A 737-8 route over the Caribbean may require extended-overwater equipment and may, depending on routing and approval, invoke ETOPS planning. Virtual crews should model suitable en-route alternates, diversion weather, depressurization/engine-out critical fuel,

B737 MAX 8 AOM

communication capability and survival equipment. Do not label a flight ETOPS-capable solely because the aircraft has range.

8. Normal Procedures — Preflight to Takeoff

8.1 Preliminary Preflight

Review aircraft status, technical log, MEL/CDL, weather, NOTAMs, route, alternates and fuel.

Establish electrical power and verify fire-protection test capability.

Perform cockpit safety checks; confirm gear lever DOWN, flap position and circuit-breaker condition.

Initialize IRS/FMS and set oxygen, navigation and communications.

Conduct exterior inspection using the add-on checklist; look for damage, leaks, doors/panels, probes, tires, brakes, fan blades and ice/contamination.

8.2 Cockpit Preparation Flow

Overhead — forward	Electrical power, IRS, emergency lights, signs, window heat, probes.
Overhead — center	Fuel pumps, hydraulics, anti-ice, packs, isolation, bleeds, pressurization.
Main panel	Displays, flight instruments, standby instruments, landing altitude, autobrake.
Pedestal	Radios, transponder, trim, speedbrake, flap lever, parking brake.
CDU/MCP	Route/performance complete; initial speed, heading, altitude and flight directors.

8.3 Before Start

Loadsheet accepted: ZFW, fuel, takeoff weight and CG agree across dispatch, CDU and simulator.

Departure briefing complete: threats, taxi, runway, performance, automation, rejected takeoff and engine-out plan.

Doors closed, beacon on, ground crew clearance obtained, push/start plan confirmed.

Trim set to computed value; rudder trim zero; speedbrake down detent; parking brake as coordinated.

8.4 Engine Start

Configure packs/bleeds and start source according to the model.

Select start switch to GND for the intended engine; verify N2 rotation and oil pressure response.

At the modeled minimum N2, move the start lever to IDLE.

Monitor EGT, fuel flow, N1/N2 and oil pressure for a normal light-off; abort for no light-off, hot start, hung start or no oil pressure.

Verify starter cutout and stable idle, then start the other engine.

Reconfigure generators, probes, anti-ice, packs/bleeds and APU as required.

8.5 Taxi

Brake check immediately after movement.

Taxi at a speed that permits stopping within visible clear pavement; reduce speed for turns and wet ramps.

Complete flight-control check in a clear area and verify correct movement/indications.

B737 MAX 8 AOM

Set takeoff flaps; verify green-light/indication and complete Before Takeoff checklist before runway entry.

8.6 Takeoff

Align using runway markings and verify runway/heading.

Advance thrust to approximately 40% N1 and allow stabilization; then set takeoff thrust/TOGA as modeled.

PM verifies thrust set and calls "80 knots," "V1," and "Rotate."

At VR, rotate smoothly toward approximately 15° pitch, following flight-director guidance.

After positive rate, select gear UP. Track the engine-out safe path even on a normal departure.

9. Normal Procedures — Climb, Cruise and Descent

9.1 Initial Climb and Acceleration

At acceleration altitude, lower pitch as commanded, retract flaps on schedule using speed cues and positive acceleration, and avoid exceeding maneuver/placard speeds. Confirm CLB thrust and complete the After Takeoff checklist.

9.2 Climb

Monitor pressurization, engine trend, fuel balance and weather.

Set altimeters at transition altitude and cross-check.

Use speed intervention or selected modes deliberately when VNAV is unsuitable.

Reassess top-of-climb capability when turbulence, icing or high weight reduces margin.

9.3 Cruise

At level-off	Thrust mode, cruise altitude entry, fuel and ETA.
Regular scan	Fuel remaining vs plan, balance, engine/system trend, cabin, weather and alternates.
Before oceanic segment	Position, communications, contingency routing and suitable airports.
Before descent	Weather/ATIS, NOTAMs, landing performance, arrival/approach and fuel.

9.4 Descent Planning

A useful mental check is about 3 NM per 1,000 ft to lose, plus allowance for deceleration and wind. VNAV top of descent remains the primary planned point when the route and forecasts are valid. If high, use drag early; do not chase the path with excessive speed near terrain or approach gates.

9.5 Arrival Briefing

Airport/runway, weather, threats and diversion triggers.

STAR and approach, navigation aids, minima, missed approach and expected taxi.

Landing weight, flap, VREF plus wind additive, autobrake and calculated landing distance.

Automation plan, visual references, special terrain/noise constraints and go-around strategy.

B737 MAX 8 AOM

10. Normal Procedures — Approach, Landing and Shutdown

10.1 Approach Configuration

Configure early enough to stabilize without prolonged low-altitude level flight at high thrust. Use flap maneuver speeds as targets unless ATC or procedure requires otherwise. Select landing gear at the point needed for descent/drag and complete the Landing checklist by the stabilization gate.

10.2 ILS Approach

Confirm both radios/courses if modeled, identify the approach and verify minima.

Arm APP only when cleared and positioned for a credible intercept.

Confirm localizer capture, then glideslope capture, with correct FMA.

At the gate, confirm stabilized criteria and landing clearance.

Disconnect or continue coupled as briefed and permitted by the simulator capability.

10.3 RNAV Approach

Confirm the procedure and navigation specification supported by the add-on. Check RNP, path angle, temperature limits and barometric minima. VNAV path guidance does not make an approach precision-capable. If lateral or vertical integrity is doubtful, execute the missed approach.

10.4 Landing Technique

Maintain target speed and aim point; avoid large thrust changes below 500 ft.

Begin a smooth flare near the modeled normal height; reduce thrust toward idle while preserving touchdown-zone aim.

Touch down without holding the aircraft off for a “soft” landing.

Verify speedbrake deployment, apply reverse as planned, monitor deceleration and use manual braking as required.

10.5 Go-Around

Select TOGA as modeled, call “Go-around, flaps 15” or the add-on-specific command, and establish flight-director guidance.

Verify positive rate; gear UP.

Follow missed-approach track and altitude; manage acceleration and flap retraction.

Engage automation when stable, communicate with ATC, and decide whether to re-approach, hold or divert.

10.6 After Landing and Shutdown

Clear the runway completely before heads-down actions.

Retract flaps, disarm speedbrake, set transponder, lights, probes and anti-ice; start APU when needed.

At stand: parking brake/chocks coordinated, electrical source established, engines shut down, beacon off when safe.

Complete secure flow: fuel pumps, hydraulics, bleeds/packs, lights, IRS and battery according to turnaround or termination needs.

B737 MAX 8 AOM

11. Non-Normal and Emergency Operating Framework

CONTROLLING SOURCE: Memory items and checklist wording must come from the simulator's current QRH/ECL. The summaries below describe priorities and decision logic, not substitute checklists.

11.1 Universal Response

Maintain control and establish a safe flight path.

Identify the condition using indications and crew cross-check; do not act on a single ambiguous cue.

Complete only genuine memory actions.

Read and complete the applicable non-normal checklist.

Assess landing urgency, fuel, weather, terrain, runway and support.

Communicate, brief cabin/passengers, and plan the approach and evacuation risk.

11.2 Rejected Takeoff

Below 80 kt, reject for significant abnormality or doubt. Above 80 kt and before V1, reject only for high-severity events such as fire warning, engine failure, predictive windshear warning, aircraft unsafe/unable to fly, or other virtual-operator criteria. At or after V1, continue unless the aircraft is clearly incapable of flight.

11.3 Engine Failure or Fire

Control yaw and pitch; follow flight director only if commands are credible.

Positive rate: gear up. Do not rush identification.

At a safe altitude, identify, confirm and action the correct engine using the QRH.

Plan a prompt landing for fire, severe damage or persistent abnormal indications.

11.4 Rapid Depressurization / Cabin Altitude

Don oxygen masks, establish crew communications, complete memory actions, initiate emergency descent when required, turn away from high terrain/traffic, and advise ATC. Level at a safe altitude, assess fuel and divert. Passenger oxygen duration and terrain may control the decision.

11.5 Windshear and GPWS

For a reactive windshear or terrain escape, follow the modeled escape guidance immediately.

Use maximum available thrust as commanded; disconnect automation if required; do not change configuration until clear unless the checklist directs.

Do not attempt to "salvage" an approach after a warning or significant unstable condition.

11.6 Unreliable Airspeed

Set known pitch and thrust appropriate to phase of flight, reduce automation, compare all sources and use the QRH tables. Avoid configuration changes until control is secure and the condition is understood.

B737 MAX 8 AOM

11.7 Smoke, Fire or Fumes

Protect the crew, initiate the checklist, plan the nearest suitable landing, and avoid troubleshooting that delays descent. If the source is unknown or smoke persists, urgency is high. Consider passenger condition, runway access and evacuation after landing.

11.8 Flight-Control Anomalies

If trim, stabilizer or control behavior is unexpected: hold the control column firmly, disengage automation as required, use the exact memory items/checklist for the modeled condition, and avoid speculative switch selection. Stabilizer-trim events demand precise checklist discipline.

12. Adverse Weather and Special Operations

12.1 Thunderstorms

Avoid cells laterally; never use weather radar returns as a corridor between strong cells.

Use tilt and range actively; radar shows reflectivity, not every hazard.

Expect rapid wind, runway and braking changes near Caribbean convection.

Delay, hold elsewhere or divert before fuel becomes the decision-maker.

12.2 Turbulence

Turn seat-belt signs on early, coordinate cabin service, use turbulence penetration speed/guidance, avoid large control inputs and maintain an appropriate altitude margin. Do not chase altitude aggressively in severe turbulence.

12.3 Wet and Flooded Runways

Standing water increases hydroplaning, spray ingestion and braking risk. Use runway-condition information, recalculate takeoff/landing data, apply crosswind constraints and reject informal “it should stop” reasoning.

12.4 Volcanic Ash

Avoid visible or reported ash. Weather radar may not reliably display ash. If encountered, use the aircraft checklist, exit the cloud promptly, monitor engines and systems, and land at the nearest suitable airport.

12.5 Low Visibility

Autoland/low-visibility operation requires an aircraft, airport, crew and procedure all qualified in the simulation scenario. Brief fail-passive/fail-operational status as modeled, alert height/decision altitude, rollout guidance, lighting and taxi plan.

13. Crew Resource Management and Line Operations

B737 MAX 8 AOM

13.1 Threat and Error Management

Short sector	Complete arrival setup before departure or early climb.
Convective weather	Define escape routes and diversion fuel before cells close options.
Unfamiliar airport	Brief terrain, runway geometry, lighting and missed approach.
Automation surprise	Call FMA, simplify mode, hand-fly when necessary.
Time pressure	Stop the sequence; re-establish checklist discipline.
Fatigue	Use cross-checks, conservative decisions and fit-for-duty policy.

13.2 Briefing Standard

A good briefing is short, specific and interactive. State the plan, highest threats, key configuration/performance decisions, and one or two triggers that will cause a go-around, diversion or stop. Invite correction: “Anything to add or challenge?”

13.3 Simulator Single-Pilot Adaptation

Pause only when the simulator/network rules allow; otherwise stabilize before using menus.

Use a written scratchpad for clearance, performance and fuel gates.

Automate routine radio or cabin functions only when it does not hide operational cues.

Never let camera manipulation or external views replace instrument monitoring during critical phases.

14. Training Profiles and Proficiency Standards

14.1 Initial Qualification Sequence

1 — Systems/flows	Power-up, cockpit layout, FMS and normal start.
2 — Handling	Takeoff, climbs, turns, stalls awareness, descent and visual landing.
3 — Instrument	ILS, RNAV, missed approach and automation mode management.
4 — Non-normal	Rejected takeoff, engine failure, depressurization, smoke and diversion.
5 — Line-oriented	Complete Caribbean sector with weather, ATC and operational decisions.

14.2 Proficiency Standard

Maintains safe flight path and recognizes deviations promptly.

Configures by SOP and completes checklists without omitted safety-critical items.

Explains active/armed modes and intervenes appropriately.

Meets stabilized-approach criteria and goes around without prompting when required.

Uses fuel, weather and airport information to make timely decisions.

15. Sample Caribbean Airlines Virtual Sector

B737 MAX 8 AOM

15.1 Scenario: Trinidad to Miami

Route	TTPP/POS → KMIA/MIA (route per current clearance)
Mission	Day passenger service; 737-8 virtual fleet
Primary threats	Convective weather, oceanic communications, arrival congestion, wet runway
Key gates	Fuel after climb, suitable en-route airports, landing performance before descent
Diversion concept	Select operationally suitable airport using actual weather/fuel—not proximity alone.

15.2 Dispatch-to-Block Sequence

Review release and weather; define no-go and diversion triggers.

Load aircraft and validate weight/CG/fuel.

Program and verify route/performance.

Brief departure, engine-out strategy and weather escape.

Fly with fuel checks at top of climb, midpoint and before descent.

Update arrival and landing performance; execute stabilized approach or go around.

Record discrepancies and operational notes after shutdown.

16. Source Hierarchy, Data Updates and Glossary

16.1 Source Hierarchy

1	Simulator aircraft's current FCOM/QRH/ECL, performance tool and limitations.
2	Virtual operator SOP, dispatch release, MEL/CDL and training notices.
3	Current charts, NOTAMs, weather and ATC clearance.
4	This AOM as explanatory and training guidance.

16.2 Public References

Boeing — 737 MAX product and technical specifications pages (aircraft dimensions, engine family and public range).

Caribbean Airlines — official About Us/fleet description (public fleet context).

Applicable simulator developer documentation and change logs for aircraft-specific behavior.

16.3 Glossary

AOM	Aircraft Operating Manual
CDL	Configuration Deviation List
ECL	Electronic Checklist
ETOPS	Extended Operations

B737 MAX 8 AOM

FMA	Flight Mode Annunciator
FCOM	Flight Crew Operations Manual
MEL	Minimum Equipment List
PF / PM	Pilot Flying / Pilot Monitoring
QRH	Quick Reference Handbook
RNP	Required Navigation Performance
TOGA	Takeoff/Go-Around
VNAV / LNAV	Vertical / Lateral Navigation

TRAINING & FLIGHT-SIMULATION USE ONLY • REV 1 — 17 AUG 2026 •

CARIBBEAN AIRLINES VIRTUAL | B737-8 AOM

Appendix A — Quick-Reference Normal Flow

Power-up	Battery/external power • fire test • IRS • emergency lights
Preflight	FMS • radios • oxygen • pressurization • performance • exterior inspection
Before start	Loadsheet • trim • doors • beacon • push/start clearance
Start	Packs/bleeds • starter • fuel at N2 • monitor • generators • reconfigure
Taxi	Brake check • controls • flaps • trim • departure review
Takeoff	Runway verify • stabilize thrust • TOGA • calls • rotate • positive rate gear up
Climb	Acceleration • flap retraction • climb thrust • altimeters • systems
Cruise	Fuel/engine/cabin/weather checks • arrival preparation
Descent	Landing data • briefing • minima • pressurization • approach setup
Landing	Stable gate • touchdown zone • speedbrake/reverse • deceleration
Shutdown	Parking/chocks • power • fuel cutoff • beacon • secure flow

Appendix B — Go/No-Go Decision Gates

Dispatch	Legal release, suitable weather/alternates, serviceable aircraft and adequate fuel.
Before push	Loadsheet/performance complete; doors and ground coordination confirmed.
Before takeoff	Correct runway/configuration, no warning, performance and clearance verified.
Approach gate	Correct path/configuration, checklist complete, stable speed/thrust/sink.
Landing commitment	Runway clear/adequate, aircraft controlled, no alert requiring go-around.

Appendix C — Personal Notes and Aircraft-Specific Entries

Complete these fields from the exact simulator add-on documentation. Do not copy values from another 737 variant.

B737 MAX 8 AOM



Simulator/add-on and version

Engine rating

Maximum weights

Fuel capacity/useable fuel

Flap maneuver/placard speeds

Autoland capability

RNP capability

Crosswind guidance

Start limitations

MEL simulation policy