PARTS BOOK


FOR

BROTHER DB2-B781, -100, -200



Single Needle Differential Feed Straight Stitcher Single Needle Differential Feed Straight Stitcher with Thread Trimmer

BROTHER INDUSTRIES, LTD.
NAGOYA, JAPAN



How to use the parts book

- 1. When the column for the parts number or the parts assembly number is ______, please refer to the different parts list on the page 11.
- 2. When the column for the parts number is ______, the parts cannot be supplied. But when the parts assembly number is shown in the column, please order the parts by the parts assembly number so that the parts can be arranged in the form assembled parts.
- 3. This book is edited basing on the data as of the January, 1978.
- 4. The parts in this book may be changed without any advance notice.

Hinweise für das Zubehörteilebuch


- 1. Wenn die Klumne für die Nummer der Zubehörteile oder dessen Montage ist, bitte schlage Sie die Liste der Differentialzubehörteileliste in der Seite 11 nach.
- 2. Wenn die Klumne für die Nummer der Zubehörteile ist, gibt es keine Zubehörteile, dagegen wenn die Montage- Nummer der Zubehörteile in der Liste steht, können Sie die Zubehörteile mit der Differentialzubehörteileliste ordentlich bestellen.
- 3. Diese Buch-Ausgabe ist im Januar, 1978.
- 4. Bei der Änderung der Zubehörteile in diesem Buch mag es keine Notiz geben.

Mode d'emploi du livre des pièces

1.	Quand la case pour le numéro des pièces ou le numéro des pièces as- semblées est, veuillez vous référer à la liste des pièces dif- ferentes à la page 11.
2.	Quand la case pour le numéro des pièces est, les pièces ne peut pas être fournir. Mais quand le numéro des pièces assemblées est presenté sur la case, veuillez ordonner les pièces au numéro des pièces assemblées pour que les pièces puissent être arrangées sur la forme assemblée des pièces.
3.	Ce livre est édité suivant les données de Janvier, 1978.
4.	Les pièces de ce livre peuvent être changées sans aucune annonce.
	Como usar libros de piezas
1.	Como usar libros de piezas Las piezas que no tiene numeros referentes pero, se vea la lista de piezas diferentes en la pagina 11 en adelante.
	Las piezas que no tiene numeros referentes pero, se vea la lista
2	Las piezas que no tiene numeros referentes pero, se vea la lista de piezas diferentes en la pagina 11 en adelante. La pieza que tiene, no se puede suministrarse en pieza misma


CONTENTS

A.	Machine Body	1
В.	Upper Shaft, Needle Bar, Thread Take-up, Rotary Hook Mechanism	2
C.	Main Feed Mechanism	3
	Differential Feed Mechanism	
E.	Presser Foot, Knee Lifter Mechanism	5
F.	Lubrication	6
	Thread Trimmer and Tension Releaser (-100, -200)	
	Synchronizer (-100, -200)	
	Thread Wiper Mechanism (-200)	
	Accessories	
	FFERENT PARTS LIST (1)	
	FFERENT PARTS LIST (2)	
	DEX	




Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No.	Ref. No.	Name of Parts		Parts No.	Assembly No.
A- 1-1	Face Plate	1		A-1	A-28	Model Plate	1		
A. 1.2	Packing	1	109195-0-01	Face Plate	A-29	Pin		116231-0-01	
A. 1-3	Face Plate Thread Guide	1	111476-0-01	Assembly	A-30	Pump Cover		145454-0-01	
A- 1-4	Screw	1	108960-0-02	181357-0-01	A-31	Nut	2	100090-0-04	
A- 2	Screw	2	009671-0-13		A-32	Name Plate "BROTHER"	1		
A- 3	Oil Cap	1	112782-0-01		A-33	Screw		100191-0-03	
A- 4	Oil Cap	1	104449-0-01		A-34	Screw		013680-6-12	
A · 5	Screw	1	009671-8-13		A-35	Thread Retainer	1	114931-0-01	
A- 6	Oil Cap	1	142607-0-01		A-36	Thread Take-up Cover		140885-0-01	
A- 7	Screw	2	009670-5-12		A-37	Screw	1	009680-7-13	
				A-8	A-38	Arm Thread Guide		113316-0-01	
A- 8-1	Oil Stopper	1		Oil Stopper Assembly	A-39	Screw		009670-6-14	
A- 8-2	Wick	1	109405-0-01	181472-0-01	A-40	Arm Thread Guide L		145524-0-01	
A. 9	Oil Cap	1	104449-0-01		A-41	Nut		021660-1-02	
A-10	Vinyl Cap	8	104450-0-01		A-42	Screw		103950-0-02	
A-11	Oil Cap	3	104821-0-01		A-43	Tension Release Pin		100400-0-00	
A-12	Oil Cap	1	111865-0-01		A-44-1	Screw	1	100402-0-04	
A-13-1	Pretension Stud	1		4.10	A-44-2	Upper Tension Regulator Bracket	-	144741-0-01	A-44
A-13-2	Spring	1	144505-0-01	A-13 Pretension	A-44-3	Packing		114294-0-01	Upper Tension
A-13-3	Thread Guide Disc	2	144504-0-01	Assembly	A-44-4	Thread Take-up Spring	1	100399-0-01	Regulator
A-13-4	Pretension	1		144502-0-01	A-44-5	Tension Stud		100398-0-01	Bracket
A-13-5	Screw	1	102716-0-03	144002-0-01	A-44-6	Tension Disc		145446-0-01	Assembly
A-14	Pretension Stud	1	146056-0-01		A-44-7	Tension Disc Washer		100134-0-01	181638-0-01
A-15	Thread Guide Disc	2	144504-0-01		A-44-8	Tension Spring		117215-0-01	
A-16	Pretension Disc Washer	1	146206-0-01		A-44-9	Nut	1	100136-0-01	
A-17	Pretension Spring	1	146058-0-01		A-45	Arm Bed	1		
A-18	Pretension Nut	1	146059-0-01		A-46	Bed Leg L	1	104829-0-01	
A-19	Spring	1	146060-0-01		A-47	Bed Leg S	1	104830-0-01	
A-20	Nut	1	105234-0-01		A-48	Needle Plate Washer		146251-0-01	
A-21	Washer	1	025680-2-34		A-49-1	Slide Plate	1		A-49 Slide Plate
A-22	Thread Guide Plate	1	146055-0-01		A-49-2	Screw	2	122771-0-01	Assembly
A-23	Screw	6	009670-8-12		A-49-3	Slide Plate Spring	1	114561-0-01	180100-0-01
A-24	Rear Cover	1			A-50	Oil Cap		142274-0-01	
A-25	Packing	1	110547-0-01		A-51	Oil Cap		104833-0-01	
A-26	Oil Cap	2	104832-0-01		A-52	Screw		100032-0-03	
A-27	Oil Cap	1	108520-0-01		A-53	Needle Plate	1		

B. Upper Shaft, Needle Bar, Thread Take-up, Rotary Hook Mechanism




Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No.	Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly N
B- 1	Needle Bar Bushing Upper	1	111463-0-01		B-25	Screw	-	010001	
B- 2	Screw	1	100260-0-01		B-26	Upper Shaft Bushing Left	1	013761-4-10	
B- 3	Screw	1	013761-4-12		B-27	Upper Shaft Upper Shaft	1	111459-0-01	·. I
B- 4-1	Stud	1			B-28	O Ring PWZ	1	110469-0-01	
B- 4-2	Thread Take-up Supporter	1			B-29		1	081002-6-70	
B- 4-3	Thread Take-up Lever	1			B-29	Oil Screw Right for Upper Shaft Screw	1	104555-0-01	
B- 4-4	Thread Take-up Supporter Pin	1			B-31		1	013761-4-10	
B- 4-5	Washer	1				Upper Shaft Bushing	1	140726-0-00	
3- 4-6	Pin	i			13-32-1	Screw	2	013760-8-10	B-32
B- 4-7 3- 4-8	Needle Roller Bearing	2	116735-0-00	13-4	B-32-2	Collar	1		Collar 181994-0-01
3- 4-9	Cap	1		Thread Take-up	B-33-1	Upper Shaft Gear	1		B-33
	Screw	1	145465-0-01	Lever Assembly	12 12 0	S			Upper Gear
3- 4-10	Needle Bar Connector	1			B-33-2	Screw	2	013770-7-10	Assembly 180022-0-01
3- 4-11	Set Screw	1	140004-0-01		13 00 0 1				
3- 4-12	Needle Bar Clamp	1	111237-0-01		B-33-3-1	Screw	2	013770-7-10	B-33-3 Vertical Sha
3- 4-13	Needle Bar Crank	1							Upper Gear
3- 4-14	Wick	1			B-33-3-2	Vertical Shaft Upper Gear	1		Assembly 180957-0-01
4-15		1			B-34	Vertical Shaft Upper Bushing	1	142708-0-00	100957-0-01
3- 5	Packing	1	118770-0-01		B-35	Screw		013760-6-10	
. 6	Oil Adjusting Screw for Upper Shaft	1	140412-0-01		B-36	Upper Shaft Bushing R		146331-0-01	
- 7	Spring	1	116799-0-01		B-37	Oil Seal			
- 8	Oil Bushing	1	140357-0-01		B-38	Screw		101487-0-00	
- 9	Washer	1	110367-0-01		B-39	Pulley		013760-6-10	
-10	Needle Bar Cork	1	111863-0-01		B-40	Screw	1		
-11	Wick	1	108809-0-01		B-40 B-41	Vertical Shaft		013761-4-12	
-12	Needle Bar	1			B-42-1	Screw		144868-0-01	
-13	Needle Bar Bushing Lower	1	111464-0-01		D-42-1	Screw	2	101706-0-03	B-42
-14	Screw		100260-0-01		B-42-2	Lower Shaft Collar	1		Collar
-15	Thread Guide Under		00573-0-01		B-43	6			181995-0-01
-16	Screw		40553-0-01			Screw		013761-4-12	
-17	Needle Bar Thread Guide	it	140555-0-01			Vertical Shaft Lower Bushing		142709-0-00	
-18	Needle	 			B-45	Screw	1 1	104478-0-01	
19	Needle Bar Guide Slide Block	·	02630-0-01	——————————————————————————————————————	3-46-1	Screw	3 (013770-7-10	B-46
	Screw		02630-0-01						Vertical Shaft
	N II D C II		02631.0.00	l	3-46-2	Vertical Shaft Lower Gear	1		Lower Gear Assembly
	C	' '	02031-0-00			onare Bower Geal	_		180959-0-01
	0		04464 0 0:		3-47-1	Lower Shaft Gear	,		B-47
	Screw		04464-0-01				1		Lower Shaft
44	OCICII	2 0	13770-7-10	11	3-47-2	Screw	2 0	13770-7-10	Gear Assembly 180960-0-01

C. Main Feed Mechanism




Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No.	Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No
> 1	Feed Shaft Bushing, Left	1	142632-0-01		C-23	Lower Shaft	1		
- 2	Screw	1	101706-0-01		C-24	Oil Stopper	1	118560-0-01	
2- 3-1	Main Feed Bar Arm	1		C-3 Main Feed Bar	C-25	Screw	2	009670-8-12	
3-1	Stud	1	110535-0-01	Main Feed Bar Assembly	C-26	Sub Feed Dog (A,B)	1		
. 3-2	Main Feed Bar	1		110532-0-01	C-27	Screw	4	100080-0-03	
. 3·3 C- 4	Screw	i	009681-6-12			O'I D :	1		C-28
2. 5	Collar	1	110529-0-01		C-28-1	Oil Rejector	1		Oil Rejector
	Screw	2	102716-0-03		C-28-2	Screw	1	013689-4-12	144943-0-01
C- 6	Stud	1	102/10 0 00		C-29	Main Feed Dog (A,B)	1		
7-1		1	013719-4-12		C-30	Oil Felt	1		
7.2	Screw	1	013713-4-12		C-31	Oil Cap Screw	1	109173-0-01	
. 7.3	Sub Feed Bar	1		C-7	C-32	Rotary Hook Assembly	1		
- 7-4	Sub Feed Shaft	_	009681-6-12	Sub Feed Bar	C-32	Bobbin	1	146290-0-01	
7-5	Screw	1	009081-0-12	Assembly	C-34	Bobbin Case Sheet	1	140356-0-01	
7-6	Sub Feed Arm	1	110700000	110527-0-01		Spring Adjusting Screw	 -	181937-0-01	
C- 7-7	Screw	1	110563-0-01		C-35-1	Spring Set Screw	1	181938-0-01	C-35
C- 7-8	Sub Feed Arm Connecting Rod	1	110506-0-01		C-35-2		1	182392-0-01	Bobbin Case
7-9	Shaft	1	110562-0-01		C-35-3	Lower Thread Adjusting Spring	1	102392-0-01	Assembly
2- 8	Washer	1	110505-0-01		C-35-4	Bobbin Case			
. · · · ·	Screw	1	009681-2-12		C-36	Bobbin Case Holder Position Bracket	1	000001 0 101	
C-10-1	Main Feed Arm	1			C-37	Screw	1	009681-0-12	
C-10-2	Shaft	1			C-38	Lower Shaft Bushing, Left	1	118761-1-00	
C-10-3	Screw	1	110563-0-01		C-39	Screw	1	013680-8-12	
C-10-4	Stud	1	140507-0-01	C-10	C-40	Spring	1	116794-0-01	
C-10-5	Slide Block	1	142634-0-01	Feed Regulator	C-41	Screw	1	145534-0-01	
C-10-6	Slide Block	1	110509-0-01	Assembly	C-42	Screw	2	009711-0-12	
C-10-7	Main Feed Arm	1		182391-0-01	C-43	Holder	1	110502-0-01	
C-10-8	Screw	1	105451-0-01	102331-0-01	C-44-1	Lower Shaft Collar	2		C-44
C-10-9	Differential Feed Adjuster	1	110501-0-01		C-44-1	Lower Shart Conar			Collar
C-10-10	Differential Feed Adjusting Link	1		1	C-44-2	Screw	4	101706-0-01	181995-0-01
C-10-11	Screw	2	101706-0-01	1	C-45	Differential Feed Adjusting Shaft	1	110512-0-01	
2-10-11				C-10-12	C-46	Pin	2	100215-0-00	
C-10-12-1	Set Collar	1		Collar	C-47	Taper Center Left	1	104847-0-01	
C-10-12-2	Corous	2	100289-0-03	J	C-48	Screw	1	013770-7-10	
	Screw	1	009669-4-14				٠.		
C-11		1	142631-0-01		C-49-1	Stud	1	110535-0-01	C-49
C-12	Feed Shaft Bushing, Middle	1	101706-0-01	+					Main Feed
C-13	Screw	2	112054-0-01	-	C-49-2	Main Feed Lifting Arm	1		Lifting Arm
C-14	Collar		101706-0-01	1					Assembly
C-15	Screw	4		-	C-49-3	Slide Block	1	110542-0-01	110540-0-01
C-16	Horizontal Feed Shaft	1	142629-0-01		C-50	Screw	1	009681-2-12	
C-17	Screw	1	101706-0-01		C-50		1	110543-0-01	
C-18	Feed Shaft Bushing, Right	1	142630-0-01			Sub Feed Lifting Arm	1	009681-2-12	
C-19	Felt	1	107155-0-01		C-52	Screw	1	118559-0-01	
C-20	Lower Shaft Bushing, Right	1	104520-1-00		C-53	Oil Stopper			
C-21	Screw	1	110230-0-01		C-54	Screw	2	009670-8-12	
	S-A Caller	1		C-22	C-55	Feed Lifting Rock Shaft	1	110539-0-03	
C-22-1	Set Collar	L.		Collar	C-56	Taper Center, Right	1	104848-0-01	
C-22-2	Screw	2	101706-0-03	181995-0-01	C-57	Screw	-1	013770-7-10	

D. Differential Feed Mechanism




Ref. No.	Name of Parts	Q't	y Parts No.	Assembly No.	Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No
D- 1-1	Screw	2	101706-0-01	D-1 Vertical Food	D-22	Screw	1	009680-7-13	
D- 1-2	Vandina III. III. III. III.	-		Vertical Feed Eccentric Whee	D-23	Pin	1	047250-6-42	
D- 1-2	Vertical Feed Eccentric Wheel	1		181485-0-01	D-24	Stop Ring	T	048090-3-42	
D- 2- D- 3-1	Vertical Feed Connecting Rod	1	110538-0-01		D-25	Washer	1	142627-0-01	
	Washer	1	142120-0-01		D-26	O Ring	1	110558-0-01	
D- 3-2	Ripple Type Spring	1	103602-0-02		D-27	Stopper	1	142626-0-01	
D- 3-3	Cam Ditch Washer	2	103601-0-01		D-28	Screw	2	101706-0-01	
D- 3-4	Screw	2	101479-0-01]	D-29	Collar	i	117671-0-02	
D- 3-5	Screw	2	013761-4-10		D-30	Horizontal Feed Crank Ring	2	142628-0-01	
D- 3-6	Screw	1	009660-4-12		Davis			142028-0-01	
D- 3-7	Gib Stopper	1	104766-0-01	D-3	D-31-1-1	Screw	1		D-31-1
D- 3-8	Pin	2	104765-0-01	Eccentric Wheel	D-31-1-2	Bush	1		Bushing 180029-0-01
D- 3-9	Stopper Spring	1	142369-0-01	140019-0-01	D-31-2	O Ring		001001 6 70	
D- 3-10		1			D-31-3	Shaft		081001-6-70	D-31
D- 3-11		1			D-31-4	Screw		110524-0-00	Differential
D- 3-12	Gib	1	103595-0-00		D-31-5	Feed Regulator Dial		011681-2-14	Feed Control
D- 3-13	Slide Block	1	101477-0-01		D-31-6	Differential Feed Control Plate		181384-0-01	Dial Assembly 110521-0-01
D- 3-14	Pin	1	101476-0-01		D-31-6			110526-0-01	110.021-0-01
D- 3-15	Eccentric Wheel	1	101470-01		D-31-7	Screw		102836-0-04	
D- 4	Feed Adjustor Button	i	111471-0-01			Packing		108549-0-01	
D- 5	Spring	1	103607-0-00		D-33	Screw		102843-0-01	
D- 6	Stop Ring	1	048040-3-42		D-34	Spring		117260-0-01	
D- 7	Screw	1	009681-2-12		D-35	Steel Ball	1	071039-7-50	
D- 8	Feed Regulator Lever	1	142635-0-01		D-36	Screw		009711-2-12	
). 9	Transverse Assembly	1	142620-0-01		D-37	Screw	2	101706-0-01	
0-10-1	Horizontal Feed Connecting Rod	1	142020-0-01		D-38	Differential Feed Regulator Rod	1	142637-0-01	
0.10.2	Shaft	3	110500 0 01		D-39	Nut	1	104689-0-01	
0-10-3	Screw	3	110562-0-01		D-40	Screw	1	100310-0-01	
0-10-4	Horizontal Feed Connecting Rod		110563-0-01		D-41	Stopper	1	142648-0-01	***
	Horizontal Feed Vertical	1	142618-0-01	Harizontal Bood	D-42	Screw	2	107407-0-02	
0-10-5	Connecting Rod	1	110485-0-01	Connecting	D-43	Pin	2 (047250-6-42	
0-10-6	Horizontal Feed Crank		1	Rod Assembly	D-44	Screw	1 (014760-6-22	
0.10.7	Shaft		142619-0-01	142617-1-01	D-45	Screw	-	13760-6-10	
0-10-7	Screw		110562-0-01		D-46	Differential Feed Connector Lever		42641-0-01	
			110563-0-01			Clip Ring		48050-3-42	
-10-9	Feed Rock Shaft Arm		148283-0-01		D-48	Connecting Bar		42649-0-01	
0-11	Stopper		101482-0-01			Screw		14760-6-22	
-12	Set Screw	1	009760-8-13		D-50	O Ring		81005-6-70	
-13	Spring		142624-0-01		D-51	Differential Feed Indicator Plate		42646-0-01	
-14	Packing	1	111194-0-01			Pin		16231-0-02	
-15	Screw	1	013761-4-10			Stop Ring		48030-3-42	
-16	Transverse Bushing	1	142623-0-00			Spring		42642-0-01	
-17	O Ring	1	105708-0-01			Spring			
-18	Set Screw	1 (015771-0-12			Screw		42643-0-01	
	Screw	1	100511-0-03			Spring Hook		09680-7-13	
-20	Reverse Lever		110491-0-01			Differential Feed Lever		42644-0-01 42645-0-01	
-21									

E. Presser Foot, Knee Lifter Mechanism




Ref.	Name of Parts	Q'ty	Parts No.	Assembly No.	Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No.
E- 1	Screw	1	141207-0-01		E-20-3	Presser Bar Lifter	1	142017-0-01	E-20
E- 2	Presser Spring Bar	1	141208-0-01		E-20-3	Shaft	<u> </u>	142011 0 01	Presser Bar
E- 3	Presser Foot Complying Bar	1	142614-0-01		E-20-4	Presser Bar Lifter	1	142016-0-01	Lifting
E- 4	Spring	1	118718-0-01		15-20-4	Lever	ļ.,		Lever Assembly 142014-0-01
E- 5	Stop Ring	1	048025-3-42		E-20-5	Bolt	1	142018-0-01	142014-0-01
E- 6	Presser Bar Lifter	1	142613-0-01		E-21	Screw	_	013760-7-12	
E- 7	Presser Spring	1	141209-0-01		E-22	Presser Bar Upper Gear	1	116746-0-01	
	Presser Bar Lifting	1	109144-0-01	E-8	E-23	Stop Ring		048040-3-42	
E- 8-1	Connector	1 1	109144-0-01	Presser Bar Lifting	E-24	Screw	1	102921-0-02	
E- 8-2	Screw	1	100294-0-01	Assembly	E-25	Presser Bar Lifter Lever	1	142615-0-01	
E- 8-3	Presser Bar Lifter Bracket	1	100290-0-01	181623-0-01	E-26	Spring		116752-0-01	
E- 9	Presser Spring Washer	1	140407-0-01		E-27	Screw	2	009761-0-13	
E-10	Presser Bar	1	111466-0-01		E-28	Presser Bar Lifter Lever Plate	1	142616-0-01	
E-11-1	Screw	1	013760-8-10	E-11	E-29	Chain	1	149247-0-01	
		Τ,		Presser Bar Assembly	E-30	Knee Lifter Upper Crank Shaft	1	109145-0-01	
E-11-2	Presser Bar Clamp	1		180102-0-01	E-31-1	Screw	1	013770-7-10	E-31 Knee Lifter
E-12	Screw	1	009680-7-13		E-31-2	Knee Lifter Crank Upper	1	141167-0-00	Connecting
E-13	Presser Bar Bracket Thread Guide	1	111469-0-01		E-31-3	Pin	1	045161-0-00	Rod Assembly
E-14	Presser Bar Bushing	1	111467-0-01		E-31-4	Knee Lifter Connecting Rod	1	141170-0-01	181633-0-01
E-15	Screw	1	001670-8-14		E-32	Knee Lifter Complying Bar	1	145573-0-00	
E-16	Presser Foot	1			E-33-1	Knee Lifter Cover	1	140503-0-01	
E-17	Hinge Screw	1	109163-0-01		E-33-2	Knee Lifter Plate	1	114966-0-01	
E-18	Tension Release Lever	1	111470-0-00		E-33-3	Bolt	1	017762-0-13	E-33
E-19	Tension Release Lever Spring	1	100405-0-01		E-33-4	Knee Lifter Bar	1	104619-0-02	Knee Lifter
		1	001600 2 02	E-20	E-33-5	Knee Lifter Joint	1	146039-0-01	Assembly
E-20-1	Nut	1	021680-2-02	Presser Bar Lifting	E-33-6	Bolt	1	100463-0-01	181427-0-01
	n 1:4 6	1	142015-0-01	Lever Assembly	E-33-7	Bolt	1	110087-0-01	
E-20-2	Presser Bar Lifter Cam	1	142015-0-01	142014-0-01	E-33-8	Knee Lifter Plate Stopper	1	114967-0-01	

F. Lubrication




Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No.	Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No.
F- 1	Wick	1	109405-0-01		F-29	Wick		111502-0-01	
F- 2	Wick	1	108804-0-01		F-30	Wick	1	111502-0-01	
F- 3	Oil Tube Assembly	1	145792-0-01		F-31	Wick	1	108802-0-01	
F- 4	Felt Support	1	145737-0-01		F-32-1	Tube Joint	1	146324-0-01	
F- 5	Screw	1	009670-5-12		F-32-2	Packing	1	146040-0-01	
F- 6	Tube Holder	1	148806-0-01		F-32-3	Screw	1	140518-0-01	
F- 7	Screw	1	145992-0-01		F-32-4	O Ring	1	081007-0-70	
F- 8	Screw	1	009670-5-12		F-32-5	Oil Pan	1	149580-0-01	
F- 9	Tube Supporter	1	110557-0-01		F-32-6	Nut	2	100022-0-04	
F-10	Upper Oil Tube	1	146348-0-00		F-32-7	Screw	2	104885-0-01	F-32
F-11	Tube Guard	1	146326-0-01		F-32-8	Bolt	1	146367-0-01	Oil Pan
F-12	Oil Hole Bolt for Oil Gauge	1	143196-0-01		F-32-9	Knee Lifter Shaft	i	146036-1-01	Assembly
F-13	O Ring	1	081014-6-70		F-32-10	Oil Cap		140480-0-01	181420-2-01
F-14	Oil Gauge Window	1	104547-0-01		F-32-11	Knee Lifter		146037-0-01	
F-15	Oil Gauge Flange	1	104546-0-01		F-32-12	Spring		146038-0-01	
F-16	Screw	4	102538-0-02		F-32-13	Stop Ring		146293-0-01	
F-17	Wick	1	112999-0-00		F-33-1	Screw		112467-0-02	
F-18	Lower Oil Tube	1	146321-0-01		F-33-2	Spring		144876-0-01	
F-19	Tube Holder	1	146325-0-01		F-33-3	Plunger		144875-0-01	
F-20	Oil Plug	1	110872-0-01		F-33-4	Joint		144878-0-01	F-33
F-21	Oil Pipe Holder	1	142655-0-01		F-33-5	Pump Body		148848-0-01	Pump Body
F-22	Oil Pipe	1	142654-0-00		F-33-6	Propeller		148849-0-01	Assembly
F-23	Screw	1	009670-5-12		F-33-7	Pump		144869-0-01	181669-1-01
F-24	Screw	1	009680-6-12	-	F-33-8	Spring		144874-0-01	
F-25	Vinyl Tube	1	143671-0-00			Screw		009670-8-12	
F-26	Oil Tube Lower	1	148828-0-00			Oil Stopper		146196-0-01	
F-27	Spring		100328-0-01		F-35	Screw		009680-7-13	
F-28	Wick		108801-0-01		F-36	Pump Filter		144872-0-01	

G. Thread Trimmer and Tension Releaser (-100, -200)




Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No.	Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No.
G- 1	Thread Release Lever	1	148327-0-01		G-23	Stopper Guide	1	145618-0-01	
G- 2	Screw	1	102716-0-03		G-24	Screw	2	145619-0-01	
G- 3	Thread Release Link	1	148328-0-01		G-25	Stopper	1	145617-0-01	
G- 4	Screw	1	120263-0-01		G-26	Screw	1	009660-7-12	
G- 5	Thread Release Link	1	147106-0-01		G-27	Screw	1	009679-3-12	
G- 6	Tension Release Solenoid Assembly	1	147107-0-01		G-28	Oil Stopper Plate	1	145623-0-01	
G- 7	Vinyl Tube	1	121823-0-01		G-29	Holder Plate	1	145933-0-01	
G- 8	Screw	1	009670-6-12		G-30	Screw	2	009680-6-12	
G- 9	Supporter	1	148326-0-01		G-31	Movable Knife Holder Assembly	1	145601-0-01	
G-10	Solenoid Holder	1	147110-1-01		G-32	Screw	2	141542-0-01	
G-11	Screw	2	009681-0-13		G-33	Movable Knife Bracket	1	145608-0-01	
G-12	Solenoid Cover	1	148451-0-01		G-34	Washer	1	145611-0-00	
G-13	Screw	2	001639-3-12		G-35	Movable Knife	1	145610-1-01	
G-14	Connector Cap	1			G-36	Movable Knife Cover	1	148325-0-01	
G-15	Nylon Connector	1	145681-0-00		G-37	Washer	1	025680-1-33	
G-16	Thread Trimming Solenoid	,	146014-0-01		G-38	Oil Stopper	1	149709-0-01	
G-10	Assembly	1	146014-0-01		G-39	Washer	3	147697-0-01	
G-17	Screw	2	009680-7-12		G-40	Screw	3	014680-6-22	
G-18	Pin	1	047300-8-42		G-41	Cord Holder	1	145595-0-01	
G-19	Washer	1	025040-3-35		G-42	Screw	2	009680-6-12	
G-20	Spring	1	145621-0-01		G-43	Bushing	1	146080-0-00	
G-21	Stud	1	145620-0-01		G-46	Cord Holder	2		
G-22	Stop Ring	1	048030-3-42		G-47	Screw	1	009670-5-12	




Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No.	Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No.
H-1	Screw	2	009711-4-12		11-2-11	Washer	1	025060-3-35	
H-2-1	Magnet Stud	1			H-2-12	Washer	1 1	028060-2-34	
H-2-2	Screw	1	215083-0-01			Screw	- 		
H-2-3	Washer		025030-3-35			Cord Holder	1	216880-0-01	H-2
H-2-4	Bearing	- i	020030-3-33	11.0			1		Synchronizer
H-2-5	Hole IC Holder	- 1		H-2		Washer		025040-1-35	Assembly
H-2-6	Washer	1	205040.0.00	Synchronizer	H-2-16		2	215080-0-01	218931-0-01
H-2-7			025040-3-35	Assembly	H-2-17	Synchronizer Cover	1		
	Screw	3	217093-0-01	218931-0-01	H-2-18	Lave!	1		
H-2-8	Hole IC with Cord	;c 1	218953-0-01		H-3	Synchronizer Holder Bar	1	218944-0-01	
H-2-9	Washer	2	025040-1-35		H-4	Holder		148329-0-01	
H-2-10	Screw		215080-0-01		H-5	Screw	1 1		
			210000-0-01		H-9	Screw	2	009670-5-12	

J. Thread Wiper Mechanism (-200)



Ref.	Name of Parts	Q'ty	Parts No.	Assembly No.	Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No.
J- 1	Face Plate	1	148330-0-01		J-13	Bushing	1	146079-0-01	
J- 2	Bushing	1	146080-0-00		J-14	Spring	1	146089-0-01	
- J· 2 - J· 3	Thread Wiper Solenoid	1	146082-0-00		J-15	Thread Wiper Crank	1	146088-0-01	
J- 3	Cord	1	146095-0-00		J-16	Grooved Link	1	146091-0-01	
J- 4 J- 5	Screw	2	009680-8-12		J-17	Screw	1	111443-0-01	
J. 5	Solenoid Set Plate	1	146081-0-01		J-18	Washer	1	102707-0-02	
J. 7	Stop Ring	2	048025-3-42		J-19	Thread Wiper Supporter	1	146093-0-01	
J- 8	Solenoid Link		146086-0-01		J-20	Screw	1	009681-4-14	
J- 8	Wire Link	1	146087-0-01		J-21	Thread Wiper Stud	1	146092-0-01	
J-10	Screw	- i	009671-0-13		J-22	Thread Wiper Stud Collar	1	146288-0-01	
J-10 J-11	Screw	2	102716-0-02		J-23	Screw	1	001670-5-14	
J-11 J-12	Thread Wiper Lever	1	146090-0-01		J-24	Thread Wiper	1	146094-0-01	

Z. Accessories



Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No.	Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No.
Z- 1	Accessory Box		110436-0-01		Z-17	Blower		1 10010 0 0 1	, , , , , ,
Z- 2	Screw Driver		142443-0-01		Z-18	Head Rest		143910-0-01	
Z- 3	Screw Driver		118837-0-01		Z-19	Oil Tank		100477-0-01	
Z- 4	Screw Driver		101572-1-01		Z-19 Z-20	Oiler		145277-1-03	
Z- 5	Spanner 8×9		100887-0-01		Z-20 Z-21	Needle Plate		114483-0-01	
Z- 6	Needle				Z-22	Thumb Screw			
Z- 7	Bobbin		146290-0-01			Ruler		106120-0-01	
Z- 8	Presser Foot		142795-0-01		Z-23			100471-0-01	
Z- 9	Screw		100666-0-02		Z-24	Allen Wrench		146049-0-01	
Z-10	Bobbin Winder Assembly		117963-0-01		Z-25	Hinge		145945-0-01	
Z-11	Magnet		112525-0-00		726	Earth Wire	[145946-0-01	
Z-12	Oil Pan Cushion		146004-0-01		Z-27	Washer		025680-2-34	
Z-13	Nail		109714-0-00		Z-28	Screw		009680-6-13	
Z-14	Head Cushion				Z-29	Movable Knife Case		145990-0-01	
Z-15	Hinge		146003-1-01		Z-30	Movable Knife		145608-0-01	
Z-16-1	Belt Cover D		143882-0-01		Z-31	Screw		141542-0-01	
Z-16-2	Screw		100000 0 00		Z-32	Main Feed Dog A,B			
Z-16-3	Washer		100666-0-02		Z-33	Sub Feed Dog A,B			
Z-16-4	Screw		025750-1-32	Z-16	Z-34	Head Cover		144222-0-01	
Z-16-5	Washer		009680-8-12	Belt Cover	Z-35	Cotton Stand Assembly		150150-0-01	
Z-16-6	Belt Cover UA		028680-2-42	Assembly					
Z-16-7	Stud Stud			147895-0-11					
			147856-0-01	ſ					
Z-16-8	Stud		147855-0-01	I					

- * The details of included accessories are subject to change.
- * Änderungen in der Aufstellung der mitgelieferten Zubehöre sind vorbehalten.
- * Les détails des accessoires inclus sont sujets à des changements.
- * Los detalles de los accesorios incluídos pueden variar.

DIFFERENT PARTS LIST (1)

				6	4						
	Sub-class	-1	-2	-3	-4				00.4		
Ref. No.	Specification	80102 · 80109 80105 · 80110	80202 · 80209 80205 · 80210	80302 • 80309 80305 • 80310	80402 · 80409 80405 · 80410	-103	-104	-203	-204		
	Name of Parts	80108	80208	80308	80408			<u> </u>			
Α- 1	Face Plate Assembly		181357	7-0-01							
A- 1-1	Face Plate			11145	5-0-01	148330-0-01					
A- 1-3	Face Plate Thread Guide		111470	6-0-01							
A- 1-4	Screw		10896	0-0-02							
A- 3	Oil Cap			11278	2-0-01						
A- 4	Oil Cap							1044	19-0-01		
A- 6	Oil Cap	142607-0-01		142607-0-01			142607-0-01				
A-13	Pretension Assembly		14450	2-0-01							
A-14	Pretension Stud						14605	66-0-01			
	Thread Guide Disc						14450	04-0-01			
A-15	Pretension Disc Washer						14620	06-0-01			
A-16				14605	58-0-01						
A-17	Pretension Spring				1460	59-0-01					
A-18	Pretension Nut			50-0-01							
A-19	Spring	105234-0-01									
A-20	Nut					025680-2-34					
A-21	Washer				146055-0-01						
A-22	Thread Guide Plate					148319-0-01					
A-24	Rear Cover		11046	7-0-01							
A-40	Arm Thread Guide L							24-0-01			
A-41	Nut							60-1-02			
A-48	Needle Plate Washer							51-0-01			
A-50	Oil Cap						1422	74-0-01			
A-51	Oil Cap		10483	33-0-01							
A-53	Needle Plate	1125	49-0-01	11047	0-0-01	ļ	1483	23-0-01			
B- 4	Thread Take-up Lever Assembly	1112	34-0-01	11323	78-0-01	145463-0-01					
B-12	Needle Bar		11146	52-0-01		145467-0-01					
B-17	Needle Bar Thread Guide		11277	75-0-01		145944-0-01					
B-18	Needle	1005	75-0-31	10026	55-0-34	100265-0-31					
B-22	Counter Weight	1114	65-0-00	10920	05-0-00		1114	65-0-00			
B-39	Pulley		1426	12-0-01			1488	24-0-01			
C-23	Lower Shaft		10916	50-0-01			17-0-01				
		A Stretch	B Shrink	A Stretch	B Shrink			tretch			
C-26	Sub Feed Dog A, B	sewing 142653-0-01	sewing 142651-0-01	sewing 142653-0-01	142660-0-01		sewi 1426	53-0-01			
C-28	Oil Rejector Assembly			43-0-01							
		AStretch	B Shrink	A Stretch	B Shrink			tretch			
C -29	Main Feed Dog A, B	sewing 142652-0-01		sewing 142652-0-01	sewing 142659-0-01			52-0-01			
C-30	Oil Felt			36-0-01				51-0-01			
C-32	Rotary Hook Assembly	1125	23-0-01		80-0-01		1455	85-1-01			
C -34	Bobbin Case Sheet		1403	56-0-01							
C-35	Bobbin Case		1003	69-0-01			1483	50-0-01			
Ċ-36	Bobbin Case Holder Position Bracket		1496	99-0-01			1105	46-1-01	,		
	15. acree		048050-3-42		048050-3-42	1			048050-3-4		

	Sub-class	s -1	2	-3	1					
Ref. No.	Specification Name of Parts		80202 · 80209 8020 · · 80210	80302 · 80309 80305 · 80316	80402 · 80409 80403 · 80410	-103	-104	203	-204	
D-48		00106	80208	80308	80408					
E- 3			1 42649 0 01		142649-0-01				142649-0-01	
E - 4									142614-0-01	
E - 5		_							118718-0-01	
E- 6									048025-3-42	
E · 8		101000 0 01	T	1	1				142613-0-01	
E-16		181623-0-01		181623-0-01			181623-0-01			
E-21	Screw			75-0-01	1		14388	8-0-01		
E-22			013760-7-12		013760-7-12				013760-7-12	
E-23	Presser Bar Upper Gear		116746-0-01		116746-0-01				116746-0-01	
	Stop Ring		048040-3-42		048040-3-42		048040-3-42			
E-24	Screw		102921-0-02		102921-0-02		102921-0-02			
E-25	Presser Bar lifter Lever		142615-0-01		142615-0-01				142615-0-01	
E-26	Spring		116752-0-01		116752-0-01				116752-0-01	
E-27	Screw		009761-0-13		009761-0-13				009761-0-13	
E-28	Presser Bar Lifter Lever Plate		142616-0-01		142616-0-01		142616-0-01		142616-0-01	
E-29	Chain						149247-0-01		149247-0-01	
E-30	Knee Lifter Upper Crank Shaft	109145-0-01		109145-0-01			109145-0-01			
E-31	Knee Lifter Connecting Rod Assembly	181633-0-01		181633-0-01		181633-0-01				
E-33	Knee Lifter Assembly						181427	-0-01		
G-14	Connector Cap					145596-0-01 146119-0-00				
G-46	Cord Holder				-	140647-	8-0-01			
Z - 6	Needle	10057	5-0-31	10026	5-0-34	-10011	100265		0.0.01	
Z-12	Oil Pan Cushion						146004			
Z-13	Nail						109714			
Z-14	Head Cushion						146003-			
Z-17	Blower									
Z-21	Needle Plate	117800	0-0-01	11254)-O-O1	143910-0-01 148332-0-01				
Z -24	Allen Wrench						146049-			
Z -25	Hinge									
Z-26	Earth Wire						145945-			
Z-27	Washer						145946-			
Z -28	Screw						025680-			
Z -29	Movable Knife Case						009680-			
Z-30	Movable Knife						145990-			
Z-31	Screw						145608-			
Z-32	Main Feed Dog A, B	B Shrink sewing 142650-0-01	A Stretch sewing 142652-0-01	B Shrink sewing 142650-0-01	A Stretch sewing 142652-0-01		B Shrin sewing	k		
Z -33	Sub Feed Dog A, B	B Shrink sewing	A Stretch sewing	B Shrink sewing	A Stretch sewing 142653-0-01		B Shrin sewing	k		
2, -00		145001-0-01			142651-0-01					
Z-34	Head Cover	142001-0-01								
	Head Cover Bobbin Q'ty	142001-0-01	3				144222-0			

DIFFERENT PARTS LIST (2)

The following specifications Model only have the parts listed below in standard accessories.

Ref	Sub-class	-1	-2	-3	-4	-103	-104	-203	-204
No	Name of Parts	80108	80208	80308	80408	100			
Z:16	Belt Cover Assembly				14789	5-0-11			

Ref.	Sub-class Specification Name of Parts	-1	-2	-3	-4	-103	-104	-203	=204
No.	Name of Parts Specification	80110	80210	80310	80410				
Z-35	Cotton Stand Assembly		15015	0-0-01					

INDEX

Ref. No. J=23 E-15 D-3-6	Remark	Parts No. 013770-7-10	B-24		100400-0-00	A-43		104766-0-01	D-3-7	
E-15										l
			B-33-2		100402-0-04	A-44-1		104821-0-01	A-11	
12-0-0			B-33-3-1		100405-0-01	E-19		104829-0-01	A-46	
C+11		1	B-46-1		100463-0-01	E-33-6		104830-0-01	A-47	
A-7		1	B-47-2		100471-0-01	Z-23		104832-0-01	A-26	
F-5			C-48		100477-0-01	Z-18		104833-0-01	A-51	
		1			100511-0-03			104847-0-01	C-47	
		1			100573-0-01			104848-0-01	C-56	
		014760-6-22						104885-0-01	F-32-7	
		014700022						105234-0-01	A-20	
		015771-0-12			100666-0-02			105451-0-01		
					100000000000000000000000000000000000000			105708-0-01		
					100887-0-01					
	-						 			
							-			
		023680-2-34		<u> </u>						-
		005550 1 00								
A-5		ļ								-
F-24					1777					
Z-28		045161-0-00								
A-37		047250-6-42	D-23		101706-0-01					
D-22			D-43							
D-56		048025-3-42	E-5]					
E-12			J -7]					
F-35		048030-3-42	D-53)		1			
J -5		048040-3-42	D-6]	C-44-2				
Z-16-4		1	E-23			D: 1:1				
C-37		048050-3-42	D-47]	D-28	<u> </u>	109163-0-01	E-17	
C-9		048090-3-42	D-24		1	D-37		109173-0-01	C-31	
		071039-7-50	D-35		101706-0-03	13-42-1		109195-0-01	A-1-2	
	 	081001-6-70			102538-0-02	F-16		109205-0-00	B-22	
		081002-6-70			102630-0-01	13-19		109405-0-01	A-8-2	
	 				102631-0-00	B-21		1	F-1	
	-				102707-0-02			109714-0-00	Z-13	
					102716-0-02			110087-0-01	E-33-7	
	 				102716-0-03	-		110230-0-01	C-21	
					1			110367-0-01	B-9	
				 	102836-0-04			110436-0-01	Z · 1	
	-							110467-0-01	 	
				 						
						2000			+	
							-			
C-39	1									
C-28-2				-					 	
C-7-2		100260-0-01		1						
B-35	ļ	<u> </u>	B-14							
B-38		D-49								
D-45		ļ								
E-21		100265-0-34	B-18							-
B-32-1			Z · 6		 		ļ			ļ
E-11-1		100289-0-03	C-10-12-2				ļ			
		100290-0-01	E-8-3		104520-1-00	C-20		110524-0-00	D-31-3	
		100294-0-01	E-8-2		104546-0-01	F-15		110526-0-01	D-31-6	
	1	100310-0-01	D-40		104547-0-01	F-14		110527-0-01	C-7	
	-				104555-0-01	13-29		110529-0-01	C-5	
	+		 	 	104619-0-02	 		110532-0-01	C-3	
			1	 				110535-0-01	C-3-2	i
	 			+			-	1		
	F-8 F-23 B-20 A-39 A-23 C-25 C-54 F-33-9 A-2 J-10 A-5 F-24 Z-28 A-37 D-22 D-56 E-12 F-35 J-5 Z-16-4 C-37 C-9 C-50 C-52 D-7 J-20 C-4 C-7-5 C-42 D-36 D-12 E-27 D-31-4 A-34 C-39 C-28-2 C-7-2 B-35 B-38 D-45 E-21 B-32-1	F-8 F-23 B-20 A-39 A-23 C-25 C-54 F-33-9 A-2 J-10 A-5 F-24 Z-28 A-37 D-22 D-56 E-12 F-35 J-5 Z-16-4 C-37 C-9 C-50 C-52 D-7 J-20 C-4 C-7-5 C-42 D-36 D-12 E-27 D-31-4 A-34 C-39 C-28-2 C-7-2 B-35 B-38 B-30 D-3-5 D-15 B-3 B-40	F-8 F-23 B-20 014760-6-22 A-39 015771-0-12 C-25 017762-0-13 C-54 021660-1-02 F-33-9 021680-2-02 A-2 025680-2-34 J-10 A-5 A-5 025750-1-32 F-24 028680-2-42 Z-28 045161-0-00 A-37 047250-6-42 D-22 D-56 D-56 048025-3-42 E-12 F-35 F-35 048030-3-42 Z-16-4 C-37 C-9 048090-3-42 C-50 071039-7-50 C-52 081001-6-70 D-7 081002-6-70 J-20 081005-6-70 C-4 081007-0-70 C-7-5 081014-6-70 C-42 100022-0-04 D-36 100032-0-03 D-12 100080-0-03 E-27 100090-0-04 D-31-4 100134-0-01 A-34 100136	F-8	F-8	F-8	F8	F.	F-8	F-8

Parts No.	Ref. No.	Remark	Parts No.	Ref. No.	Remark	Parts No.	Ref. No.	Dominule	Donat N	1 5 6 51	T
110538-0-0	1 D-2		140019-0-01	D-3	Kemark	142660-0-01		Remark	Parts No.	Ref. No.	Remark
110539-0-0	3 C-55		140354-0-01	A-8-1		142708-0-00	C-26		146119-0-00	-	
110540-0-0			140356-0-01	C-34			13-34		146196-0-01	F-34	
110542-0-0			140357-0-01	B-8		142709-0-00	13-44		146206-0-01	A-16	
110543-0-0			140407-0-01			142795-0-01	Z -8		146251-0-01	A-48	
110546-0-0			140412-0-01	E-9		143196-0-01	F-12		146288-0-01	J -22	
110547-0-0		 	140480-0-01	B-6		143671-0-00	F -25		146290-0-01	C-33	
110557-0-01			140503-0-01	F-32-10		143882-0-01	Z-15			Z-7	
110558-0-01				E-33-1		143888-0-01	E-16		146293-0-01	F-32-13	
110562-0-01	477 2247		140507-0-01	C-10-4		143910-0-01	Z-17		146321-0-01	F-18	
110002 0 01	D-10-2		140518-0-01	F-32-3		144222-0-01	Z -34		146324-0-01	F-32-1	
1		 	140553-0-01	B-16		144502-0-01	A-13		146325-0-01	F-19	
110563-0-01	D-10-7		140647-0-01	G-46		144503-0-01	A-13-4		146326-0-01	F-11	
110303-0-01			140726-0-00	B-31		144504-0-01	A-13-3		146331-0-01	B-36	
	C-10-3		140885-0-01	A-36			A-15		146348-0-00	F-10	
	D-10-3	<u> </u>	141167-0-00	E-31-2		144505-0-01	A-13-2		146367-0-01	F-32-8	
110000 0 0	D-10-8		141170-0-01	E-31-4		144568-0-01	A-13-1		147855-0-01	Z -16-8-	
110872-0-01	V (M)		141207-0-01	E-1		144741-0-01	A-44-2		147856-0-01	Z-16-7	
111194-0-01			141208-0-01	E-2		144868-0-01	13-41		147895-0-11	Z-16	
111234-0-01	48.00		141209-0-01	E-7		144869-0-01	F-33-7		148283-0-01	D-10-9	
111443-0-01			141542-0-01	Z-31		144872-0-01	F-36		148319-0-01	A-24	
111455-0-01	1000		142014-0-01	E-20		144874-0-01	F-33-8		148323-0-01	A-53	
111459-0-01	B-26		142015-0-01	E-20-2		144875-0-01	F-33-3		148330-0-01		
111462-0-01	B+12		142016-0-01	E-20-4		144876-0-01	F-33-2		1.0000-0-01	A-1-1	
111463-0-01	B-1		142017-0-01	E-20-3		144878-0-01	F-33-4		148332-0-01	J · l	
I11464-0-01	B-13		142018-0-01	E-20-5		144943-0-01	C-28		148350-0-01	Z-21	
111465-0-00	B-22		142120-0-01	D-3-1		145277-1-03	Z-19		148806-0-01	C-35	
111466-0-01	E-10		142268-0-01	G-46		145446-0-01	A-44-6		148824-0-01	F-6	
111467-0-01	E-14		142274-0-01	A-50		145454-0-01	A-30			13-39	
111469-0-01	E-13		142369-0-01	D-3-9		145463-0-01	B-4		148828-0-00	F-26	
111470-0-00	E+18		142443-0-01	Z-2		145465-0-01	B-4-9		148848-0-01	F-33-5	
111471-0-01	D-4		142607-0-01	A-6		145467-0-01			148849-0-01	F-33-6	
111476-0-01	A-1-3		142612-0-01	B-39		145517-0-01	B-12		149247-0-01	E-29	
111502-0-01	F-29		142613-0-01	E-6		145524-0-01	C-23		149580-0-01	F-32-5	
	F-30		142614-0-01	E-3			A-40		149699-0-01	C-36	
111863-0-01	B-10		142615-0-01	E-25		145534-0-01	C-41		150150-0-01	Z -35	
111865-0-01	A-12		142616-0-01			145573-0-00	E-32		180022-0-01	B-33	
112054-0-01	C-14		142617-1-01	E-28		145585-0-01	C-32		180029-0-01	D-31-1	
112467-0-02	F-33-1		142618-0-01	D-10		145596-0-01	G-14		180100-0-01	A-49	
112523-0-01	C-32		142619-0-01	D-10-4		145608-0-01	Z -30		180102-0-01	E-11	
112525-0-00	Z ·11			D-10-6		145737-0-01	F-4		180323-0-01	C-10-12	
112549-0-01			142620-0-01	D-9		145751-0-01	C-30		180957-0-01	B-33-3	
112345-0-01	A-53		142623-0-00	D-16		145792-0-01	F-3		180959-0-01	B-46	
112775-0-01	Z ·21		142624-0-01	D-13		145944-0-01	B-17		180960-0-01	B-47	
	B-17		142625-0-01	D-21		145945-0-01	Z -25		181357-0-01	A-1	
112782-0-01	A-3		142626-0-01	D-27		145946-0-01	Z -26		181384-0-01	D-31-5	
113278-0-01	F-17		142627-0-01	D-25		145990-0-01	Z-29		181420-2-01	F-32	
	B-4		142628-0-01	D-30		145992-0-01	F-7		181427-0-01	E-33	
113316-0-01	A-38		142629-0-01	C-16		146003-1-01	Z-14		181472-0-01	A-8	
114294-0-01	A-44-3		142630-0-01	C-18		146004-0-01	Z-12		181485-0-01	D-1	
114483-0-01	Z-20		142631-0-01	C-12		146036-1-01	F -32-9		181623-0-01	E-8	
114561-0-01	A-49-3		142632-0-01	C-1		146037-0-01	F-32-11		181633-0-01	E-31	
114931-0-01	A-35		142634-0-01	C-10-5		146038-0-01	F-32-12		181638-0-01	A-44	
114966-0-01	E-33-2		142635-0-01	D-8		146039-0-01	E-33-5		181669-1-01	F-33	
114967-0-01	E-33-8		142637-0-01	D-38		146040-0-01	F-32-2		181937-0-01		
116231-0-01	A-29		142641-0-01	D-46		146049-0-01	Z-24		181938-0-01	C-35-1	
116231-0-02	D-52		142642-0-01	D-54		146055-0-01	A-22		181994-0-01	C-35-2	
116746-0-01	E-22		142643-0-01	D-55		146056-0-01	A-14		181995-0-01	B-32	
116752-0-01	E-26		142644-0-01	D-57		146058-0-01	A-17		10.000.001	B-42	
116780-0-01	C-32		142645-0-01	D-58		146059-0-01	A-17		<u> </u>	C-22	
116794-0-01	C-40		142646-0-01	D-51					199901 0 01	C-44	
16799-0-01	B-7		142647-0-01	D-59		4 1 2 2 2 2 2 2	A-19		182391-0-01	C-10	
17215-0-01	A-44-8		142648-0-01	D-59 D-41			J -13		182392-0-01	C-35-3	
17260-0-01	D-34		142649-0-01				J -2				
17671-0-02	D-29		142650-0-01	D-48			J -6				
17800-0-01	Z -21			C-29			J -3				
17963-0-01	Z-10		142651-0-01	Z-32			J -8				
18559-0-01	C-53		172031-0-01	C-26	- 0		J .9		-		
18560-0-01			142650 0 0:	Z -33			J -15				
18718-0-01	C-24		142652-0-01	C-29			J -14				
18761-1-00	E-4		10055	Z-32		146090-0-01	J -12				
	C · 38	1	42653-0-01	C-26		146091-0-01	J16				
18770-0-01	B-5			Z -33		146092-0-01	J -21				
18837-0-01	Z ·3			F-22			J -19				
	A-49-2	1	42655-0-01	F-21		146094-0-01	J -24				
22771-0-01 40004-0-01	B-4-11		42659-0-01	1 21		140054-0-01) -24			I	- 1

