NVCRIS Help Document
Slope Measurement Screen

Tap on ‘Start’ to begin slope measurement. The measurement will begin once the device is at rest and stable.

If the item to be measured exists, but the measurement isn’t possible (due to standing water, etc.), tap on ‘Unable’. The item will be flagged for future measurement.

If the item to be measured does not exist, tap on ‘Does Not Exist’. The item will be flagged as such.

Make sure the arrow points in the proper direction, as shown by the text prompts on screen.