NVCRIS Help Document
Calibration Manager

The purpose of the calibration routine is to record the output values from the device's accelerometer against benchmark slope values. The values used in NVCRIS are the critical values prescribed by the ADA specifications for curb ramps and sidewalks. These values are 1:48 (2.1%), 1:20 (5.0%), 1:12 (8.3%) and 1:10 (10%).

Slope measurements conducted during the NVCRIS Detail survey will be interpolated around these values. This will correct whatever device error exists at the time. It is recommended to run the calibration routine daily for most accurate results.

Before running the calibration routine, be sure to find a flat surface (in both x and y axis) to use as a baseline. Then reproduce the running slopes listed above, with as little to no cross slope as possible.

All benchmark slopes should be verified with a digital level. Be sure to calibrate the digital level itself, if necessary, before using it.

To begin the calibration routine, tap on the ‘Calibrate 0.0%’ button. Then follow the instructions as they appear. The device will notify you when the routine is complete. The date and time of the calibration will appear on the bottom of the screen once it is complete.

It is essential to conduct the calibration routine as accurately as possible. Any deviation could have a negative affect on the accuracy of the slope measurements in the field.

To edit the benchmark values, tap on ‘Edit’. A list of values will appear. Left swipe to delete a value. Tap on the plus sign to add one. A maximum of five values are supported.

To test the device by getting uncalibrated slope values for a single measurement, tap on ‘Test’. This should indicate what error the device has at the time.