Ī	18	DCCT Fault	"READY"	N/A	FLT 11	The	Check the "Danfysik" DCCT
		(DCCT)	LED Off			"Danfysik"	sensing Module
			"OFF" LED			e1. Board	
			-> ON			(864I) is not	
						O.K.	