

NUC121 DFU

manifest_state



DFU FW config setting

MCU boot in LDROM for DFU updated APROM demo

Build Output

```
compiling clk.c...
linking...
Program Size: Code=2624 RO-data=412 RW-data=120 ZI-data=1536
After Build - User command #1: fromelf --bin ".\obj\USBD_HID_Transfer.axf" --output ".\obj\USBD_HID_Transfer.bin"
After Build - User command #2: fromelf --text -c ".\obj\USBD_HID_Transfer.axf" --output ".\obj\USBD_HID_Transfer.txt"
```




DFU driver

下载USB 驱动安装工具Zadig.exe

下载地:http://zadig.akeo.ie/downloads/zadig_2.2.exe



运行Zadig.exe,会进入如下界面



- 1, 選擇option->list all devices
- 2, 在下拉框中选择设备"HID transfer"
- 3, 選擇winusb 驅動
- 3,点击Install Driver

如果有弹出Windows 系统对话框,点击继续安装。



DFU app

- 下载DFU-Util 工具
- 下载地址(64位Windows 系统)
 - http://dfu-util.sourceforge.net/releases/dfu-util-0.9win64.zip
- 解压文件至你的电脑,例如"桌面>dfu-util-0.9-win64", 无需安装即可使用



- 在"运行"框中输入"cmd",打开Windows 终端工具
- 進入\dfu-util-0.9-win64 目錄
- 執行dfu-util.exe -a 0 -d 0x0416:0x6666 -D c:\bin.file
 - -a:燒錄起始位址
 - -d: devices pid and vid
 - -D: download file



Execution

```
C:\Users\jcliu\Desktop\dfu-util-0.9-win64>dfu-util.exe -a 0 -d 0x0416:0x6666 -D c:\USBD_HID_Transfer.bi
dfu-util 0.9
Copyright 2005–2009 Weston Schmidt, Harald Welte and OpenMoko Inc.
Copyright 2010–2016 Tormod Volden and Stefan Schmidt
This program is Free Software and has ABSOLUTELY NO WARRANTY
Please report bugs to http://sourceforge.net/p/dfu-util/tickets/
Invalid DFU suffix signature
 valid DFU suffix will be required in a future dfu-util release!!!
Opening DFU capable USB device...
ID 0416:6666
Run-time device DFU version 0110
Claiming USB DFU Interface...
Setting Alternate Setting #0 ...
Determining device status: state = dfuIDLE. status = 0
dfuIDLE, continuing
DFU mode device DFÜ version 0110
Device returned transfer size 1024
Copying data from PC to DFU device
                                                         6600 bytes
Download
                                          =1 100%
Download done.
state(6) = dfuMANIFEST-SYNC, status(0) = No error condition is present
state(2) = dfuIDLE, status(0) = No error condition is present
Done!
C:\Users\icliu\Desktop\dfu-util-0.9-win64>
```