FOR FLIGHT SIMULATOR ONLY / NUR FÜR DEN FLUGSIMULATOR

ENGLISH

This checklist is designed for a efficient operation flow in the flight simulator, for that some things were intentionally changed from the real world procedures. Making these checklists has become very time consuming for me, if you really like them, please consider a donation via flightsim.to. Many Thanks

DEUTSCH

Die Checkliste ist für einen effiziente Bedienungs im Flugsimulator gemacht, daher sind einige Prozduren absichtlich von den realen Prozeduren abweichend gestaltet. Das Erstellen der Checklisten ist sehr zeitaufwendigen geworden und falls du sie wirklich magst, dann ziehe bitte eine Spende via flightsim.to in Betracht. Vielen Dank.

CHECKLIST LEGEND

MP | MP-L | MP-R	Main Panel (Left & Right)
GS	Glare Shield Panel
OH | OHP	Overhead Panel
CC | CP	Center Console/Center Pedestal
LP | RP	Left Panel / Right Panel
BP	Back Panel
abcdefg (bold)	most important items for a quick start
abcdefg	**Navigation & ATC**
abcdefg	Gameplay / EFBs / UI Features
abcdefg	usually done by F/O or Pilot Not Flying
**abcde*	not modelled/simulated yet or not possible
AS REQ / DES	as required / desired
(d.o.w)	depending on aircraft actual gross weight

NOTES

FMC	Flight Management Computer
CDU	Control Display Unit
MCP	Mode Control Panel
CPT	Captain
F/O	First Officer
PF	Pilot Flying
PM	Pilot Monitoring (same as PNF – Pilot Not Flying)
VNAV	Vertical Navigation
LNAV	Lateral Navigation
FLC	Flight Level Change Mode
FMA	Flight Mode Annunciation (in PFD)
PFD	Primary Flight Display
EICAS	Engine Instrument and Crew Alerting System
GPU	Ground Power Unit
ACU	Air Condition Unit

CDU PMDG SETUP

- press the Menu Button on the CDU to access the PMDG Setup and Action Pages
- to enter these Pages with no Power on, press and hold the Menu Button

RECOMMENDED PMDG OPTION SETTINGS

MENU → PMDG SETUP → OPTIONS → SIMULATION
Page 1: ON | ON | **YES** | **YES** | ON
Page 8: **AS DESIRED** | **AS DESIRED**
Page 1 → IRS OPTIONS: AS DESIRED | **YES**

PARKING BRAKE

Setting the Parking Barke
- push the Brake Pedals, klick the Parking Brake Lever (or use Parking Brake Keybind) and then release the Brake Pedals

Releasing the Parking Brake
- just push and then release the Brake Pedals

ACTIVATE TOGA

- either use the TOGA Buttons on the Throttle or the hidden Clickspot on the MCP: little Screw on the left lower Corner, below left F/D Switch

AUTOTHROTTLE ADVICE

- pull your Hardware Throttle into Idle before you begin the Descent, else it could prevent the Autothrottle to go into IDLE and therefore preventing you from easily staying on the Descent Path. If you constantly have to use the Speed Brakes in Descent this could be a Sign of your Hardware Throttle interfering with the Autothrottle.

DISCONNECTING THE AUTOPILOT

- the Autopilot is disconnected with the Disconnect Button on the Yoke. Push the Button a second Time, to silence the Alarm.

NORMAL PROCEDURES

SAFETY INSPECTION & POWER UP

FMC PMDG Options | Panel State	AS DES
Tablet - Ground Operations	AS DES
- set GPU | ACU | Doors | Stairs | Jetway | Maintenance	

SAFETY INSPECTION & POWER UP

OVERHEAD PANEL

Battery Switch	**ON**
Bus Tie Switches	BOTH AUTO
Hydraulic Panel	SET
C1 & C2 Elec Pump Switches	BOTH OFF
Demand Pump Selectors	ALL 4 OFF
Wiper Selectors	BOTH OFF
NAV Lights Switch (OH)	**ON**

PEDESTAL PANEL

Landing Gear Lever	DOWN
Alernate Flaps Selector	OFF
Parking Brake	AS DES | SET
Throttles	IDLE / REV STOWED
Fuel Control Switches	CUT-OFF

OVERHEAD PANEL

EXT PWR Primary & Secondary	AS DES
APU	**START**
- APU selector → hold START → release to ON	
- wait for APU Power to come live	
- verify APU Generator Switches = ON	
EXT PWR Primary & Secondary	OFF

PREFLIGHT - Part I

OVERHEAD PANEL SCAN

(top to bottom, left to right)

Maintenance Panel	ALL GUARDS CLOSED & LIGHTS OFF

LEFT ROW

ADIRU Switch	**ON**
Thrust Asym Comp	AUTO
Primary Flight Computers	AUTO & GUARDED | no „DISC“
Electrical Panel	**SET**
Battery Switch	ON
IFE/PASS Seats	ON
Cabin Utility	ON
APU	START (if not already)
APU Generator Switches	ON
L & R Bus Tie Switches	AUTO
EXT PWR Switches	OFF
L & R Main Generators	ON
L & R Backup Generators	ON
L & R Drive Disc Swicthes	„DRIVE“ & GUARDED
Left Wiper	OFF

LEFT CENTER ROW

Voice Recorder	AUTO
Emergency Light	**ARMED & GUARDED**
Service Interphone	OFF
Pass Oxygen	GUARDED (don´t touch button)
Window Heat	**ALL 4 ON | no „INOP“**
Ram Air Turbine	GUARDED | no „UNLKD“
Hydraulic Panel	SET
L & R Primary Eng Pump	ON | but „FAULT“
C1 & C2 Elec Pump Switches	BOTH OFF
Demand Pump Selectors	ALL 4 OFF
No Electronics | Smoking	ON
Seat Belts	OFF
Left Lighting Panel	**AS DES**
Interior Lights	AS DES
Storm Light	OFF
Landing Light Switches	OFF

RIGHT CENTER ROW

Cargo Fire Arm Switches	OFF
Cargo Fire Discharge Switch	GUARDED
APU Fire Discharge Handle	IN
Fire / Overheat Test Button	PRESS→VERIFY→PRESS
Engine Panel	SET
EEC Mode Switches	NORM & GUARDED
START Selectors	NORM
Autostart	ON
Fuel & Jettison Panel	SET
Fuel Jettison L & R Nozzles	OFF | no „VALVE“
Fuel to Remain	OFF | IN
Fuel Jettsion ARM	OFF | no „FAULT“
Crossfeed Switches	OFF
Fuel Pump Switches	OFF | „PRESS“
- FWD PUMP "PRESS"	Light is OFF if APU is on
Anti-Ice Selectors	ALL 3 AUTO
Right Lighting Panel	**AS DES**
Indicator Light Switch	HOLD TEST→VERIFY→RELEASE
Indicator Light Switch	DIM AS DES
NAV Light	**ON**
Logo & Wing Light	AS DES
Beacon	OFF
Taxi | Runway Turnoff | Strobe Lights	OFF

RIGHT ROW

Air Condition Panel	**SET**
Equipment Cooling	AUTO | no „OVRD“
Gasper	ON
Recirc Fans	ON | OFF if ACU is connected
Temp Selectors	AS DES
L & R Pack	AUTO | no „OFF“
L & R Trim Air	ON | no „FAULT“
L, C & R Bleed Isolation	AUTO | no „CLOSED“
L & R Engine Bleed	ON | but „OFF“
APU Bleed	AUTO | no „OFF“
Pressurization Panel	**SET**
FWD & AFT Outflow Valve	AUTO | no „MAN“
Landing Altitude Selector	OFF | IN
Wiper Right	OFF

FMC SETUP - Part I - with SimBrief

ATIS & ATC Clearance (IFR)	**AS REQ**

TABLET- EFB

- import SimBrief and check OFP
- load Weather if desired

FMC - IDENT PAGE

→ Menu → FMC (→ INDEX → IDENT)
- verify Data

FMC - POS INIT PAGE

→ POS INIT from IDENT Page
- or → Menu → FMC → INDEX → POS INIT
- set GPS POS with LSK4R → LSK5R

FMC - ROUTE - Page

→ ROUTE from POS INIT Page
→ ROUTE REQUEST → choose SimBrief Route
→ SET PAYLOAD and → SET FUEL
→ SELECT RTE (back to RTE1 Page) → ACTIVATE + EXEC
→ ROUTE UPLINK → LOAD (wait finish Loading)
→ ACTIVATE + EXEC

FMC - DEP/ARR - Page

→ select DEPARTURE & ARRIVAL
→ (optional) select ARRIVAL (optional later in flight)

FMC - LEGS - Page

→ check Waypoints
→ clear all ROUTE DISCONTINUITIES
→ (optional) clear all VECTORS (recommended for Beginners)
→ to clear → select next Waypoint LSK then click LSK to replace
→ **important! ACTIVATE + EXEC after changes are made**

FMC SETUP - Part I - without SimBrief

ATIS & ATC Clearance (IFR) **AS REQ**

FMC - IDENT PAGE
→ Menu → FMC (→ INDEX → IDENT)
- verify Data

FMC - POS INIT PAGE
→ POS INIT from IDENT Page
- or → Menu → FMC → INDEX → POS INIT
- set GPS POS with LSK4R → LSK5R

FMC - ROUTE - Page
→ ROUTE from POS INIT Page
→ enter ORIGIN & DEST
→ ACTIVATE + EXEC

FMC - DEP/ARR - Page
→ select DEPARTURE & ARRIVAL
→ (optional) select ARRIVAL (optional later in flight)

FMC - LEGS - Page
→ enter Enroute Waypoints (optional - skip this step)
→ clear all ROUTE DISCONTINUITIES
→ (optional) clear all VECTORS (recommended for Beginners)
→ to clear → select next Waypoint LSK then click LSK to replace
→ **important! ACTIVATE + EXEC after changes are made**

FMC - MENU - FS ACTION - Page
→ MENU → FS ACTIONS
→ FUEL → set Pounds or Percent
or use Short | Medium | Long Range
→ RETURN
→ PAYLOAD → use Max | Empty | Random
or set PAX & CARGO manually

FMC SETUP - Part II - Performance

Do this after Refuel & Boarding is complete

TABLET- PERFORMANCE TOOL (optional)
→ Takeoff Performance Page
→ enter Data or Import Data
→ Calculate

FMC - PERF INIT - Page
→ INIT REF → (INDEX →) PERF INIT
→ set ZFW (two Clicks on LSK3L)
→ enter Reserves (Fuel) (e.g.20)
→ either: enter CRZ ALT & COST INDEX (0-9999) manually
or: use REQUEST LSK5L and then ACCEPT
if unsure what Cost Index to use → enter 85

FMC - THRUST LIMIT - Page
→ THRUST LIM from PERF INIT PAGE
→ either: enter SEL and choose TO|CLB as per Performance Tool
or: same as Oat to SEL and choose TO | CLB with LSK2L & 2R

FMC - TAKEOFF REF - Page
→ TAKEOFF form THRUST LIM Page
→ optional: enter TAKEOFF REF Page 2 (Next page)
enter WIND | SLOPE COND | REF OAT
verify or set Accel & Reductions Heights
→ back to TAKEOFF REF Page 1
→ enter FLAPS as per Performance Tool or enter 5
→ set CG TRIM (two Clicks on LSK3L)
→ verify REF SPDS is ON (LSK5R
→ verify GRWT in Line 4 is correct, else enter correct TOGW
→ verify and set V1,VR & V2 (each with a Click on its LSK)

PREFLIGHT - Part II

GLARESHIELD

CPT EFIS Panel	**SET**
Minimums Reference Selector	AS DES
Altimeter Baro Reference	**SET LOCAL**
ND TFC | WXR | TERR	OFF
FPV | MTRS	AS DES
Mode | Range	AS DES
Mode Control Panel (MCP)	**SET**
Flight Director	**BOTH ON**
- verify FMA TOGA | TOGA Mode	
L & R Autothrottle Switches	ARM
Speed Selector	**V2+10**
Modes	**PRESELECT LNAV & VNAV**
Autopilot DISENG Bar	UP
HDG Selector	TAKEOFF HEADING
Altitude Selector	**CRUISE or CLEARED ALT**
IAS↔MACH | HDG↔TRK | V/S↔FPA	AS DES
F/O EFIS Panel (optional)	SET

LEFT SIDE & LEFT FORWARD PANEL

Oxygen Mask	TEST
FWD Panel Brightness Controls	**AS DES**
Heaters	AS DES
Nav | Display Ctrl | Air Data Source - Switches	ALL 3 OFF
Clock	CHECK | SET
Inboard Display Selector	MFD
Heading Reference	GUARDED | NORM
PFD/ND	CHECK

CENTER FORWARD PANEL

Standby Instruments	**CHECK | SET**
G/S Inhibit	OFF
Flap Override	OFF & GUARDED
Gear Override	OFF & GUARDED
Terrain Override	OFF & GUARDED
Landing Gear Lever	**DOWN**
Alternate Gear Switch	GUARDED
Autobrake Selector	**RTO**
EICAS	**CHECK**
Gear Down	CHECK GREEN
Fuel Quantity	CHECK
Cancel/Recall	CHECK
Lower Center Display	**CHECK**
Secondary Engine Indications	CHECK
Status Page	CHECK
Checklist Page	RESET → RESET ALL
Center Display Ctrl	OFF
Upper & Lower Center Display Brightness	AS DES
FMC Selector (right fwd panel)	AUTO

CENTER PEDESTAL

Alternate Pitch Trim Levers	NEUTRAL
Speedbrake Lever	**DOWN | FWD**
Thrust Levers	**IDLE | REV STOWED**
Flap Lever	**IN AGREEMENT | UP**
Parking Brake	**SET**
Stabilizer Cutout Switches	GUARDED
Fuel Control Switches	CUTOFF & NOT LIT
Alternate Flaps Arm Switch	OFF
Alternate Flaps Selector	OFF
All Audio Ctrl Panel	AS DES
Eng Discharge Light	EXTINGUISHED
Eng Fire Handles	IN | NOT LIT
Weather Radar	SET
Weather Radar Test	PRESS → VERIFY
Weather Radar Auto	AS DES | AUTO
Transponder Panel	**SET**
Alt Source	NORM
Squawk	**SET**
Mode	**STBY**
TCAS	AS DES | N - REL
Evacuation Command	GUARDED
Floor & Aisle Stand Lights	AS DES
Observer Audio	NORM

PREFLIGHT - Part III

RIGHT SIDE & RIGHT FORWARD PANEL (optional)	
Oxygen Mask	TEST
FWD Panel Brightness Controls	AS DES
Heaters	AS DES
Nav | Display Ctrl | Air Data Source - Switches	ALL 3 OFF
Clock	CHECK | SET
Inboard Display Selector	MFD
FMC Selector	AUTO

call „PREFLIGHT CHECKLIST“

PREFLIGHT CHECKLIST

Oxygen	**TESTED, 100%**
Flight Instruments	**Heading ___ | Altimeter ___**
Parking Brake	**SET**
Fuel Control Switches	**CUTOFF**

BEFORE PUSHBACK / BEFORE START

FMC/CDU Setup	COMPLETE
CDU Pages	TAKEOFF (CPT) | LEGS (F/O)
EICAS	CANCEL → RECALL → CONSIDER
MCP Panel	verify SET
Flight Deck Windows	CLOSED
Flight Deck Door	CLOSED & LOCKED
APU	**verify ON**
EXT Power	**verify OFF**
Hydraulic Panel	**SET**
R Elec Demand	AUTO | no „FAULT“
C1 & C2 Elec Primary	ON | no „FAULT“ at C1
L Elec Demand	AUTO | no „FAULT“
C1 & C2 Air Demand	AUTO | no „FAULT“
Seat Belts Signs	**AUTO**
No Electronics | No Smoking	**ON**
L & R Fuel Pumps	**ON**
Center Fuel Pumps	**OFF if empty, else ON**
Beacon	**ON**
STAB Trim	**SET FOR TAKEOFF**
- if not using Performance Tool → set 5.0	
Rudder & Aileron Trim	ZERO
Transponder	**XPNDR**

Tablet - Ground Operations	**AS DES**
- remove GPU | ACU | Stairs | Jetway | Chocks	
- close Doors	

call „BEFORE START CHECKLIST

BEFORE START CHECKLIST

Flight Deck Door	**CLOSED & LOCKED**
Passenger Signs	**___**
MCP	**SPD ___ | HDG ___ | ALT ___**
Takeoff Speeds	**(from CDU) V1 ___ | VR ___ | V2 ___**
CDU Preflight	**COMPLETE**
Trim	**ELEVATOR TRIM ___ | 0 | 0**
Taxi & Takeoff Briefing	**COMPLETE**
Beacon	**ON**

ENGINE START |PUSHBACK

ATC Clearance (Pushback/Start)	**AS REQ**
Pushback	**AS REQ**
Parking Brake	AS REQ
START 1st ENGINE	
Lower Center Display	ENG PAGE
Start Selector	L or R START
Respective Fuel Control Switch	RUN
EICAS & Lower Center Display	MONITOR INDICATIONS
Oil Pressure	verify INCREASING, else abort Start
START 2nd ENGINE	
Start Selector	L or R START
Respective Fuel Control Switch	RUN
EICAS & Lower Center Display	MONITOR INDICATIONS
Oil Pressure	verify INCREASING, else abort Start

BEFORE TAXI

APU	**OFF**
Generators	verify ON | no „FAULT“
Left & Right Start Selector	verify NORM
Engine Anti-Ice	AS REQ | AUTO
Packs	verify ON
Auto Brake	**verify RTO**
Flaps	**SET FOR TO**
Flight Controls	**verify FREE & FULL MOVEMENT**
EICAS	RECALL → CONSIDER
Pushback Tug	**REMOVED**

call „BEFORE TAXI CHECKLIST“

ATC Clearance (Taxi)	**AS REQ**
Taxi Lights	**ON**
Runway Turnoff Lights	AS REQ

BEFORE TAXI CHECKLIST

Anti-Ice	**___**
Recall	**CHECKED**
Auto Brake	**RTO**
Flight Controls	**CHECKED**
Ground Equipment	**CLEAR**

TAXI

- release Parking Brake
- only slowly apply power
- max. 30 kts on straights & max. 8-10 kts in turns
- test Brakes & Steering
- check Flight & Engine Instruments

BEFORE TAKEOFF

Autobrake	**verify RTO**
Flaps	**verify SET FOR T.O.**
Speed Brakes	**DOWN | FWD**
Transponder	**TA ONLY or TA/RA**
WX Radar	**AS REQ**
MCP	**SET**
Autothrottle	**ARM**
FMA	verify „TOGA | TOGA“ active (green)
FMA	verify „LNAV | VNAV“ armed (white)
ND WXR | TFC | TERR (EFIS Panel)	AS DES
CDU Pages	TAKEOFF (CPT) | LEGS (F/O)
EICAS	CANCEL → RECALL → CONSIDER
Cabin Crew	NOTIFY

call „BEFORE TAKEOFF CHECKLIST“

ATC Clearance (Departure)	**AS REQ**
Start Replay-Tool	***IF REQ***
Landing Lights	**ON**
Runway Turnoff Lights	**ON**
Strobe Lights	**ON**

BEFORE TAKEOFF CHECKLIST

Flaps	**SET FOR T.O. | 5**

TAKEOFF

- line up and brake
- Throttle → 55% N1
- press TOGA Button (Throttle or Clickspot on MCP)
- verify Autothrottle active and Takeoff power is set
- release Brakes
- @ V1 → start slightly pulling the Yoke back
- @ VR → start pulling more to actual rotate slowly
- maintain ~ 12° Pitch untill Lift-Off
- @ positive Rate of Climb → Gear UP
- follow Flight Director
- @ 200 ft AGL → Autopilot ON
- if flying manually → trim per Cyan FBW Marker on SPD Band
- @ 400 ft AGL → select Roll & Pitch Mode (if not preselected)

ABOVE 1.500 ft AGL (Acceleration/Thrust Red Height)

- verify Climb Thrust is set
- Flap Retraction per Schedule

FLAP RETRACTION SCHEDULE

Current Flaps	Current Speed	Select Flaps	Select Speed
20	at or above 20*	15	at or above 15*
15	at or above 15*	5	at or above 5*
5	at or above 5*	1	at or above 1*
1	at or above 1*	UP	at or above UP*

* This is the Green Marker on the Speed Band in the PFD

AFTER TAKEOFF | CLIMB

Landing Gear	verify UP
Flaps	verify UP
Autobrake	verify OFF
Engine Anti-Ice	AS REQ/AUTO
Transponder	TA/RA

call „AFTER TAKEOFF CHECKLIST“

@ 10.000 ft

Landing Lights	OFF
Taxi & Runway Turnoff Lights	OFF
Passenger Signs	AS DES
ND WXR | TFC | TERR (EFIS Panel)	AS DES

@ TRANSITION ALTITUDE

Altimeters	SET STD

AFTER TAKEOFF CHECKLIST

Landing Gear	**UP**
Flaps	**UP**

CRUISE

Seat Belt Signs	AS DES
Pressurization	CHECK
Flight Progress	MONITOR
Top Of Descent	VERIFY AND CROSS CHECK

Estimated Top Of Descent (TOD) Formula:
(CRZ ALT - DEST ALT)/1000 x 3 + 20 = TOD in NM Out

~ 50 NM PRIOR TO TOD

- you can see the Distance to the TOD on the FMC PROG Page

Tablet Landing Performance	CALCULATE | optional
FMC DEP/ARR Page	CHECK | SET ARRIVAL
FMC Approach Page	CHECK & SELECT CONFIG
Minimums	SET
- if unsure or without Maps → use 200 ft Radio Height	
MCP Altitude Select	FAF ALTITUDE | do not push Btn

FAF = Final Approach Fix, a Waypoit where you typically latest catch the Glide Slope, some 6-10 NM before Destination

Autobrake	AS DES | 2 or 3
EICAS	CHECK RECALL
ILS Frequency | RAD NAV Page	CHECK | SET

call „DESCENT CHECKLIST“

DESCENT CHECKLIST

EICAS RECALL	**CHECK**
Notes	**CHECK**
Autobrake	**???**
Landing Data	**VERF ??? | MINIMUMS ???**
Approach Briefing	**COMPLETE**

DESCENT

ATC Clearance | ATIS	**AS REQ**

- verify that your Hardware Thrust Lever is in IDLE
- watch for „Drag Required“ Message in FMC
- use Speed Brakes if necessary

@ TOP OF DESCENT

MCP Altitude Select	CHECK | SET
Desecent	verify is initiated automactically in VNAV
- else manually initiate Descent VNAV | FLC | V/S	
Seat Belt Signs	AS DES

@ 10.000 ft \| FL100

Speed	verify max. 250 KIAS
Landing Lights	ON
Logo Lights	AS DES
Taxi & Runway Turnoff Lights	OFF
Seat Belt Signs	ON
No Electronics | No Smoking	ON
ND WXR | TFC | TERR (EFIS Panel)	AS DES
Cabin Crew	NOTIFY
ILS Frequency | RAD NAV Page	CHECK | SET
Pressurization	CHECK

@ TRANSITION FLIGHT LEVEL

Altimeters	SET LOCAL

call „APPROACH CHECKLIST“

APPROACH CHECKLIST

Altimeters	____

FLAP EXTENSION SCHEDULE

Current Flaps	Current Speed	Select Flaps	Select Speed
UP	at or above UP*	1	at or above 1*
1	at or above 1*	5	at or above 5*
5	at or above 5*	15	at or above 15*
15	at or above 15*	20	at or above 20*
20	at or above 20*	Landing Flap	VERF+CORR**

* This is the Green Marker on the Speed Band in the PFD
**CORR = Wind Correction - if unsure → use 5 KNOTS

INSTRUMENT APPROACH & LANDING

- plan to be in Config Flaps 15 | Gear UP and at ~ 170 KIAS at FAF
- start descelerating rather early than late
- verify that your Hardware Thrust Lever is in IDLE
- use Speed Brakes if necessary
- plan to first intercept Localizer, then the Glide Slope
- you can see the Distance to the Destination on the FMC PROG Page

25 NM OUT | ~ 8.000 ft AGL

Altimeter — **LOCAL**
Autobrake — **SET**
Landing Lights — **ON**
ILS Frequency | RAD NAV Page — **CHECK | SET**

- switch to Manual Speed Mode & set UP Speed
- @ UP Speed → select FLAPS 1 & set 1 Speed
- @ 1 Speed → select FLAPS 5 & set 5 Speed
- @ 5 Speed → select FLAPS 15 & set 170 KIAS
- if 170 KIAS is below 15 Speed → set FLAPS 20

@ LOCALIZER INTERCEPT COURSE

- activate MCP LOC Mode & verify in FMA „LOC“ (white or green)

@ ~12 NM OUT | ~ 4.000 ft AGL

- activate MCP APP Mode & verify in FMA „G/S“ (white or green)

ON GLIDE SLOPE or LATEST 8 NM OUT

- select Flaps 20
- select GEAR DOWN
- select LADNING FLAPS & set VRFE+CORR in SPD
- arm SPEED BRAKES
- preselect Missed Approach Altitude (only if you have the time)

call „LANDING CHECKLIST“

Speed Brakes — **ARMED**
Landing Gear — **DOWN**
Flaps — **SET FOR LANDING | 25 or 30**
Autobrakes — **SET**

@ 1.000 ft AGL

- be stable at LOC and G/S and not more then VREF +20
- *verify „LAND 3“ and FMA „Rollout“ and „Flare“ armed*
- *either leave AUTOPILOT ON for CAT III AUTOLAND or DISCONNECT AUTOPILOT for manual Landing*
- *(optional if manual Landing) AUTOTHROTTLE OFF and set Thrust manually to maintain VREF+CORR manually*

@ TRESHOLD

- @ 30 ft → THROTTLE → IDLE
- @ 30 - 20 ft → flare to ~ 3-4° NOSE UP
- touch down with Main Gear, then lower the Nose Gear
- verify Speed Brakes | Spoilers are OUT
- set REVERSE THRUST
- @ 60 KIAS → REVERSE IDLE
- @ 40-30 KIAS → brake manually to disable AUTOBRAKE
- turn Autopilot OFF before leaving the Runway (Autoland only)

LANDING CHECKLIST

Speed Brakes — **ARMED**
Landing Gear — **DOWN**
Flaps — **SET FOR LANDING | 25 or 30**

GO AROUND

- use TO/GA Button
- picth Up and follow Flight Director
- set FLAPS 20
- at postive rate → GEAR UP
- follow Flight Director
- @ 200 ft AGL → Autopilot ON
- if flying manually → trim per Cyan FBW Marker on SPD Band
- @ 400 ft AGL → select Roll & Pitch Mode

ABOVE 1.500 ft AGL (Acceleration/Thrust Red Height)

- verify Climb Thrust is set
- Flap Retraction per Schedule

AFTER LANDING / CLEAR OF RUNWAY

Landing Lights	OFF
Strobe Lights	OFF
Logo Lights	AS REQ | OFF
Taxi Lights	ON
Runway Turnoff Lights	AS DES
Speedbrake	DOWN | FWD
Auto Brakes	OFF
Flaps	UP
Transponder Mode	AS REQ | XPNDR
APU	AS DES | START
Anti-Ice	AS REQ
ND WXR | TFC | TERR (EFIS Panel)	OFF

PARKING / SHUT DOWN

Parking Brake	SET
APU	AS DES | verify ON
Fuel Control Switches	CUTOFF
Electric Hydraulic Pumps	OFF
Fuel Pumps	OFF
Anti-Ice	AUTO
Beacon	OFF
Pass Signs	OFF
Flight Director	OFF
Transponder	STBY

call „SHUTDOWN CHECKLIST“

Tablet - Ground Operations — **AS DES**
- disarm Doors
- set Wheel Chocks & select Stairs | Jetway
- select GPU | ACU as desired

APU / EXT Power	AS REQ
Cockpit Door	UNLOCK
Lower Center Display	STAT PAGE | CONSIDER

SHUTDOWN CHECKLIST

Hydraulic Panel — **SET**
Fuel Pumps — **OFF**
Flaps — **UP**
Parking Brake — **AS REQ**
Fuel Control Switches — **CUTOFF**
Weather Radar — **OFF**

SECURING THE AIRCRAFT	
ADIRU Switch	OFF
Emergency Exit Lights	OFF
Packs Switches	OFF
call „SECURE CHECKLIST“	
APU	OFF
EXT Power	OFF
Battery Switch	OFF
Tablet - Ground Operations	**AS DES**

SECURING CHECKLIST	
ADIRU	**OFF**
Emergency Lights	**OFF**
Packs	**OFF**