Provisioning Jig v3 Documentation

Project by Jesse Jabez Arendse
Project for UCT EEE Department - Robyn Verrinder & Justin Pead

Host Machine Details:

Raspberry Pi 3B+ with Raspberry Pi OS 64-bit, with 16GB SD Card, SSH and VNC enabled

Username: ProvisioningJig Password: ProvisioningJig Hostname: raspberrypi

System Functions:

- Auto login and run provisioning script on startup
- Automatically detect which device is plugged in, and the version
- Flash the device via SWD, with its specific binary file
- Upgrade the STLink to a recent usable version, this step needed to be done with the STSW-LINK007 software package, but has been eliminated details found in the project report

For updates / reproduction:

- main script is located at /Desktop/ProvisioningJig_Code/newMain.py
- binary file selection can be done from the telnet_commands.py file
- use Win32DiskImager to create an .img of the ProvisioningJig's SD Card, and then PiShrink to compress it (optional, but saves a few GB and time)
- use Win32DiskImager to flash the desired .img file to an SD Card
- assemble the Jig according to the assembly guide