Model 33

Twin Syringe Pump User's Manual

Syringe Pump Model 33 MA1 55-3333





WEEE/RoHS Compliance Statement

EU Directives WEEE and RoHS

To Our Valued Customers:

We are committed to being a good corporate citizen. As part of that commitment, we strive to maintain an environmentally conscious manufacturing operation. The European Union (EU) has enacted two Directives, the first on product recycling (Waste Electrical and Electronic Equipment, WEEE) and the second limiting the use of certain substances (Restriction on the use of Hazardous Substances, RoHS). Over time, these Directives will be implemented in the national laws of each EU Member State.

Once the final national regulations have been put into place, recycling will be offered for our products which are within the scope of the WEEE Directive. Products falling under the scope of the WEEE Directive available for sale after August 13, 2005 will be identified with a "wheelie bin" symbol.

Two Categories of products covered by the WEEE Directive are currently exempt from the RoHS Directive – Category 8, medical devices (with the exception of implanted or infected products) and Category 9, monitoring and control instruments. Most of our products fall into either Category 8 or 9 and are currently exempt from the RoHS Directive. We will continue to monitor the application of the RoHS Directive to its products and will comply with any changes as they apply.



- Do Not Dispose Product with Municipal Waste
 - Special Collection/Disposal Required

SUBJECT

Warranty and Repair Information	2
General Safety Summary	3
Specifications	
Features	
Initial Setup	
Loading Syringes	
User Interface:	
Description of Keys	9
Entering Data	
•	10
Operation: Diameters	44
Pumping Rates	
Selecting the Run Mode	
Selecting the Pumping Directions	
Running the Pump	
Single Syringe Operation	
Valve Control Box	
Pinch Valve Connectors	
External Control and Interfaces:	
Attaching/Configuring a Pump Chain	15
TTL Devices	
Foot Switch Input	
Pump Chain Commands:	
Pump Commands and Responses	18
Pump Chain Error Messages	21
Appendices:	
A. Syringe Diameters in mm	
B. Nominal Min/Max Flow Rates	
C. Command Information	
D. RS-232 Specifications	
E. TTL Connector Specifications F. Pump to PC Connection	
G. Maintenance	
H. Troubleshooting	
I. Accessories	

PAGE NO.

Serial Numbers

All inquires concerning our product should refer to the serial number of the unit. Serial numbers are located on the rear of the chassis.

Calibrations

All electrical apparatus is calibrated at rated voltage and frequency. While the flow will stay calibrated, the peak will vary.

Warranty

Harvard Apparatus warranties this instrument for a period of two years from date of purchase. At its option, Harvard Apparatus will repair or replace the unit if it is found to be defective as to workmanship or material.

This warranty does not extend to damage resulting from misuse, neglect or abuse, normal wear and tear, or accident. This warranty extends only to the original customer purchaser.

IN NO EVENT SHALL HARVARD APPARATUS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow exclusion or limitation of incidental or consequential damages so the above limitation or exclusion may not apply to you. THERE ARE NO IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR USE, OR OF ANY OTHER NATURE. Some states do not allow this limitation on an implied warranty, so the above limitation may not apply to you.

If a defect arises within the two-year warranty period, promptly contact *Harvard Apparatus, Inc. 84 October Hill Road, Building 7, Holliston, Massachusetts 01746-1371* using our toll free number 1-800-272-2775, or outside the U.S. 508-893-8999. Goods will not be accepted for return unless an RMA (returned materials authorization) number has been issued by our customer service department. The customer is responsible for shipping charges. Please allow a reasonable period of time for completion of repairs, replacement and return. If the unit is replaced, the replacement unit is covered only for the remainder of the original warranty period dating from the purchase of the original device.

This warranty gives you specific rights, and you may also have other rights which vary from state to state.

Repair Facilities and Parts

Harvard Apparatus stocks replacement and repair parts. When ordering, please describe parts as completely as possible, preferably using our part numbers. If practical, enclose a sample or drawing. We offer a complete reconditioning service.

CAUTION

This pump is not registered with the FDA and is not for clinical use on human patients.



CAUTION: Not for clinical use on human patients.

Please read the following safety precautions to ensure proper use of your syringe pump. To avoid potential hazards and product damage, use this product only as instructed in this manual.

To Prevent Hazard or Injury:

Use Proper Line Cord

Use only the specified line cord for this product and make sure line cord is certified for country of use.

Ground the Product

This product is grounded through the grounding conductor of the power cord. To avoid electric shock, the grounding conductor must be connected to earth ground. Before making any connections to the input or output terminals of the product, ensure that the product is properly grounded.

Make Proper Connections

Make sure all connections are made properly and securely. Any signal wire connections to the unit must be no longer than 3 meters.

Observe all Terminal Ratings

Review the operating manual to learn the ratings on all connections.

Use Proper Fuse

Use only specified fuses with product.

Avoid Exposed Circuitry

Do not touch any electronic circuitry inside of the product.

Do Not Operate with Suspected Failures

If damage is suspected on or to the product do not operate the product. Contact qualified service personnel to perform inspection.

Place Product in Proper Environment

Review the operating manual for guidelines for proper operating environments.

Observe all Warning Labels on Product

Read all labels on product to ensure proper usage.





Harvard Pump 33 Specifications

Type Microprocessor dual drive, single syringe, infuse/withdraw

Accuracy $\pm 0.35\%$ Reproducibility $\pm 0.1\%$

Syringe:

Type Plastic, glass or stainless steel

Size Minimum 0.5 μl Size Maximum 140 ml

Flow Rate:

 $\begin{array}{ll} \mbox{Minimum} & 0.0004 \ \mu \mbox{ l/hr} \\ \mbox{Maximum} & 106.6 \ ml/min \end{array}$

Non Volatile Memory Storage of all settings
RS-232 RJ11-4 conductor
TTL 9-pin connector

Average Linear Force 57 lbs

Drive Motor 2 motors, each 0.9° step angle motor

Motor Drive ControlMicroprocessor controlled from 1/2 to 1/4 microsteppingMotor Steps per1,600 steps at 1/2 stepping or 3,200 steps at 1/4 stepping

Rev. of Leadscrew

Step Resolution 0.33 µm/step

Step Rate:

 Minimum
 27.3 sec/step

 Maximum
 416.7 μ sec/step

Pusher Travel Rate:

 Minimum
 0.726699 μm/min

 Maximum
 95.25 mm/min

 Power
 45 W, 1.0 A fuse

Voltage Range 95 to 130 VAC, 60 Hz; 220 to 260 VAC, 50 Hz, selectable

Dimensions, H x W x D 15.2 x 31.1 x 28.6 cm (6 x 12.5 x 11.25 in)

Weight 6.8 kg (15 lb)

Timing Belt Drive 2:1

Lead Screw Pitch 24 threads/inch

Display 5 digits plus 14 indicator LEDS

Pressure and Speed

Pump 33 can deliver up to 106.60 ml/min with a 140 ml syringe, and is capable of pressures of up to 99.5 PSI with a 20 ml syringe.

Independent Syringe Diameters and Rates

In the Proportional Mode, separate syringe types and rates may be set.

Variable Syringes

Enter the inside diameter of the syringes being used.

Modes of Operation

Auto Stop

Both syringes will operate at same rate and stop when either syringe reaches a limit stop.

Continuous Run

With both syringes operating at same rate, when end of travel is reached, the pump automatically reverses the direction of travel for both syringes. The external valves, optionally attached to the syringes, will be automatically activated or deactivated.

Proportional

Pump operates as in Auto Stop, but independent rates and diameters are set for each syringe.

Parallel/Reciprocal Operation

Syringes may pump in the same direction (parallel) or opposite directions (reciprocal).

External Connections

TTL

Allows pump operations to be synchronized with external devices or by a person at a distance from the pump. Direction of pump travel can be set via a TTL pin. Also, TTL pins are used to control an external valve for refilling and provide an output to indicate whether or not the pump is running. Additional TTL pins are available for general use.

RS-232

Multiple pumps can be chained together and remotely controlled from a computer or any device communicating via RS-232.

Non-Volatile Memory

All operational data entered into the pump from the keypad or requested to be saved via RS-232, will be stored. On power up, all settings from when it was powered down will be recalled and the display will blink until the pump receives its first command.

Stall Detection

An optical detector on each motor is used to verify expected movement of the motors. If motor is prevented from turning due to jamming or kinking of the tubing, the pump stops and the display indicates a stall condition by blinking the run light and the syringe direction light of the stalled syringe. Pump 33 employs a microcontroller which controls a small step angle stepping motor that drives a lead screw and half nut. Microstepping techniques are used to further reduce the step angle making flow pulsation negligible. A keypad is used for entry of operating data to the pump or data can be entered via RS-232. The microcontroller calculates the cross-sectional area of the syringe selected and calibrates the flow rate.

- 1. Read the manual.
- 2. Locate the voltage selector switch on the rear panel of the pump and set it to the voltage being used. If other than 115VAC, 60 Hz is being used, the plug must be cut off and an appropriate plug installed, observing the polarity of the international line cord used:

Brown - high Blue - neutral Green - ground

- 3. Turn on main power switch located directly above the line cord on the rear panel. The display will illuminate indicating that the power connections are correct. The flashing display indicates that power has just been applied.
- 4. Load syringes.
- 5. Set syringe ID
- **6.** Set pumping rate(s)
- 7. Select the run mode
- 8. Selecting the pump direction

See section on operation for more information




Figure 1. Syringe Loading

- 1. The syringe holder and pusher block are fitted with movable retaining brackets which hold the syringe barrel and plunger when refilling. When loading the syringe into the pump, it is necessary to adjust these brackets. The pusher block is fitted with a mechanism to release the drive nut from the leadscrew. This allows the block to move freely so the syringe to be loaded.
- 2. Loosen the screws on the syringe block and pusher block to free the retaining brackets (2 and 3, Figure 1)
- **3.** To free the pusher block from the leadscrew, turn the knob on the front of the block (1) until the pin in the knob slips into the hole in the block.
- **4.** The syringe clamp locking screw on the right side of the syringe block (4) should be loosened and the clamp rotated to the side.
- 5. Place the syringe barrel on the syringe holder block and move the pusher block to accommodate the plunger.
- Make sure the syringe barrel flange and the plunger flange are held by the retaining clamps. Press the retaining brackets firmly against the flanges and tighten the retaining screws.
- 7. Rotate the syringe clamp and press down firmly on the syringe barrel. Secure in place by tightening the locking screw (4).

Setting Limit Stops

To set the limit stops, loosen thumbscrews on limit stops and slide stops to desired travel limits (infuse limit & refill), tighten thumbscrews.




Figure 2. User Interface

The user interface consists of a display area and a keypad. The display consists of a 5 digit LED display and 14 LED indicators. The display will be showing either the default display or an informational message. The two syringes are referred to as Syringe 1 and Syringe 2. Syringe 1 is located towards the front and Syringe 2 is located towards the rear. Rate 1 refers to the set flow rate of Syringe 1 and Rate 2 refers to Syringe 2.

By default, the display will be showing Rate 1. Informational messages are shown when the user queries another data value by pressing the corresponding key, or when the pump is alerting the user to a problem. Such problems are a value out of range (oor) or the pump stalling (StALL).

The 14 LED indicators are divided into three sections: *Pump mode and state, syringe directions, and units of value being displayed.* See Figure 2.The LED indicators are as follows:

Pumping Mode and State LEDs	<u>Meaning</u>
Auto Stop	Pump is in Auto Stop mode
Proportional	Pump is in Proportional mode
Continuous	Pump is in Continuous mode
Remote	Pump Chain communication
Run	At least one motor is operating

Syringe Directions LEDs

Comprising of 4 indicators, these LED's indicate the direction of the syringes when illuminated. When <u>blinking</u>, indicates the corresponding motor is stalled, or data pertaining to that syringe is being entered.

<u>Unit LEDs</u>	<u>Meaning</u>
ml/min	milliliters per minute
μl/min	microliters per minute
ml/hr	milliliters per hour
μl/hr	microliters per hour
mm	millimeters




Figure 3. Keypad Interface

The keypad consists of 21 keys used for entering control information and data into the pump. These keys are grouped into 3 sections (see Figure 3 above): *Set keys, toggle keys, and data entry keys.*

Allows modification of a data item in this group of keys. To

Set Keys Set

	modify a data item, press the relevant key after pressing the SET key.
Rate 1	Displays/sets current rate of syringe 1. Also syringe 2 rate if current mode is not Proportional. Scrolls through rate units when setting.
Rate 2	Displays/sets current rate of syringe 2. Scrolls through rate units when setting. Key only valid in Proportional mode.
Diameter 1	Displays/sets current diameter of syringe 1. Also diameter of syringe 2 if current mode is not Proportional.
Diameter 2	Displays/sets current diameter of syringe 2. Key only valid in Proportional mode.
"1"	Used to display and set current Pump Chain address and to scroll through supported baud rates while setting.

Toggle Keys

Parallel/ Reciprocal	Chooses between Parallel and Reciprocal pumping operation.
Select Mode	Chooses between Proportional, Continuous Run, or Auto Stop. LED indicators display current mode. Pump must be stopped to change modes.
Change Direction	Reverses direction of both syringes and sets the valve control output as appropriate.
Run/Stop	Starts or stops the pump.

Data Entry Keys

1 through 0,. Used to facilitate the entering of numeric data values.Enter Stores displayed data value when entering data.

Set Keys

The keys in this group are used to modify or review settings of the pumps control d a t a .

To review the current setting of a control data item, simply hold down the relevant key and the data setting will appear in the display.

To modify a data setting, first press then release the green SET key. The display will then read "SET". Press the key in the SET key group of the data item that is to be modified. The display will show the current setting. Data is entered into the pump by either entering a numerical value or, in the case of entering a baud rate, by scrolling through a menu of choices. Always press ENTER to terminate each data request by the pump.

When entering a numerical value, the LEDs corresponding to the data being entered will blink. Using the yellow data entry keys on the right side of the keypad (see Figure 3) enter the new data value. Up to five digit numbers are accepted for rates and diameters, including up to four decimal places. Entering more than five digits will clear the previous five digits in the display. Press the green ENTER key when the desired data value is displayed.

If the data value entered is outside the pump's operating parameters, the display will read "oor" meaning "Out of Range". Pressing any key will restore the display with the original data value. Enter another data value within the pump's parameters or just press ENTER to reuse the original data value.

The data value entered can be reviewed as described above. *Note: Certain data items bave multiple settings.* For these, after the ENTER key is pressed, the display will prompt you for the additional information. Various rules apply to when, what and how data can be set at various times. See the relevant section for further details.

Toggle Keys

The keys in this group, when pressed successively, select different states. Each state change is accompanied by a corresponding change in status LED display.

To operate, Pump 33 needs to know the diameter(s) of the syringes, the rate(s) of pumping, pumping directions, and the mode of operation. Except for Proportional mode, syringe 2 is assumed to be the same diameter as syringe 1 and will pump at same rate as syringe 1.

Diameters

The pump must be stopped when entering a diameter. Diameter 1 is the diameter of both syringes, except in Proportional mode. In Proportional mode, enter the diameter of each syringe separately; Diameter 1 for syringe 1 and Diameter 2 for syringe 2. When entering a diameter, the 2 direction LEDs corresponding to the syringe and the "mm" LED will blink. Enter the inside diameter of the syringe in millimeters. After a new diameter is entered the corresponding rate is set to 0. This is done for reasons of safety. The maximum diameter is 50 mm. See Appendix A for a list of syringe diameters.

Pumping Rates

Rate 1 is the rate of pumping of both syringes, except in Proportional mode. In Proportional mode, enter the rate of each syringe separately, Rate 1 for syringe 1 and Rate 2 for syringe 2. When entering a rate, the directional LEDs corresponding to the syringe and the current units LED will blink. Use the corresponding rate key (RATE 1 or RATE 2) to scroll through the rate units: ml/min, ml/hr, µl/min and µl/hr. The minimum and maximum rates permitted vary depending on the diameter of the syringe. If an "OOR" message, meaning "Out of Range" is displayed when entering a rate, try using a different syringe for your application.

Selecting the Run Mode

To select the run mode, press the SELECT MODE key to advance the run mode LED indicator. Advance the run mode indicator to the desired mode, either *Auto Stop, Proportional, or Continuous* mode.

Auto Stop Both syringes pump according to DIAMETER 1 and RATE 1

until syringe 1 reaches the limit switch, pump stops.

Proportional Each syringe pumps independently; syringe 1 according to

DIAMETER 1 and RATE 1, syringe 2 according to DIAMETER 2 and RATE 2. When syringe 1 reaches limit switch, pump stops.

Continuous Both syringes pump according to DIAMETER 1 and RATE 1.

When syringe 1 reaches limit switch, the direction of pumping for both syringes is reversed and pumping continues.

The valves, if applicable, are set accordingly.

Selecting the Pumping Directions

Parallel or Reci- Pressing the PARALLEL/ RECIPROCAL key reverses

procal Operation pumping direction of syringe 2.

Change Direction Pressing the CHANGE DIRECTION key reverses the pump-

ing directions of both syringes. When valves are used in the system then the valve(s) setting(s) will be changed simulta-

neously with the change in direction.

Running the Pump

Pressing RUN/STOP key starts pump and illuminates Run LED on display. Pressing RUN/STOP key again stops pump. While running, a new rate can be set. The new rate, for relevant syringe(s), takes effect when ENTER key is pressed. Pump will operate according to selected run mode. Pump can also be started and stopped via external controls. If operation of one of the motors is impeded, both motors will stop and display will read "StALL", with the "run" LED and the direction LED of stalled syringe blinking. Investigate cause of stalling and then press RUN/STOP key to resume pumping.

Single Syringe Operation

To operate only one syringe, select the Proportional mode and set the rate of the syringe not in use to 0. Set the diameter and rate of the other syringe to discard values.

www.harvardapparatus.com

Setting up Valve

Set up consists of:

Model No

1. Pump to Valve Electrical Connections:

The cable fitted with a male 9 pin D-sub connector must be connected to the female D-sub connector on the rear of the Model 33 Syringe Pump. The Valve Power can now be swiched on with the illuminated power On/Off switch on the front valve housing.


2. Valve tubing to syringe hook up:

The valve(s) are de-energized when the front mechanism (#1) is running in the INFUSE direction. The syringe on the #1 mechanism when infusing should therefore be connected to the lower tubing in the pinch valve (see figures on next page).

Continuous Delivery Valve Boxes

Description

WOUGH NO.	Description
55-7000	Pump 33 Continuous Delivery Valve Box, normal pressure, 30 p.s.i. supplied with 3.2 mm ID X 6.4 mm OD (1/8" ID X 1/4" OD) silastic tubing and a connector cable for connection to the syringe pump.
55-7001	Pump 33 Continuous Delivery Valve Box, high pressure, 200 p.s.i. supplied with 6.4 mm (1/4) OD stainless steel tubing with SWAGELOK® fittings and connector cable for connection to the syringe pump.



Valve Shown de-energized

Figure 4. Pinch Valve Connections




Figure 5. Continuous Delivery. Pump in Reciprocal Mode.




Figure 6. Dual Delivery followed by Refill. Pump in Parallel Mode.




Figure 7. Continuous Delivery. Pump in Reciprocal Mode.




Figure 8. Dual Delivery followed by Refill. Pump in Parallel Mode.

Swage lock fittings should be finger tight plus 1-1/4 turns. Tubing is 304, stainless 1/4" OD, wall thickness 0.035"




Figure 9. External Interface

External devices that can be attached to the Pump 33 include external valves, pump chain, and TTL devices. See the appropriate appendixes for specification details on attaching devices.

Attaching a Pump Chain

On the back of the pump are two telephone jack type connectors. These are the RS-232 ports. Looking at the back of the pump, the connector on the right is port 1 and the left is port 2. Attach the RS-232 connectors in the appropriate port according to the following chart:

<u>Device</u>	<u>Port Number</u>
Computer	1
Pump Chain	2

Configuring the Pump Chain

After pressing SET and 1, the Remote LED will blink, indicating the pump is requesting its pump chain configuration:

- First, the display will show "Adr:nn", with the colon blinking, where "nn" is the current pump chain address. Enter the 2 digit address assigned to the pump and press ENTER. Note: Each pump in the chain needs a unique address.
- 2. Next, the display will show "b:nnnn", with the colon blinking, where "nnnn" is the current baud rate. Use the 1 key to select between the supported baud rates: 300, 1200, 2400 and 9600; then press ENTER. Note: Each pump in the chain must have the same baud rate.

See the section on Pump Chain Commands for pump chain control information.

Attaching a Valve Control Accessory Box

Attach the valve control cable to the pump's accessory valve connection (see Figure 9). Refer to the Valve Control Box section.

TTL Devices

The pump does not need to be configured to attach a TTL device. To attach a TTL device, simply plug the appropriate TTL connector into the 9 pin connector on the rear of the pump. See Appendix E for wiring specifications.

Foot Switch Input

Used to start and stop the pump. Pressing the foot switch performs the same function as pressing the RUN/STOP key on the keypad. The foot switch connector allows remote or automated operation of the pump.

Timer Input

Opening the timer input starts the pump. Closing the timer input stops the pump. The timer input allows for an externally controlled pumping interval.

Pumping Direction Input

Sets the direction of pumping. Opening the directional input sets syringe 1 to infuse. Closing the input sets syringe 1 to refill. The pumping direction input is not recognized when data is being entered from the keypad. Syringe 2 changes direction appropriately. Also, the valve control output is set appropriately.

Directional Indicator Output

The Directional Indicator output is an indicator of the direction of pump travel. When the output is a logical high, syringe 1 is set to infuse. A logical low indicates refill. A valve attached to this output enables automatic selecting of infuse and refill vessels.

Running Indicator Output

Provides a signal to another device indicating whether or not the pump is running.

The Pump Chain RS-232 interface is used to enhance the control applications of the Pump 33. This interface allows all control information to be entered into the pump from an external source such as a computer. In addition, this interface allows up to 100 Pump 33's or, in certain cases, other RS-232 devices to be controlled from a single RS-232 communication port on a computer. Assign each pump in the pump chain a unique address from 0 to 99. This address is used to identify which pump is to receive a command and which pump is responding. Configure each pump with its assigned address and the baud rate being used (See External Control & Interfaces). When a pump is sent a command, or a request is made for its prompt, the Remote LED on the display will illuminate, indicating that the pump is receiving pump chain commands. The LED remains illuminated until the pump is turned off or SET and 1 is entered on the keypad, indicating a change in the pump chain configuration.

A pump will not respond to pump chain communication while it is in a setting mode (entered when the user presses the SET key). The pump can still be controlled from the keypad while it is in a pump chain. Control data that is changed via RS-232 will NOT be stored in the pump's non-volatile memory unless requested with the "SAV" command or other data is changed from the keypad. Each command sent to the pump chain is a string of ASCII characters, with leading zero's on numbers and all spaces optional. Numbers are a maximum of five digits. The following symbols are used in describing the commands:

Meaning

<u>5y111001</u>	<u>meaning</u>
[]	optional
{}	select one
I	either-or
f	digits 0-9 or a decimal point
d	digits 0-9
<cr></cr>	carriage return (ASCII 13)
<lf></lf>	line feed (ASCII 10)
<float></float>	ffffff
<integer></integer>	d d d d d
<text></text>	any string of ASCII characters
	36
Command Formats	<u>Meaning</u>
<u>Command Formats</u> <cr></cr>	Stops all pumps. All pumps on the pump
	Stops all pumps. All pumps on the pump
	Stops all pumps. All pumps on the pump chain interpret this as a stop command, but
<cr></cr>	Stops all pumps. All pumps on the pump chain interpret this as a stop command, but do not respond with a prompt.
<cr></cr>	Stops all pumps. All pumps on the pump chain interpret this as a stop command, but do not respond with a prompt. Request for prompt. The pump with the
<cr> pump address, <cr></cr></cr>	Stops all pumps. All pumps on the pump chain interpret this as a stop command, but do not respond with a prompt. Request for prompt. The pump with the indicated address responds with its prompt.
cr> pump address, <cr> optional pump address,</cr>	Stops all pumps. All pumps on the pump chain interpret this as a stop command, but do not respond with a prompt. Request for prompt. The pump with the indicated address responds with its prompt. Sends a command to a pump. The pump
cr> pump address, <cr> optional pump address,</cr>	Stops all pumps. All pumps on the pump chain interpret this as a stop command, but do not respond with a prompt. Request for prompt. The pump with the indicated address responds with its prompt. Sends a command to a pump. The pump with the indicated address executes the
cr> pump address, <cr> optional pump address,</cr>	Stops all pumps. All pumps on the pump chain interpret this as a stop command, but do not respond with a prompt. Request for prompt. The pump with the indicated address responds with its prompt. Sends a command to a pump. The pump with the indicated address executes the command then responds with its prompt.

After each command is received and executed, the pump acknowledges the command with a prompt. Preceding the prompt will be the text response, if applicable. The text response will be one or more lines of ASCII text, each preceded by a line feed and terminated by a carriage return:

```
<lf>, <text>, <cr>
```

Symbol

A prompt is a string of ASCII characters sent by a pump, indicating the pump's address and its present state:

<lf>, 1 or 2 digit address, prompt character

Prompt Characters	Meaning
:	Pump stopped
>	Syringe 1 infusing
<	Syringe 1 refilling
*	Pump stalled

Pump Commands and Responses

RUN

Starts pumping according to the present setting of the pump. If pump already pumping, a "Not Applicable" error is returned.

STP

Stops pump if it was running. If pump already stopped, a "Not Applicable" error is returned.

RAT [{A | B}] [[<float> [<units>]]

Request to set or query infusion rate settings.

Set syringe 1 rate:

RAT rate

RAT rate units

RAT A rate

RAT A rate units

Set syringe 2 rate (only valid in proportional mode):

RAT B rate

RAT B rate units

Rate is of the format: ffffff

<u>Meaning</u>
μl/mn
μl/hr
ml/mn
ml/hr

Rate 2 is only accepted when mode is *Proportional*. If rate is accepted and valid, rate will become the new rate. If the rate is invalid, an "Out Of Range" error is returned.

Query syringe 1 rate:

RAT

RAT A

Query syringe 2 rate (only valid in proportional mode):

RAT B

Response is of the following format:

f f f f f f <units>

Where units are one of the following:

ml/mn, ml/hr, µl/mn, µl/hr

Publication 5390-001-REV-D

DIA [{A | B}] [<float>]

Request to set or query syringe diameter settings.

Set syringe 1 diameter:

DIA diameter

DIA A diameter

Set syringe 2 diameter (only valid in proportional mode):

DIA B diameter

Corresponding syringe's rate will be zeroed.

Diameter is of the format:

ffffff

Units are millimeters.

Diameter 2 is only accepted when mode is *proportional*. If diameter is accepted and valid, diameter will become the new diameter. Diameter <u>will not</u> be accepted if the pump is running and a "Not Applicable" error is returned. If the diameter is invalid, an "Out Of Range" error is returned.

Query syringe 1 diameter:

DIA

DIA A

Query syringe 2 diameter (only valid in proportional mode)

DIA B

Response is of the following format:

ffffff

Units are millimeters.

MOD [{AUT | PRO | CON}]

Request to set or query pumping mode

SET:	Command	Meaning
	MOD AUT	Puts pump in Auto Stop mode
	MOD PRO	Puts pump in Proportional mode
	MOD CON	Puts pump in Continuous mode

If pump is running, command will not be accepted and a "Not Applicable" error is returned.

Query:

MOD

Possible Responses	Meaning
AUT	Auto Stop mode
PRO	Proportional mode
CON	Continuous mode

DIR [{INF | REF | REV}]

Request to set or query pumping direction of syringe 1.

SET:	Command	<u>Meaning</u>
	DIR INF	Sets syringe 1 pumping direction to infusion
	DIR REF	Sets syringe 1 pumping direction to refill
	DIR REV	Reverses pumping direction of syringe 1

Direction of syringe 2 is set appropriately.

Query pumping direction of syringe 1:

DIR

Response will be one of:

INFUSE

REFILL

PAR [{ON | OFF}]

Request to set or query Parallel or Reciprocal setting.

SET: <u>Command</u> <u>Meaning</u>

PAR ON Sets syringes to parallel pumping direction.
PAR OFF Sets syringes to reciprocal pumping direction.

Direction of syringe 2 changes appropriately, while direction of syringe 1 does not change.

Query:

PAR

Possible Responses Meaning
ON Parallel
OFF Reciprocal

IN <d>

Request to read in the TTL logic level at the specified pin, "d", on the external 9 pin D-SUB connector.

Valid pin numbers for input are:

6, 7 and 8

Possible Responses	<u>Meaning</u>
ON	TTL level high
OFF	TTL level low

If the pin specified is invalid, a "Not Applicable" error is returned.

$OUT < d > = {ON | OFF}$

Request to set the TTL logic level at the specified pin "d" on the external 9 pin D-SUB connector.

ON - Set pin to a *logic high* OFF - Set pin to a *logic low*

Valid pin numbers for output are:

A and 5

If the pin specified is invalid, a "Not Applicable" error is returned.

SAV

Request to save pump settings in the pumps non-volatile memory (NOVRAM). Normally, settings changed from a pump chain are not stored in the pump's NOVRAM and are lost after power down.

VER

Request *for version of pumps* embedded software. Response for the present version will be: 33V2.0

Publication 5390-001-REV-D

Pump Chain Error Messages

Error messages are in the format:

<lf>, <message>, <cr>,

and are followed by a prompt. <Message> is one of the following:

<u>Possible Responses</u>	Meaning
?	Syntax error in a received command
NA	Command "Not Applicable" at this time.
OOR	"Out Of Range". Control data is out of pump's operating range.

Harvard Stainless Steel		Terumo		SGE Scientific Glass Engineering		
Size	Diameter	<u>Size</u>	<u>Diameter</u>		Diameter	
		3 сс	8.95 mm	<u>Size</u>		
8 cc	9.525 mm	5	13.00	25 μl	0.73 mm	
20	19.130	10	15.80	50	1.03	
50	28.600	20	20.15	100	1.46	
100	34.900	30	23.10	250	2.30	
200	44.755	60	29.10	500	3.26	
Recto	n Dickinson	Sherwood-Monoject		1.0 ml 4.61 mm 2.5 7.28		
	tic 'Plasti-		Sperwooa-Monojeci Plastic		7.28	
	pak'			5	10.30	
Size	-	<u>Size</u>	<u>Diameter</u>	10	14.57	
	<u>Diameter</u>	1 cc	4.65 mm	Hamilton	n–Microliter	
1 cc	4.78 mm	3	8.94		Gastight	
3	8.66	6	12.70		_	
5	12.06	12	15.90	<u>Size</u>	<u>Diameter</u>	
10	14.50	20	20.40	0.5 <i>μ</i> l	0.103 mm	
20	19.13	35	23.80	1	0.1457	
30	21.70	60	26.60	2	0.206	
50/60	26.70	140	38.40	5	0.3257	
l ——			·	10	0.460	
	ir–Tite	Popper	r & Sons, Inc.	25	0.729	
'Au	l Plastic'	Perje	ktum' Glass	50	1.031	
<u>Size</u>	<u>Diameter</u>	<u>Size</u>	<u>Diameter</u>	100	1.46	
2.5 c	c 9.60 mm	0.25	cc 3.45 mm	250	2.3	
5	12.45	0.5	3.45	500	3.26	
10	15.90	1	4.50	1.0 ml	4.61 mm	
20	20.05	2	8.92	2.5	7.28	
30	22.50	3	8.99	5	10.3	
50	29.00	5	11.70	10	14.57	
		10	14.70	25	23.0	
Uı	nimetrics	20	19.58	50	32.6	
Seri	es 4000 &	30	22.70			
	5000	50	29.00	Becton	Dickinson	
<u>Size</u>	<u>Diameter</u>	100	35.70	Glass	-All Types	
10 <i>μ</i> Ι	0.460 mm		Renfac	<u>Size</u>	<u>Diameter</u>	
25	0.729		•	0.5 <i>μ</i> l	4.64 mm	
50	1.031	<u>Size</u>	<u>Diameter</u>	1 '	4.64	
100	1.460	2 cc	9.12 mm	2.5	8.66	
250	2.300	5	12.34	5	11.86	
500	3.260	10	14.55	10	14.34	
1000	4.610	20	19.86	20	19.13	
		30	23.20	30	22.70	
		50	27.60	50	28.60	
	I			100	34.90	

Minimum flow rates are taken from the smallest inside diameters and maximum flow rates are taken from the largest inside diameters of the syringes supplied by the eleven most widely used syringe manufacturers.

Nominal Minimum/Maximum Flow Rates for Various Syringes (Actual Limits will vary depending on manufacturer)								
Syringe Size	μl/hr Min.	Max.	μl/min Min.	Max.	ml/hr Min.	Max.	ml/min Min.	Max.
0.5 μl	0.0004.	IVIAA.	IVIIII.	0.79	IVIIII.	IVIAA.	IVIIII.	IVIAA.
1 μΙ	0.0004			1.58				
2 μl	0.0005			3.1				
2 μl	0.0013			7.93				
3 μι 10 μl	0.0037			15.829				
25 μl	0.0073			39.756				
25 μl	0.0365			79.519				
30 μl	0.0303			159.46				
250 μl	0.0731			155.40		23.751		
200 μl	0.1013					23.731		
	0.7281					95.418		
1000 µl	0.7281					102.580		
2 ml						373.430		
	2.8493 1.8156							
2.5 ml 3 ml						237.950		
	2.5691					336.710		
5 ml	4.9824					653.010		45.700
10 ml	7.2024							15.733
20 ml	12.5360							27.384
30 ml	16.1310							35.236
50 ml	24.4201			0.007				53.346
100 ml				0.087				91.20
140 ml				0.1053				106.60

Pump Chain Command Summary

All spaces in command are ignored. Maximum 5 digits per integer, or float data.

```
command = > [<adr>] [<cmd>] <CR>
adr
           => [d]d
                                              1 or 2 digit address
           => RUN
cmd
                                             Start pump
                STP
                                             Stop pump
                RAT [A] [<float> [<units>]] Set/query syringe 1 rate
                RAT B [<float> [<units> ] ]
                                             Set/query syringe 2 rate
                DIA [A] [<float>]
                                             Set/query syringe diameter 1
                DIA B [<float>]
                                             Set/query syringe diameter 2
                MOD [{AUT|PRO|CON}]
                                             Set/query pumping mode
                DIR [{INF|REF|REV}]
                                             Set/query pumping direction
                PAR [{ON|OFF}]
                                             Set/query Parallel/Reciprocal
                IN <d>
                                             Read TTL pin d
                OUT < d > = {ON | OFF}
                                             Set TTL pin d
                SAV
                                             Save settings in NOVRAM
                VER
                                             Query software version
units
           = > \{UM | UH | MM | MH\}
                                             μl/mn, μl/hr, ml/mn, ml/hr
```

Command Response Output Format:

```
=> [<response>] <prompt>
response
           = > <response> <response>
                <lf> <message> <cr>
           = > <lf> <adr> :
                                            Stopped
prompt
                <lf> <adr> >
                                            Syringe 1 infusing
                <lf> <adr> <
                                            Syringe 1 withdrawing
                <lf> <adr> *
                                            Pump stalled
adr
           => [d]d
                                             1 or 2 digit pump address
message
           => ?
                                            Unrecognized command
                NA
                                            Command not presently applicable
                OOR
                                            Entered value out of range
                <text>
                <integer>
                <float>
```

All spaces ignored. Maximum 5 digits per integer or floating point number.

Legend

```
float
           => ffffff
           => d1.
           => ddddd
           =>0|1|2|3|4|5|6|7|8|9
d
b
           => space
           = > (ASCII 13)
cr
1f
           = > (ASCII 10)
           = > (any string of ASCII characters)
text
<...>
                non-terminal
upper case
                terminals
                optional
[...]
{ . . . }
                select one
I
                either-or
Publication 5390-001-REV-D
```

Pump Chain

Pump Port 1: Computer

control side


Pump Port 2: Connection for

remainder of pump chain

Baud Rate: 300, 1200, 2400

or 9600

Word Size: Parity: none Stop Bits:



Appendix E: TTL Connector Specs

TTL Connections are via a 9 pin D-sub type connector. All inputs are internally pulled up to a logic high. All user definable pins are controlled via the IN and OUT pump chain commands. See Pump Chain Commands.

Pin Assignments


- Vss (Ground reference, logic low)
- 2. Directional Indicator: Low - Syring 1 Infusing High - Syringe 1 Refilling
- 3. Pump Running Indicator Low - Pumped Stopped High - Pump Running
- 4. User Definable Output
- 5. User Definable Output
- 6. Foot Switch Input Falling edge starts/stops pump
- 7. Timer Input Rising edge starts pump Falling edge stops pump
- 8. Directional control input
 - Rising edge sets Syringe 1 to infuse Logic High: 2 V 5 V Falling edge sets Syringe 1 to refill
- Directional Indicator Running Indicator User Definable Outputs 2 3 4 5 O O O O O \bigcirc Foot Switch Vcc (5V) Figure 10.TTL Connector Specifications

Logic Low: 0 V - 0.5 V

Max. 2 mA current sink

Max. 400 mA current source

9. Vcc (Logic High Reference)



Pump 33 requires no special maintenance other than keeping it clean by avoiding accidental spills of pumped material.

The two guide rods and the lead screw should be sparingly lubricated periodically with the Magnalube-G R grease provided with the pump. This Teflon R based grease is available either from Harvard Apparatus or Carleton-Stuart Corp. 13-02 44th Ave., Long Island City, NY 11101.

Solvents of any type should never be used to clean the pump. A mild detergent solution may be used to clean the keypad.

Fuse Replacement

Make sure power cord is disconnected from main supply before replacing fuse. Remove bottom cover on pump by removing four (4) rubber feet and four (4) screws. Locate fuse on power supply module. Remove fuse from fuse clip. Use caution no to break fuse when removing. Replace fuse, bottom cover, screws and rubber feet. For continued fire protection replace fuse only with 250V fuse of the specified type and rating. (3AG 1AMP 250V SLO-BLO)




Figure 11. Fuse Replacement



WARNING:

Use in manner not specified by manufacturer may impair protection provided by equipment.

RS-232 Difficulties

Verify that the baud rates and data framing parameters on all devices are the same. With a pump chain, a "Communication timeout" error on a computer is usually caused by the computer errantly handshaking on the RTS, CS and/or DSR lines. Verify pins 4, 5 and 6, on the 25 pin connector, are jumpered on the computer side of the cable.

Display Messages:

All digits flashing

Pump has not received any commands since being powered on.

StALL

Also a syringe LED and Run LED flashing. This indicates that the pusher block travel of the syringe corresponding to the syringe LED blinking has been impeded. This may be caused by the syringe plunger hitting bottom, a kink in the tubing, syringe plunger binding or any situation requiring more force to the head of the syringe than the pump is capable of delivering. To restart the pump, remove the cause of stalling and press RUN. The pump will continue the interrupted procedure where it stopped. Also note, a large increase in the pumping rate while running could also stall the motor.

oor

Out of range. A value was entered or encountered in a pump program that was beyond the pumps limits. Try using a different size syringe. Note that rates must be less than 42950. Express larger rates using different units.

Key pressed is not applicable.

Catalog No.	Product
MA1-55-4144	Foot Switch
MA1-55-7760	Daisy Chain Cable 2ft for connecting two or more pumps; need 1 cable per pump
MA1-70-2022	RS-232 Connector Cable, 7ft, 9 pin D-Sub
MA1-55-7000	Continuous Delivery Valve Box, normal pressure, 30 p.s.i. supplied with 1/8" ID x 1/4" OD silastic tubing and connector cable for connection to the syringe pump.
MA1-55-7001	Continuous Delivery High Pressure Valve Box, high pressure, 200 p.s.i. supplied with 1/4" OD 304 stainless steel tubing with SWAGELOK® fittings and a connector cable for connection to the syringe pump.

The Harvard 33 Syringe Pump lends itself to a multitude of OEM industrial applications, for all types of custom pumping or pilot plant applications. Please contact the Harvard Technical Support Department if we can be of help.

Declaration of Conformity

Application of

Council Directive(s): 73/23/EEC, 89/336/EEC

Standard(s) to which

conformity is declared: *EN61010*, *EN50082-1*, *EN50081-1*

Manufacturer's Name: Harvard Apparatus, Inc.

Manufacturer's Address: 84 October Hill Road

Holliston, Massachusetts 01746

U.S.A.

Type of Equipment: Syringe Pump

Model No.: Model 33

I, the undersigned, hereby declare that the equipment specified above conforms to the above Directive(s) and Standard(s).

Place: United States of America

Date: *November 11, 1996*

(€ ARVARD Beth Bourse (Signature)

Beth Bauman

(Full Name)

VP Engineering / Operations

(Position)



U.S.A.

Harvard Apparatus

84 October Hill Road

Holliston, Massachusetts 01746

Phone (508) 893-8999 Toll Free (800) 272-2775 Fax (508) 429-5732

E-mail bioscience@

harvardapparatus.com

Web www.harvardapparatus.com

Warner Instruments, Inc.

1125 Dixwell Avenue Hamden, CT 06514

Phone (203) 776-0664 Toll Free (800) 599-4203 Fax (203) 776-1278

E-mail sales@warneronline.com Web www.warneronline.com

Canada

Harvard Apparatus, Canada

6010 Vanden Abeele Street Saint Laurent, Quebec, H4S 1R9

Phone (514) 335-0792
Toll Free (800) 361-1905
Fax (514) 335-3482
Toll Free (800) 335-0792

E-mail sales@

Web

harvardapparatus.ca www.harvardapparatus.ca

U.K.

Harvard Apparatus, Ltd.

Fircroft Way, Edenbridge Kent TN8 6HF

Phone (44) 1732-864-001 Fax (44) 1732-863-356

E-mail sales@harvardapparatus.co.uk Web www.harvardapparatus.co.uk

France

Harvard Apparatus, S.A.R.L.

6 Avenue des Andes Miniparc – Bat. 8 F-91952, Les Ulis Cedex

Phone (33) 1-64-46-00-85 Fax (33) 1-64-46-94-38

E-mail info@harvardapparatus.fr

Germany

Hugo Sachs Elektronik

Harvard Apparatus GmbH

Gruenstrasse 1

D-79232, March - Hugstetten

Phone (49) 0 7665-92-00-0 Fax (49) 0 7665-92-00-90 E-mail Info@hugo-sachs.de Web www.hugo-sachs.de