g	GE Energy		Functional Testing Specification						
	Parts & Repair Services Louisville, KY				LOU-GED-IS200STAI				
			OSTAL din roil o	nalag I/O ta	rminal board				
Test Procedure for an IS200STAI din rail analog I/O terminal board.									
	MENT REVISION STATUS:	Determined by the last e	ntry in the "REV" a	nd "DATE" col					
REV.		DESCRIPTION			SIGNATURE	REV. DATE			
Α	Initial release. Cover card.	Initial release. Covers versions H1A, H2A, S1A, and S2A of the STAI card			J. Francis	1/08/2014			
В									
С									
	YRIGHT GENERAL ELECTI								
	pies are uncontrolled and are f		JS PROPRIETARV IN	EORMATION O	NE GENERAL ELECTRIC	COMPANY AND			
PROPRIETARY INFORMATION – THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF GENERAL ELECTRIC COMPANY AND MAY NOT BE USED OR DISCLOSED TO OTHERS, EXCEPT WITH THE WRITTEN PERMISSION OF GENERAL ELECTRIC COMPANY.									
PREPA	ARED BY	REVIEWED BY	REVIEWE	D BY	QUALITY APF	PROVAL			
J. Fra	ncis				Charlie Wa				
DATE		DATE	DATE		DATE				
1/08/2014					1/9/2014				

	g	
LOU-GED-IS200STA	GE Energy	Page 2 of 4
Rev A	Parts & Repair Services	
	Louisville, KY	

1. SCOPE

1.1 This is a functional testing procedure for an a din rail Analog I/O terminal board, versions H1A, H2A, S1A, and S2A.

2. STANDARDS OF QUALITY

2.1 Refer to the current revision of the IPC-A-610 standard for workmanship standards.

3. APPLICABLE DOCUMENTS

- **3.1** The following document(s) shall form part of this specification to the extent specified herein. Unless otherwise indicated, the latest issue shall apply.
 - **3.1.1** Check board's electronic folder for more information.

4. ENGINEERING REQUIREMENTS

- 4.1 Equipment Cleaning
 - **4.1.1** Equipment should be clean and free of debris prior to applying power unless performing an initial check. Refer to site specific SRA's for cleaning guidelines.
- **4.2** Equipment Inspection
 - **4.2.1** Equipment should be visually inspected for any defects prior to applying power. This inspection should include the following as a minimum:
 - **4.2.1.1** Wires broken, cracked, or loosely connected
 - 4.2.1.2 Terminal strips / connectors broken or cracked
 - 4.2.1.3 Components visually damaged
 - 4.2.1.4 Capacitors bloated or leaking
 - 4.2.1.5 Solder joints damaged or cold
 - 4.2.1.6 Circuit board burned or de-laminated
 - 4.2.1.7 Printed wire runs / Traces burned or damaged

5. **EQUIPMENT REQUIRED**

5.1 The following equipment is required to perform the process requirements. Equipment may be substituted provided that all accuracy's and test ratios are equivalent or better.

Qty	Reference #	Description
1	H188922	Mark Vie Simplex Test Rack with computer

GE Energy
Parts & Repair Services
Louisville, KY

LOU-GED-IS200STA Rev A

6. TESTING PROCESS

6.1 Testing Procedure



Note: The following tests assume you are familiar with using ToolboxST. You will need to perform downloads at least twice for UUT to be setup fully. You must also wait for approximately 3 minutes in between downloads for rack and UUT to reboot.

- **6.1.1** Turn "OFF" SW6 on JPDD card, just above NTRON Switches on front of test rack.
- **6.1.2** Remove test card (GOLD card) from test rack and install Unit Under Test (UUT) into test rack
- **6.1.3** Turn "ON" SW6 on JPDD card. Wait for test rack to fully boot, approximately 3 minutes.
- **6.1.4** Open **ToolboxST** and open "**UCSAH1A_Simplex_VIe**" by double-clicking on it and click the "ONLINE" button in the toolbar.
- 6.1.5 Click on the "HARDWARE" tab, then click on the "+" sign next to the "Simplex" group under the "Distributed IO" icon. This will show you all of the modules setup in the rack. The PAIC module should have a red circle with an X through it, indicating no communications.
- **6.1.6** Double click on the "X" on the PAIC Module. This will bring up a configuration box to enter the serial number of the UUT and hardware form. Click "OK" button when done.
- **6.1.7** From the menu, Download Controller Setup by going to **Device->Download->Download Wizard.** Follow instructions in dialog boxes that follow.



Note: The following portions of the test assume you are familiar with using ToolboxST. You will need to perform downloads at least twice for UUT to be setup fully. You must also wait for approximately 3 minutes in between downloads for rack and UUT to reboot.

- 6.1.8 After all downloads completed successfully, bring unit online in ToolboxST and check that the red circle with an X through it is gone and ToolboxST will communicate with PAIC Module.
- **6.1.9** Verify all 24VDC LED's are illuminated.
- **6.1.10** Click on the "Summary" tab to the right of the PAIC icon. Should display the "LIVE VALUES" in green. All values should be very close in readings.
- **6.1.11** Increasing input values should have all readings increase accordingly.
- **6.1.12** Decreasing input values should have all readings decrease accordingly.
- **6.1.13** Verify that the 2 Analog Output LED's are illuminated.

LOU-GED-IS200STA	g GE Energy	Page 4 of 4
Rev A	Parts & Repair Services Louisville, KY	

- **6.1.14** Let unit run online for at least 48 hours.
- **6.1.15** After testing has been completed successfully, remove UUT, reinstall GOLD card, and verify successfully operation in ToolboxST.
- 6.2 ***TEST COMPLETE ***

7. NOTES

7.1 Live View screens will be forthcoming and tests will be amended as needed.

8. ATTACHMENTS

8.1 None at this time.