

Water Vending Machine 829P Dual Outlet - Standalone Edition - Operation Code Manual

1. Main Screen Display Codes

Standby Status

- **Top Display (Temperature):** 2 5 C (Example: 25 degrees Celsius)
- **Bottom Display (Time):** 8. 3 0 (Example: 8:30)

System Status and Processes

- **Water Tank Empty:** E - - - - qS
- **Card Payment (Displaying Balance):**
 - If the balance is less than 10,000, it is displayed on the top screen.
 - If the balance is over 10,000, the higher digits are shown on the top screen, and the last 3 digits are shown on the bottom screen (Example: 1 0 0 0 on top, 0 0 0 on bottom, indicating a balance of 1,000,000).
- **Water Dispensing Process:**
 - **First 4 digits (Remaining Credit):** 11 2 6 (Example: 1126 credit remaining)
 - **Last 4 digits (Water Dispensed):** 0. 6 8 (Example: 0.68 liters dispensed)

Card Reading Prompts

- E - - - - 003: Region code error
- E - - - - 004: Abnormal card balance
- E - - - - gSK: Card is blacklisted
- E - - - - EEr: Card error
- E - - - - NOCP: Insufficient balance

Buzzer Alerts

- **1 Beep:** Card read successfully, ready for use.
- **2 Beeps:** Card error or card reading error.
- **3 Beeps:** Invalid card.

2. Rear Screen Display Codes

Standby Display Cycle (Each item displays for 2 seconds)

- **Temperature:**

- 2 5 C (Default value without probe)
- 1 8 C (Actual value with probe connected)
- **Year:** 2 3 (Example: Year 2023)
- **Date:** 0 7 - 1 0 (Example: July 10th)
- **Time:** 1 7 = 0 8 (Example: 17:08)
- **Source Water TDS:**
 - y - - - - (Not displayed without probe)
 - y - 5 0 0 (Actual value with probe connected)
- **Purified Water TDS:**
 - C - - - - (Not displayed without probe)
 - C - 1 0 (Actual value with probe connected)

Fault Display

- **Flow Meter Billing Failure:** E - L I U

3. Machine Parameter Settings

How to operate:

1. Press the **"Function"** button to select a parameter.
2. Press the **"Add" / "Subtract"** buttons to change the value.
3. Press the **"Function"** button to save the current value and move to the next parameter.
(Exits automatically after 1 minute of inactivity)

A. Vending Parameters (Channel 1)

Code	Parameter Name	Range/Options	Unit/Description
0A	Billing Method	1 - 3	1: Time, 2: Flow, 3: Flow Priority
1A	Card Price Base	1 - 990	Final Price = (1A) × Multiplier (FB)
2A	Pulses per 1L of Water	10 - 1599	-
3A	Card Vending Time	1 - 255	Unit: 0.1s
4A	Coin Count Setting	1 - 255	-
6A	Dispensing Volume	0.1 - 26.0	Liters

7A	Coin Price Base	1 - 990	Final Price = (7A) × Multiplier (FB)
8A	Credit Reset Time	15 - 240	Seconds
9A	Dispensing Light Delay	5 - 240	Seconds

B. Vending Parameters (Channel 2)

Code	Parameter Name	Range/Options	Unit/Description
AA	Billing Method	1 - 3	1: Time, 2: Flow, 3: Flow Priority
bA	Card Price Base	1 - 990	Final Price = (bA) × Multiplier (FB)
CA	Pulses per 1L of Water	10 - 1599	-
dA	Card Vending Time	1 - 255	Seconds
HA	Dispensing Volume	0.1 - 26.0	Liters
JA	Coin Price Base	1 - 990	Final Price = (JA) × Multiplier (FB)

C. Water Production Parameters

Code	Parameter Name	Range/Options	Unit/Description
0b	Delayed Production Type	0, 1	0: Time Delay, 1: Cumulative Volume
1b	Delay Time/Cumulative Volume	0 - 10	Minutes / *10 Liters

2b	Flushing Time	1 - 240	Seconds
3b	Flushing Interval	1 - 240	Minutes
4b	Ozone Sterilization Time	1 - 240	Seconds
5b	Ozone Sterilization Interval	1 - 240	Minutes
6b	Heating Lower Limit	1 - 35	°C
7b	Heating Upper Limit	1 - 35	°C
8bH	Ad Light On Time (Hour)	0 - 23	Hours
8bM	Ad Light On Time (Minute)	0 - 59	Minutes
9bH	Ad Light Off Time (Hour)	0 - 23	Hours
9bM	Ad Light Off Time (Minute)	0 - 59	Minutes

D. Control Parameters

Code	Parameter Name	Range/Options	Unit/Description
1C	Insulation Switch	0, 1	0: Off, 1: On
2C	Max Coin Pulse Interval	3 - 30	0.1s (Corresponds to 0.3 - 3.0 seconds)

E. System Parameters

Code	Parameter Name	Range/Options	Unit/Description
F1	Year Setting	15 - 99	-
F2	Month Setting	1 - 12	-
F3	Day Setting	1 - 31	-
F4	Hour Setting	0 - 23	-
F5	Minute Setting	0 - 59	-
F6	Second Setting	0 - 59	-
F7	Cycle Flush Time	0 - 99	Seconds (0 to disable)
F8	Cycle Flush Interval	1 - 12	Hours
F9	RTC Compensation	1 - 314	-
FA	Coin Acceptor Base (Channel 1)	1 - 100	Channel 1 Coin Amount = Coin Validator Base (FA) × Amount Multiplier (FB) × Number of Pulses
FB	Amount Multiplier (Channel 1)	1, 10, 100	
FC	Coin Acceptor Base (Channel 2)	1 - 100	Channel 2 Coin Amount = Coin Validator Base (FC) × Amount Multiplier (Fd) × Number of Pulses
Fd	Amount Multiplier (Channel 2)	1, 10, 100	
P0	Water Production Channels	1 - 2	-
P1	Coin Channels	1 - 2	-

One-Touch Rate Setting Mode

1. In standby mode, press and hold **"Subtract"** and **"Function"** simultaneously to enter.

2. The rear screen will show F--AU, followed by the mode:
 - Time Mode: S-00000
 - Flow Mode: L-00000
3. Press **"Start"** to dispense water (e.g., into a 7.5L container).
4. Once full, press **"Stop"**. The system will automatically calculate and save the rate.
5. Long-press any **"Stop"** button for 2 seconds to exit.

4. Special Functions

Operations During Power-On

- **Swipe Admin Card on Channel 1 during startup:**
 - After two beeps, displays S H I - - - O K (Time Mode) or L I U - - - O K (Flow Mode), followed by S U C C E S S K (Card Success).
- **Press "Function" + Swipe Admin Card on Channel 1 during startup:**
 - C - - - - L J: Clears total accumulated amount and total water volume.
- **Press "Subtract" + "Function" + Swipe Admin Card on Channel 1 during startup:**
 - C - - - - F L: Clears all stored information.
- **Press "Start" + "Stop" during startup:**
 - A - - - C C O K: Restores system parameters to factory settings.
- **Press "Function" + "Subtract" during startup:**
 - F r e e - - O K: Enables free water mode.
- **Press "Function" + "Add" during startup:**
 - F r e e - O F F: Disables free water mode.

Onboard Credit/Debit (Channel 1 Only)

Add Credit

1. Press **"Add"** and swipe the admin card, you will hear one beep.
2. Main screen displays F-- - - - C Z.
3. Rear screen displays 1 0 0 0 0 (recharge amount), which can be changed with **"Add"/"Subtract"**.
4. Swipe a user card to add credit. The main screen will show the new balance.
5. Success is indicated by C Z - - - - OK.
6. If it fails (exceeds limit), it will display E - - - O U E t.
7. Press **"Stop"** to exit.

Debit Credit

1. Press **"Subtract"** and swipe the admin card, you will hear one beep.
2. Main screen displays F-- - - - K F.
3. Rear screen displays 1 0 0 0 0 (debit amount), which can be changed with **"Add"/"Subtract"**.

4. Swipe a user card to debit. The main screen will show the new balance.
5. Success is indicated by K F - - - OK.
6. If it fails (insufficient funds), it will display E - - - OUEt.
7. Press **"Stop"** to exit.

Runtime Operations

- **Press "Add" and "Subtract" simultaneously:** View total machine earnings ("A" for card, "b" for coin).
- **Stored information is incorrect:** C - - - - C C

5. Power-On Display Codes

Main Screen Startup Sequence

1. **Product Model:** b - - - 8 2 9 P
2. **Display Self-Test:** 8 8 8 8 8 8 8
3. **Hardware and Software Version:** V 0. 2 C 0. 2
4. **Operating Mode:** C - - - - S H I (Time) or C - - - - L I U (Flow)

Rear Screen Startup Sequence

1. **Product Model:** 8 2 9 - 1 or 8 2 9 - 2
2. **Display Self-Test:** 8 8 8 8 8
3. **Software Version Date:** 2 3. A. 0 7 (Example: 2023-10-07)
4. **Region Code:** 0 0 0 1 8 (Example: Region Code 18)

Hongka Electronic Technology Co., Ltd.

- **Website:** www.yktwww.com
- **Phone:** 400-026-9788