


## **MOUNTING**



**LOGO** 



## RFM95W 1 9 ANT 3.3V RF\_INT 14 DIO0 RESET 5 RF\_CS 15 DIO1 NSS 4 SCK 11 DIO3 MOSI 2 MISO 10 GND GND RF95W

