use only supplied tuning tool actuate tuner carefully · do not apply too much pressure or torque keep tuning tool coaxial tuner might not be perfectly orthogonal to box